

Concept 4000

PROGRAMMING, APPLICATIONS AND REFERENCE MANUAL

P/No: 631022

INSTALLER / MASTER PIN CODES.

The default Installer PIN Code is 01.

The default Master User PIN Code is 02.

These default PIN Codes should be changed by the Installer as soon as possible.
i.e. As soon as programming commences.

UPDATES AND ADDITIONAL INFORMATION:

Check the Website regularly for:

- Additional Applications and Tables not included in this manual.**
- Updates and/or changes to existing documents.**
- New documents to be added to this manual.**

Advanced Tech Support:

<http://www.innerrange.com/support.php> (To login or create an account)

Home Page:

<http://www.innerrange.com>

Please send or fax any comments regarding this manual to:

Donald Sargent at the Head Office address. *(See page 4)*

Or e-mail to: donald.sargent@innerrange.com

Current Document Revision numbers.

Revision number relates to the Control Module Firmware Version when the document was last changed.

e.g. No changes have been made to "Area List programming" (MENU, 2, 3, 1) since V3.0 release.

Section 0. Preamble	Sec 1. Intro	Sec 2. Summ	Sec 3. Mem.	Sec 4. Bas Prg.	Sec 5. Apps	Sec 6. Prog Ref	Sec 7. Tables	Sec 8. Install.	Sec 9 Glossary
8.2	8.2	8.2	8.2	5.71	SeeBelow	SeeBelow	SeeBelow		5.6
Sec 5. Applications	Contents	Anti-Pass	AutoArm	Batt Test	Camera	Defer	Dr l'lock	Duress	EN50131
	7.84	5.61	4.5	5.6	3.0	5.12	3.01	4.5	7.82
	EvntCount	Holdup	HomAux	Inet	Latch Al	Lift	Lift HLI	Rdr Area	Rdr Toggl
	5.61	4.5	3.01	4.0	4.5	4.54	7.82	3.0	7.84
	Review	Siren	TimeRep- rt	TimedAux	Usr Count	ZoneTst	ZoneMult		
	3.0	3.0	5.6	4.5	7.8	4.5	3.5		
Sec 6. Prog Reference	1. Info	2. Access	3 Isolate	4. Testing	5. Times	6. Misc	7. Installer	8 Service	9 Control
	5.61	SeeBelow	5.6	6.21	SeeBelow	5.7	SeeBelow	6.21	5.61
Menu, 2. Access	2, 1 User	2, 2 UT			2, 5 SC	2, 6 BC	2, 7 Fob		
	7.81	6.22			6.0	4.01	5.1		
Menu, 2, 3. Lists	2, 3, 1	2, 3, 2	2, 3, 3	2, 3, 4	2, 3, 5	2, 3, 6			
	3.0	3.01	3.0	3.01	3.01	4.01			
Menu, 2, 4. Groups	2, 4, 1	2, 4, 2	2, 4, 3						
	5.61	5.64	7.82						
Menu, 5. Times	5, 1	5, 2	5, 3	5, 4	5, 5				
	5.61	5.61	3.01	4.51	5.1				
Menu, 7. Installer	7, 0 Inp	7, 1 Area				7, 6 Dr		7, 8	7, 9 Lift
	5.62	7.82				8.0		7.8	7.8
Menu, 7, 2. Modules	7, 2, 1	7, 2, 2	7, 2, 3	7, 2, 4	7, 2, 5	7, 2, 6	7, 2, 7	7, 2, 8	7, 2, 9
	8.2	6.04	6.0	7.82	5.1	5.61	4.5	7.82	4.52
Menu, 7, 2, 0. Modules	7, 2, 0, 1	7, 2, 0, 2							
	4.5	7.63							
Menu, 7, 2, 0, 0. Reg.	7,2,0,0,1	7,2,0,0,2	7,2,0,0,3						
	5.11	5.62	5.1						
Menu, 7, 3. Comms	7, 3, 1	7, 3, 2	7, 3, 3						
	7.4	3.0	5.1						
Comms Task Formats									
Contents & Overview	1 Mon	2 Ans	3 PCDir	4 IRfst	5 CID	6 EMS	7a WDirct	8 Sectel	9 Print
	7.81	3.0	5.1	6.0	8.2	8.2	7.82	6.0	8.2
10 Ext Modem	11 Inet	12 Acc	13 Poll D	14 Pac	15 IRfB	16 CidB	17 GSM	18 SN	19 4+2
	4.51	8.2	6.0	8.2	8.2	3.0	3.0	8.2	4.0
20 Buffer	21 Auto	22 32pin	23 CBus	24 Inov	25 PosDat	26 Dynal	27 HPM	28 Insight	29 Ins Int
See GSM	8.2	5.7	7.01	5.01	4.5	5.7	5.6	8.2	7.41
30 Insight ExtModem	31 SIA								
	7.4	8.2							
Menu, 7, 5. System	7, 5, 1	7, 5, 2	7, 5, 3	7, 5, 4	7, 5, 5	7, 5, 6	7, 5, 7	7, 5, 8	
	8.2	8.2	4.01	5.63	4.51	7.4	3.0	5.61	
Menu, 7, 5, 9. Auto.	7, 5, 9, 1	7, 5, 9, 2	7, 5, 9, 3						
	4.52	7.01	5.6						
Section 7. Tables:	Contents	Syst I/P	Review	CID	CID Std	Map 1	Sch30	Sch19	SIMSI
	7.01	7.02	7.82	5.2	7.1	7.1	7.1	7.1	7.0
	Acc-1	Std II	Sch19B	Securitel	SIA Mess	SIA Syst	SIA HEX	SIA Dec.	UK Def.
	7.11		7.1	7.0	7.0	7.0	7.0	7.0	7.8

Contents

Current Document Revision numbers	2
Warranty	4
Disclaimer	4
Trade Mark Acknowledgements	4
Inner Range Offices.....	4

System Overview and Introduction to Programming.

System Overview
 Conventions and Abbreviations
 System Information Menu
 Programming via the LCD Terminal
 The LAN system
 Configuring the Model 3000/Access 4000 LAN
 Model Options

Programming Summary

Memory Configurations

Introduction
 Upgrading or re-configuring
 Selection guide
 Configurations

Basic Programming Guide

Getting Started
 Alarm Processing
 Module programming
 Door programming
 Basic Lift programming
 User programming
 Central Monitoring Station communications
 Remote Access and Control
 Miscellaneous Options

Applications Programming Guide

Note: Information on Additional Applications are available on the Website.

Programming Reference Section

Detailed information on most programming options presented in numerical order according to Menu Option number.
 (Additional information available on the Website)

Tables

System Inputs
 Review Messages
 Contact ID Messages & Mapping options. ("Standard" Map provided. Other maps available on the Website)
 Securitel Map (Available on the Website only)
 SIA Messages & Mapping options. (Available on the Website only)
 Blank Programming Sheets.(Available on the Website only)

Installation and Troubleshooting

Glossary

Notes

See Page 1 of this document for Website addresses.

Warranty

Inner Range Pty Ltd is proud of the reputation it has gained in the provision of high quality electronic products. Exhaustive factory and field testing ensure that enhanced system programming features and additional hardware components operate as expected prior to their release to our customers. Extensive function testing is carried out on every Inner Range Concept product prior to it leaving the factory.

It is our intention to completely satisfy the requirements of our customers. To that end, Inner Range Pty Ltd stands behind its products with confidence.

Disclaimer

- 1) The manufacturer and/or its agents take no responsibility for any damage, financial loss or injury caused to any equipment, property or persons resulting from the correct or incorrect use of the Concept system and its peripherals. The purchaser assumes all responsibility in the use of the Concept system and its peripherals.
- 2) Whilst every effort has been made to ensure the accuracy of this manual, Inner Range Pty Ltd assumes no responsibility or liability for any errors or omissions.

Due to ongoing development the contents of this manual is subject to change without notice.

Trade Mark Acknowledgements

The Trademarks & Brand names used in this manual are the registered property of the following Corporations:

C-Bus.	Clipsal Integrated. Systems Pty Ltd. Bowden, SA, Australia.
Dynalite.	Philips Dynalite Controls. Mascot, NSW, Australia.
iControl	HPM Pty. Ltd. Auburn, NSW, Australia.
Pacom	Pacom Systems Pty. Ltd. Castle Hill, NSW, Australia.
HID/Indala/MR Access	HID Global. Irvine, CA, USA.
Keri	Keri Systems, Inc. San Jose, CA, USA.
Honeywell	Honeywell International Inc. Morristown, NJ, USA
SpreadNet	C&K Systems.
Inovonics	Inovonics Wireless Corporation, Louisville, CO. USA.
Visonic	Visonic Ltd. Tel Aviv, Israel
Paradox	Paradox Security Systems. Montreal, Canada.
Patriot	Patriot Systems Ltd. Gisborne, NZ
SIA	Security Industry Association. Alexandria, VA, USA

All other Registered names and Trademarks are the property of their respective owners.

INNER RANGE OFFICES

Head Office (& Distribution Enquires):

Inner Range Pty Ltd.
1 Millennium Court.
Knoxfield. Victoria. 3180.
Australia.
Phone: (+61 3) 9780 4300
Fax: (+61 3) 9753 3499
e-mail: admin@innerrange.com
Website: <http://www.innerrange.com>

Europe:

Inner Range (Europe) Ltd.
Units 10 & 11. Theale Lakes Business Park.
Moulden Way
Sulhampstead.
Reading. Berks. RG7 4GB
United Kingdom
Phone: +44 (0) 118 983 2647
Fax: +44 (0) 118 983 5986
e-mail: ireurope@innerrange.com

DISTRIBUTORS

Inner Range has Distributors in the following regions:

- **Australia and New Zealand**
- **UK**
- **Europe**
- **Middle East**
- **South East Asia and The Philippines**
- **China**
- **Korea**

See the Website for details and new distributors.