

Elite Version **6**
16 Zone Control Communicator

Arrowhead
Alarm Products Ltd

Installation & Programming Guide

Proudly Designed and Manufactured in New Zealand

Arrowhead Alarm Products Ltd

PHONE: (09) 414 0085
FAX: (09) 414 0088
FREEPHONE: 0800 700 123

344B Rosedale Road
Albany
AUCKLAND

PO Box 303-096
AUCKLAND 1330
NEW ZEALAND

**Copyright by Arrowhead Alarm Products Ltd
June 2002 Elite V6.20 and above.**

This manual relates to the Arrowhead Elite 16D alarm control panel
software version V6.20 and above.

Disclaimer

Arrowhead Alarm Products Ltd make no warranties regarding the content
of this document and assume no responsibility for any omissions or errors
contained herein.

To the best of our knowledge the information contained in this manual is
correct at the time of printing. Arrowhead Alarm Products Ltd reserve the
right to make changes to the features and specifications at any time
without notice in the course of product development..

CONTENTS

INTRODUCTION.....	5
Package Contents.....	5
Cabinet Details.....	6
Input Configurations (Zone Wiring Details)	7
Output Specifications.....	8
Communication Ports	8
PCB Wiring Instructions.....	9
ELITE KEYPADS.....	10
Display Indications	10
Keypad Installation.....	11
Addressing individual keypads.....	12
Displaying Memory Events at a Keypad	13
OPTIONAL ACCESSORIES.....	15
Receiver Board Installation	15
Voice Board Installation.....	15
DTMF Board Installation.....	15
ACCESSING PROGRAM MODE for the FIRST TIME	16
Accessing Installer Mode from Power-up.....	16
Accessing both Program Modes from Normal Run Mode.....	16
How to Program your Elite.....	16
How to Reset the Panel back to Factory Defaults	16
Exiting Program Modes	17
USER CODE PROGRAMMING	17
Programming User Codes	17
User Code Options.....	18
Assigning Time Zone Control to Users	18
Programming the Installer Code.....	19
Duress Digit	19
OUTPUT PROGRAM OPTIONS.....	19
Primary Output Options	19
Special Output Options.....	20
Secondary Special Output Options	20
Assigning Time Zones to Turn Outputs On/Off	21
Assigning Time Zones to Inhibit Outputs	21
KEYPAD OPTIONS	22
Assigning Keypads to Areas	22
Keypads Allowed to Arm/Stay/Bypass & Control.....	22
Keypads with Panic/Medical & Fire Alarms Enabled	22
Various Alarms to Keypad Buzzer Programming	22
Entry & Exit Beeps to Keypad Buzzer	23
Keypad LED's Off when Armed.....	23
PARTITION PARAMETERS.....	24
Primary Area Based Alarms to Outputs	24
Secondary Area Based Alarms to Outputs	24
Area Based Arm & Stay Button Options	25
Time Zone Auto Arm/Disarm of Areas.....	25
Special Area Arming and Delay Options.....	25
Area Based Miscellaneous Keypad Options	26
Area Based Special Options.....	27
Area Based Dialler Reporting Options.....	28
MISCELLANEOUS PANEL OPTIONS.....	29
Miscellaneous Panel Options.....	29
Key-switch and Tamper Options	29
ZONE PROGRAMMING.....	30
Soak Test Zones.....	30
Zone Vibration Settings	30
Single or Dual Zone Input (8 or 16 zones)	30
Input is a Short or EOL Monitored	30
Zone Response Time	31
Low Zone Program Options (Zones 1-8)	31
High Zone Program Options (Zones 9-16).....	32
PROGRAMMING DELAYS & TIMERS	34
Zone Entry Delay Times	34
Area Exit Delay Times.....	34
Two Trigger Timers	34
Stay Mode Entry Delay Times.....	34
Day Zone to Keypad & Output Active Times.....	35
Output Reset Times	35

Continued on next page

CONTENTS Continued

PROGRAMMING DELAYS & TIMERS	34
Mains Fail and Zone Alarm Reporting Delays	35
Output On Delay Times	35
Zone Inactivity & Supervised Radio Times.....	35
Output Pulse Times	35
Door Open Too Long Times.....	36
PROGRAMMING RADIO DETECTORS	36
Enrolling Radio Zones	36
Assigning Radio Zone Options.....	36
PROGRAMMING RADIO KEYS	37
Enrolling Radio Keys	37
Assigning a Radio Key Type.....	37
Assigning Area & Arm Disarm Options to Radio Keys.....	37
Assigning Output & Panic functions to Radio Keys	38
Assigning Radio Keys to Outputs	39
PROGRAMMING REAL TIME CLOCK & TIME ZONES.....	39
Setting the Real Time Clock.....	39
Daylight Savings Adjustments.....	40
Time Zone Programming	40
MISCELLANEOUS SETUP & DIAGNOSTIC DATA	41
Temporary Output Disable.....	41
Clear Output Defaults	41
Data Transfer using EE ² Board	41
Dynamic Data e.g. Keypad Address, Panel Software Version	41
Start Printing the Event Memory Buffer	41
Start Walk Test Mode	42
RESET PANEL TO FACTORY DEFAULTS.....	42
Reset Various Panel Functions to the Factory Default	42
COMMAND CONTROL OPTIONS.....	42
Programming Codes for Arm/Disarm, Output & Mic Control	42
Start of Voice Status Messages for Arm/Disarm & Outputs	43
Remote Command Control Operation	44
Local Command Control Operation	45
DIALLER PROGRAMMING.....	46
Enable Dialler & Dialling Parameters	46
Reporting Scenarios.....	46
Maximum Dial Attempts.....	47
Telephone Number Prefix.....	47
Telephone Numbers.....	47
Reporting Format for each Telephone Number.....	48
Telephone Number Options.....	49
Assigning Scenarios	49
Send Multiple Zone Alarm Reports	51
Automatic Test Call Time	51
CONTACT ID CODE & SPEECH PROGRAMMING	51
Account Code Numbers	51
Zone Alarm Event Code	51
Manual Fire/Panic/Medical Alarms Event Code	52
Zone Tamper Alarm Event Codes.....	52
Assigning Voice Messages to Zone & Manual Alarms.....	52
MISCELLANEOUS DIALLER OPTIONS	52
Area Arm/Disarm Reporting Options	52
Enabling Various Options to Report	53
Keypad & Output Listen-in Options	54
Auto- Answer Ring Count	54
Mains Failure and Zone Alarm Reporting Delays.....	54
Upload/Download Security Options.....	54
4+2 PROGRAMMING.....	55
Programming Special Characters for 4+2.....	55
COMMON CONTACT ID CODES	55
PROGRAM ADDRESS SUMMARY	56
SUMMARY OF CONTACT ID CODES SENT BY THE ELITE.....	82

INTRODUCTION

This Arrowhead Elite Version V6 alarm control panel has been designed to provide the most requested features for both the installer & the end-user. These features include ease of installation, ease of programming and user friendly operation all in a package which is reliable, functional and attractive.

Utilising many years of experience in the security industry and implementing valuable feedback, we are proud to provide you with a new generation of alarm controller. The Elite V6 is a New Zealand designed and built product which brings you the quality and features which you deserve at an affordable price. In addition to the advanced design, only the highest quality components have been used in the production of this Elite panel to ensure the highest degree of reliability.

This manual will guide you through the installation and programming of your Elite alarm panel. For additional information regarding the operation instructions and options, please refer to the enclosed "Elite User's Guide".



PACKAGE CONTENTS

This Arrowhead Elite package should contain the following items;

- 1 x Elite controller PCB
- 1 x Elite new generation backlit keypad
- 1 x Elite keypad zone list
- 1 x Elite Users Guide
- 1 x Elite cabinet & lid
- 1 x 17 volt 1.4a mains transformer
- 1 x Cabinet hardware accessory pack including,
 - 1 x Spare 1.5a fuse
 - 1 x Cabinet tamper switch
 - 1 x Cabinet tamper bracket
 - 1 x Tamper switch wire set
 - 1 x Battery lead set
 - 2 x Cabinet lid screws
 - 10 x 2k2 (red, red, red) end of line resistors
 - 10 x 4k7 (yellow, purple, red) end of line resistors
 - 10 x 8k2 (grey, red, red) end of line resistors

If any of these items are missing from this package, please contact the Arrowhead branch where you placed your order.

CABINET DETAILS



TAMPER ASSEMBLY

INPUT CONFIGURATIONS (ZONE WIRING DETAILS)

The Elite V6 has 10 separate programmable monitored analogue inputs,

- 8 x Programmable, multi-state detection inputs
- 1 x Programmable tamper input
- 1 x Programmable key-switch input

Each input must be terminated with a short or the appropriate combination of end-of-line resistors, depending upon the programmed configuration.


ZONE INPUTS - Each of the 8 zone inputs can be independently assigned one of the following configuration options;

- Type 1(8Z) 8 Zone Short circuit input NO-End-of-Line (EOL).
- Type 2(8Z) 8 Zone Single-End-of-Line 2k2 (EOL) with no tamper.
- Type 3(16Z) 16 Zone Double-End-of-Line (EOL) No Tamper.
- Type 4(16Z) 16 Zone Double-End-of-Line (EOL) With open & short circuit Tamper.


The following table shows end-of-line resistor configurations. The reference to LEDs in bold below relate to the program option setting at addresses P410E & P419E. The options 1-8 at addresses P410E & P419E relate to zone inputs 1-8. If an input is set to EOL at address P419E then it relates to the single zone being a 2K2 resistor but if zone doubling is turned on for the same input (P410E LED On) then EOL means that the tamper resistor is 2K2.

Zone Type	Low Zone	Hi Zone	Tamper
Type 1(8 Zone No EOL) P410E LEDS Off, P419E LEDS Off	N/A (Short circuit)	None	None
Type 2(8 Zone EOL, No Tamper) P410E LEDS Off, P419E LEDS On	2k2	None	None
Type 3(16 Zone EOL, No Tamper) P410E LEDS On, P419E LEDS Off	4k7	8k2	N/A
Type 4(16 Zone EOL, with Tamper) P410E LEDS On, P419E LEDS On	4k7	8k2	2k2


Type 1 (8 Zones, Short Circuit)




Type 2 (8 Zones, 2k2 EOL, No tamper)



Type 3 (16 Zones, 4k7 & 8k2 EOL with No tamper)



Type 4 (16 Zones, 4k7 & 8k2 EOL , 2k2 EOL for tamper)



LED at Address P410E (Zone Doubling) E	LED at Address P419E (EOL or Tamper) E
LED # 1 Off = Zone 1 only On = Zones 1 & 9	LED # 1 Off = No EOL On = Zone EOL or Tamper
LED # 2 Off = Zone 2 only On = Zones 2 & 10	LED # 2 Off = No EOL On = Zone EOL or Tamper
LED # 3 Off = Zone 3 only On = Zones 3 & 11	LED # 3 Off = No EOL On = Zone EOL or Tamper
LED # 4 Off = Zone 4 only On = Zones 4 & 12	LED # 4 Off = No EOL On = Zone EOL or Tamper
LED # 5 Off = Zone 5 only On = Zones 5 & 13	LED # 5 Off = No EOL On = Zone EOL or Tamper
LED # 6 Off = Zone 6 only On = Zones 6 & 14	LED # 6 Off = No EOL On = Zone EOL or Tamper
LED # 7 Off = Zone 7 only On = Zones 7 & 15	LED # 7 Off = No EOL On = Zone EOL or Tamper
LED # 8 Off = Zone 8 only On = Zones 8 & 16	LED # 8 Off = No EOL On = Zone EOL or Tamper

INPUTS Cont.

KEYSWITCH - This input can be used to control the panel via a key-switch, digital keypad or similar. This is a multi-state input which can be end-of-line configured in the same way as the 8 zone inputs. These multiple end-of-line configurations will produce either arm/disarm or stay mode on/off on an individual area basis.

TAMPER - A 24Hr tamper circuit is available for monitoring tamper status of detectors, junction boxes, cabinets and satellite sirens etc. This Tamper circuit is programmable with 2 options (P311E1E) either normally closed loop or 2k2 EOL supervision. The tamper circuit must be terminated with an end-of-line resistor if 2k2 EOL supervision is selected. The activation events to outputs for this tamper circuit are fully programmable.

AC - Connect the two low voltage wires (no polarity) from the transformer to the terminals marked AC on the Elite PCB. The Elite box includes a transformer rated at 1.4 amps at 17 volts AC and incorporates an inbuilt thermal protection fuse.

EARTH - Always connect the mains earth to the steel cabinet via the appropriately marked terminal on the mains terminal block in the steel cabinet. Also connect a lead from this earth point to the terminal marked "Earth" on the Elite PCB.

BATTERY - Connect a sealed lead acid rechargeable 12V DC battery to the battery terminals via the red and black battery leads supplied. The minimum recommended battery capacity is 7 amp hours. Battery charge current at these terminals is limited to a maximum of 300ma.

LINE IN - This pair of terminals is used to connect the Elite to the incoming telephone line from the street. The Dialler uses this line for reporting alarm events.

LINE OUT - This pair of terminals is used to connect telephones and other communication equipment to the incoming phone line via the Elite controller. The telephone line is passed through the Elite controller to ensure that the line is available to the controller when it is required.

OUTPUTS

12 VOLT OUTPUTS - There are four 12V DC outputs available on the Elite PCB. They are fuse protected suitable for powering detectors, sirens and other external devices. These outputs are marked 12v and 0v (or POS & NEG at the keypad buss), and are supplied by fuses F1 and F2. A maximum total load of 1 amp may be drawn from these terminals.

OUTPUTS 1 & 2 - These fully programmable, high current, open collector (high-going-low) type FET outputs capable of switching up to **1.5A @ 12V DC**. These 2 outputs are normally set as switched outputs, providing power for 12v sirens or piezos. However If options 2 or 3 are turned On at address P310E (2 relating to output 1 and 3 relating to output 2) then the output becomes a modulated output designed to drive an 8 ohm 10 watt horn speaker. **Also if a horn speaker is connected to Output 1 you may select the listen-in feature to this output at address P313E as well so that the dialling sequence can be heard at the speaker.**

OUTPUT 3 - This is a low current, open collector (high-going-low) type output capable of switching no more than **500ma**. Like Outputs 1 & 2 it is fully programmable.

OUTPUTS 4,5,6,7&8 - These are low current, open collector (high-going-low) type outputs capable of switching no more than **100ma**. Like Outputs 1 & 2 they are fully programmable.


NOTE: - *Connecting devices which draw current in excess of 100ma to outputs 4,5,6,7&8 may cause permanent damage to the Elite controller output concerned.*

COMMUNICATION PORTS


KEYPAD PORT - The terminals marked *POS, NEG, CLOCK, & DATA* make up the communications port which the keypads and other intelligent field devices use to talk to the Elite controller. The terminals are connected to corresponding terminals on the remote devices. The "listen" terminal is only used by the keypads and utilises a fifth wire to provide a dialler listen in facility. This feature is particularly useful when servicing monitoring faults.

SERIAL PORT - The serial port is for the connection of the RS232 serial board, the optional VOICE or DTMF Boards, or the DTU (data transfer) board. The serial board allows for printing of the 255 event buffer to a serial printer or for PC direct up/down load connection. The VOICE board allows for alarm reporting and remote control with speech messages, the DTMF board allows for remote control using tones, both from a remote telephone. The DTU board to allows program back-up and re-instatement.

PCB WIRING INSTRUCTIONS



ELITE KEYPADS



16 Zone Elite LED Keypad Window Layout

When the Elite keypad is displaying numeric values in program mode it uses the zone LEDs 1-8 to indicate a value of 1-8 and to maintain consistency with the 8 zone LED keypad, the panel uses the "A" LED to indicate a "0" and the "B" LED to indicate a "9".

"A" = 0, "B" = 9.

LIGHT	OFF	ON STEADY	FLASHING
BATTERY		Normal	Battery Low
MAINS		Normal	Mains Power Off
ARMED	Unused	Unused	Unused
MEMORY	Normal	Memory Display	New Event to View
BYPASS	Normal	Bypass Mode Active	Zone(s) Bypassed
PROGRAM	Run Mode	Client Program Mode	Installer Program Mode
TAMPER	Normal	Tamper still Active	New Tamper Alarm
LINE	Normal	Communicating	Line Fail or no Kissoff
AUX.	Unused	Unused	Unused
CONTROL	Control Function Off	Control Function On	DOTL Override On
ZONES 1-16	Zone Secure	Zone Violated	Zone in Alarm
A	Partition A Disarmed	Partition A Armed	Partition A in Stay Mode
B	Partition B Disarmed	Partition B Armed	Partition B in Stay Mode
C	Partition C Disarmed	Partition C Armed	Partition C in Stay Mode
D	Unused	Unused	Unused

KEYPAD FUNCTIONS

The Elite LED Keypad consists of; an 18 button, backlit silicone rubber keypad, 30 LED indicators and an internal piezo buzzer housed in a modern white plastic housing. The plastic housing has a hinged front lid to cover and protect the rubber buttons when not in use. All the electronics are contained on a single circuit board inside the housing.

Because the keypads communicate with the controller using data, the cable run from panel to keypads is secure against tampering. For this reason there is no tamper switch on the keypad assembly. Access to the keypad electronics will not disarm the panel.

BUTTONS

The 18 silicone rubber buttons are used for the following functions;

a-In normal operating mode the numeric keys are used for entering Access Codes. In Program Mode the numeric keys are used for entering program addresses & new values.

b-The buttons with text labels are used as function buttons and select the options indicated by the text and normally precede other button presses, e.g. to enter Bypass Mode press <**BYPASS**> and a two digit numeric key entry corresponding to the zone number you wish to be excluded eg "01" for Zone # 1, "09" for Zone # 9 and "15" for Zone # 15.

c-The **PROGRAM** Key is used to prefix option selections in the program modes e.g. <**PROGRAM**> 24 <**ENTER**> selects User Code 24 when in either of the two program modes. The **PROGRAM** key is also used prior to a Master or Installer Code to enter one of the program modes from normal operating mode.

d-The **ENTER** Key is used after entry of a sequence of numbers (eg entry of a User code to Arm or Disarm the system). As a User code can be 1-6 digits in length, the panel will not accept a code entry until the Enter key is pressed.

e-The **CONTROL** button, if enabled, is used to either turn an output on/off or disable the Day Mode alarms. The control output can be used to operate other external devices such as garage door openers, door locks, lights, etc.

LED INDICATORS

The LED indicators are used to display system conditions including Zone status, Battery state, Tamper etc. Please refer to the LED table on page 13 for a full explanation of the conditional displays.

KEYPAD INSTALLATION

Separate the two keypad halves by **carefully** inserting a small screwdriver into the release slots on the bottom edge of the keypad front half and applying a gentle pressure. This will release the bottom edge of the housing enough for you to unclip the top.

Screw the base to the wall using the mounting holes provided. These holes will match the standard single switch plate spacing. Ensure the base is mounted right side up. It is marked with the word "TOP" to aid orientation. When fixing the base to the wall make sure the top of the screw heads will not touch or short out the underside of the PCB when the top half of the keypad is reinstalled. Bring the cables through the centre of the base.

Connect the 4 or 5 wires to the 5 way terminal block on the rear of the keypad PCB making sure to match the cables up with the terminals as marked on the control panel's keypad port. The 5th wire is connected from the "LIN" terminal of the keypad to the "Listen" terminal of the Elite PCB keypad port.

Once the cables have been terminated and the required address allocated (see page 12) clip the front half of the keypad onto the base by first engaging the clips at the top edge and then close the front down and clip it in at the bottom. Now stick the zone list provided to the inside of the hinged lid.

WIRING

The Elite keypad connects to the Elite Controller via a 4 or 5 wire data & power connection. A maximum of 8 LED keypads can be connected, each wired in parallel. It is advisable that each keypad has a separate cable run from the keypad to the control panel. If the cable runs are short distances it is possible to connect two keypads at the end of one cable run but we don't recommend this. A 5th wire may be used to provide a "Listen-in" facility at the keypad. The maximum recommended cable length using standard 0.2mm² security cable is 50m. Cable runs exceeding this

distance may require 0.5mm² cable. Always use good quality cable. Some installations may require data cable to ensure data integrity in noisy sites.

KEYPAD TAMPER (wrong code alarm)

A wrong code or **Keypad Tamper** alarm is generated by the Elite after 4 consecutive invalid code entries. The controller will not “Lock-Out” the keypad at this point but simply create an alarm condition that may be reported to a monitoring company via the dialler. Entry of a valid user code will reset the Keypad Tamper alarm, however, the alarm event will be written into memory and the keypad memory light will be flashing indicating the presence of a new memory entry.

KEYPAD ADDRESS ASSIGNMENT

Keypad Address	Address Links		
	A	B	C
#			
1			
2	X		
3		X	
4	X	X	
5			X
6	X		X
7		X	X
8	X	X	X


Each of the 8 possible LED keypads which are able to be connected to your Elite panel must be addressed individually to avoid BUS conflicts and other communication problems. As default, each keypad comes addressed as #1 with all links intact.

Use the table to the left to determine which links to cut to assign the correct address to the keypads you are installing, e.g. To assign a keypad as address #2, you must cut link A only. To assign a keypad as address # 4, you must cut link A&B.

When cutting address links it is important to make a clean cut between the link blocks as shown below. Links can be restored by soldering across the effected pads.

IMPORTANT NOTE: KEYPAD ADDRESS CHANGES ARE ONLY RECOGNISED AT POWER-UP. ALL CHANGES SHOULD BE MADE IN THE POWERED DOWN STATE AND THEN ON POWER-UP THE NEW KEYPAD ADDRESS WILL BE RECOGNISED BY THE PANEL.

X denotes link is cut



VIEW MEMORY MODE

This Elite alarm panel has an event memory which stores the most recent events, (up to 255), including all alarm events, all system events such as mains failure etc as well as arming by Area. This event memory is displayed via the standard keypad with the most recent event shown first and subsequent events following in descending order from newest to oldest.

The "MEMORY" light will flash on and off when there is a new event in memory which has not been viewed. To stop the "MEMORY" light flashing, simply press the MEMORY button and the event memory will be flashed back to you with the most recent event shown first. To cancel the memory display just press "ENTER". Each event is separated by a beep tone. The memory light will also stop flashing when the system is armed.

Current System Alarms

When viewing the memory event buffer at the keypad by pressing the "MEMORY" button, the first thing that will always be displayed is the Current System Alarms that are still present. The Current System Alarms are indicated by the Memory/Mains & Battery LEDS being on plus a zone LED from 1-8 to indicate the system alarm/s present. If no Zone LED's are on at this time, it means that there are no current system alarms. If a zone LED or LED's are On then this indicates system alarms that have not yet cleared. The zone LED's 1-8 are pre-defined as to what system alarm they will display. These system alarm indications are shown in the table below. Following the display of current system alarms the panel will then sequence through the 255 historical memory events starting at the most recent event. The second table shows the alarm events that can be displayed in memory mode and what indicators are used to show them.

CURRENT SYSTEM ALARMS			
LED # 1	Battery Low	LED # 5	Radio Pendant Battery Low
LED # 2	Mains or 12V Fuse Failure	LED # 6	Supervised Detector Failure
LED # 3	Telephone Line Failure	LED # 7	Zone Inactivity Timeout
LED # 4	Radio Detector Battery Low	LED # 8	Dialler Kiss-off Failure

HISTORICAL EVENT DISPLAY CHART			
EVENT	DEVICE	INDICATOR	STATUS
ACTIVATION	Zones 1-16	LED's 1-16	On Steady
BYPASS	Zones 1-16	BYPASS LED's 1-16	On Steady On Steady
DETECTOR TAMPER (SHORT CIRCUIT)	Zones 1-8	TAMPER LED's 1-8	Flashing On Steady
DETECTOR TAMPER (OPEN CIRCUIT)	Zones 9-16	TAMPER LED's 9-16	Flashing On Steady
CABINET TAMPER	Cabinet or Satellite Siren	TAMPER	Flashing
WRONG CODE ALARM	Code Tamper at Keypad #	TAMPER LED's 1-8	On Steady On Steady
CROW KEYPAD TAMPER SWITCH ACTIVATED	Keypad Tamper Alarm at Keypad #	TAMPER LED's 1-8	On Steady On Steady
LOW BATTERY	Controller Battery	BATTERY	Flashing
MAINS FAILURE	Controller Mains Supply	MAINS	Flashing
FUSE FAILURE (F1 or F2)	Controller on-board fuses	MAINS	Flashing

VIEW MEMORY MODE Continued;

HISTORICAL EVENT DISPLAY CHART-Continued			
EVENT	DEVICE	INDICATOR	STATUS
LOW BATTERY-ZONE	Radio Zone Zone 1-16	BATTERY LED's 1-16	Flashing On Steady
LOW BATTERY-PENDANT	Radio Key User 1-20	BATTERY LED's 1-16,17,18,19,20	Flashing On Steady
ZONE INACTIVITY TIMEOUT	Zone 1-16	LED's 1-16 TAMPER CONTROL	On Steady Flashing Flashing
SUPERVISED RADIO TIMEOUT	Zone 1-16	LED's 1-16 TAMPER BYPASS	On Steady Flashing Flashing
DURESS ALARM	Duress Alarm (at Keypad #)	TAMPER LINE LED's 1-8	Flashing Flashing On Steady
KEYPAD PANIC	Panic Alarm at Keypad	LINE LED's 1-8	Flashing Flashing
KEYPAD FIRE	Fire Alarm at Keypad	LINE CONTROL	Flashing Flashing
KEYPAD MEDICAL	Medical Alarm at Keypad	LINE BYPASS	Flashing Flashing
ARMED	Area "A" Armed	"A"	On Steady
ARMED	Area "B" Armed	"B"	On Steady
ARMED	Area "C" Armed	"C"	On Steady
STAY MODE ON	Area "A" in Stay Mode	"A"	Flashing
STAY MODE ON	Area "B" in Stay Mode	"B"	Flashing
STAY MODE ON	Area "C" in Stay Mode	"C"	Flashing
TELEPHONE LINE FAIL	Panel Dialler	LINE	On Steady
EXCESSIVE RE-TRIES	Panel Dialler	LINE LED 1	On Steady On Steady
FAILURE TO GET A KISSOFF	Panel Dialler	LINE LED 2	On Steady On Steady
WALKTEST MODE	Manual Walk-test Mode	MAINS BATTERY LINE LED's 1-16	On Steady On Steady On Steady On Steady

OPTIONAL ACCESSORIES

INSTALLATION OF RX-16 RECEIVER

The Elite V6 has a high level interface with the RX-16 radio receiver. The addition of this receiver will add wireless capability to your system in the form of wireless PIR detectors, Wireless Radio-key transmitters and wireless reed switch transmitters. The RX-16 receiver connects to the same communications port as the keypads and can be installed, either inside the cabinet, or if preferred, may be installed at a remote location. The RX-16 is available in 2 frequencies, 303.875mhz or 433.92mhz. Multiple RX-16 receivers may be connected to the panel to increase the effective range if required.

The RX-16 receiver requires 4 cores and can successfully be connected via 0.2mm² unscreened cable over a distance of up to 100metres. Like the keypads the RX-16 has 12v and 0v terminals for connection to the 12v supply and CLK and DATA terminals for connection to the communications bus.

The green LED fitted to the RX-16 receiver will indicate when the unit is in "Learn" mode (LED Flashing) or when it is receiving an actual radio transmission (On Steady)

INSTALLATION OF VOICE or DTMF BOARD

The Elite V6 can also be fitted with a 90 second Voice Board or DTMF module. The Voice board stores either alarm event messages for Voice dial monitoring and /or status messages for use with Command Control. The DTMF board provides decoding of keypad numeric entries from a remote telephone. The Elite V6 Voice or DTMF Boards are installed directly onto the motherboard via the "SERIAL" socket.

Installation procedure for the Voice or DTMF Board module is as follows.

- 1 Power-down the Elite fully before starting the installation procedure.
- 2 Carefully plug the Voice or DTMF Board into the SERIAL socket.
- 3 Power-up the Elite.

Once you have installed the Voice Board you can record your personalised speech messages into the module with the speech programmer. The programmer plugs onto the 10 way strip connector on the voice board.

To record your messages once the programmer is installed, first press the reset button on the side of the Voice Board, then hold the programmer about 10 cm away from the mouth and speak clearly at normal level into the microphone while holding down the "REC" button. When you reach the end of your message release the REC button. (NOTE: Each individual message must be longer than 2 seconds duration). When recording your voice alarm message, you must ensure that you clearly identify the origin of the call. You can play the message back through the programmer by first pressing the reset button then by pressing the "PLAY" button momentarily. Because the Elite V6 can address many individual voice messages you must store individual messages at what is known as recording slots within the Voice Board. These recording slots are recorded sequentially, one message starting where the other finishes. Every time you press and release the REC button on the programmer, you create an end of message marker. These markers are used to define the recording slots within the Voice Board and can be of varying length according to each message duration.

To re-record your messages you must first press the "RESET" button on the speech module to get back to recording slot #1. Once you are at slot #1 you can re-record your messages in order as required.

NOTE: When recording multiple messages you only press the "RESET" button once at the beginning then record all messages sequentially as stated above. When you have finished recording all of your messages you can then press the "RESET" button to allow play-back of the recording messages for verification purposes.

When you have finished recording your alarm messages, unplug the programmer and the process is complete.

ACCESSING PROGRAM MODE FOR THE FIRST TIME

GENERAL INFORMATION

There are two program modes in the Elite panel. The first is the “**Client**” Program Mode to allow a system User to Add, Change or Delete User Codes.

The second mode is the “**Installer**” Program Mode. The Installer Program Mode allows ALL programmed data to be changed. Access to both Modes is described below.

ACCESS TO INSTALLER PROGRAMMING ON POWER UP

When **power is applied** to the controller for the first time, **with the panel tamper input open and none of the Areas either fully Armed or in Stay mode**, the panel will inhibit tamper alarms and ready the panel to enter INSTALLATION PROGRAM Mode (unless the Installer Lock-out option P310E7E has previously been enabled). At this point you can go to any keypad which is connected to the panel and;

Press –“**PROGRAM**”-“**ENTER**”

which will automatically put that keypad into Installation Program mode, Program LED Flashing. (NOTE: Only one keypad can be in Program mode at any time)

ACCESS TO PROGRAM MODES FROM RUN MODE

Before you can enter program mode from the normal Run Mode, the panel must be disarmed and not in stay mode. Then;

Press <**PROGRAM**> - <Code 1 (or Master Code)> - <**ENTER**>

Program light steady

Note: Default Master Code (Code 1) is 1,2,3

You are now in Client Program Mode. When you are in Client programming mode you have access to program addresses P1E to P50E (user code programming). To **Enter Installer Program Mode from Client Program Mode**;

Press <**PROGRAM**> - <Install Code> - <**ENTER**>

Program light flashing

Note: Default Installer Code (P249E) is 0,0,0,0,0,0

By default the installer can go directly to Installer Program Mode from Normal Run mode provided No Areas are Armed or in Stay Mode. The Installer Mode direct option can be disabled at address P310E Option 6.

HOW TO PROGRAM YOUR ELITE

The programming sequence always follows this pattern once you have accessed one of the Program Modes;

<**PROGRAM**> - <1,2,3 or 4 digit address> - <**ENTER**>

3 short beeps if OK - 1 long beep if error

The LED's will display current value or status

Enter the new value or option

<New Value> - <**ENTER**>

3 short beeps if OK - 1 long beep if error

An example of programming is shown below. Here we are programming User Code 23 (P23E) with the code number of 2580.

P 23 E 2,5,8,0 E

In this example the <P> represents the **PROGRAM** key, <23> represents the actual program address, 2580 is the data and <E> represents the **ENTER** key.

TO CLEAR PROGRAM INFORMATION (From Installation Mode Only)

There are multiple options available for clearing program information (Reset to defaults). These are detailed on page 41.

e.g. To reset User Codes 1-50 (P 840E)

Press <**PROGRAM**> - 840 - <**ENTER**>
3 beeps - Program light flashing

After resetting the various defaults, all options associated with that function (eg User Code Defaults P840E) will be set to the default values shown in the Program Summary at the rear of this manual. The default settings have been chosen to simplify the installation process by minimising the amount of programming necessary to get the system fully functional.

TO EXIT PROGRAM MODES

To exit program modes when you have finished programming:

Press <**PROGRAM**> - <**ENTER**>
Program light goes out

The panel is now back in normal Run Mode, any program changes you have made will have replaced previous values and be in effect.

Note: During programming Tamper and 24 hour alarms are disabled which allows quiet access to the panel, detectors and satellite siren units etc. On exiting program mode, all inputs are scanned and if any tamper or 24Hr alarms are present an activation will occur.

Note: *Where there are multiple options at one address, the numbers "0" & "9" have been reserved. Entering a "0" at the address will turn all options OFF at that address whereas entering a "9" will turn all options ON at that address.*

USER CODE PROGRAMMING

USER CODES - (P1E to P50E) & INSTALLER CODE - (P249E)

There are 51 codes available in the Elite, 50 user codes and 1 installer code. The user codes are located at addresses 1-50. By default, **Code 1 is the Master Code** because it has full access to enter program mode. Other user codes can be programmed as master codes also if required. The Installer code is stored at address 249 and is used to move from *Client Program mode* up to *Installer Program mode*.

Codes 1-50 may be varied in length from 1 to 6 digits. Code 249 must be 3-6 digits.

To program a User Code you must first be in client or installer program mode, then select the address from 1-50. (If there is already a code programmed at this address, it will be flashed back to you)

NOTE: Not all User Codes may have the ability to access Client Program Mode. The installer can restrict access to Users so that they have no access to Client Mode or they can have access to change only their code or they may have access to change all User codes as defined at addresses P101-P150.

To change User code 1 from the default setting of 1,2,3 to 9,8,7,6 you would enter the following data at the keypad.

P 1 E
(Old code is flashed back at the keypad, in this case it will be 1,2,3)
Then **9876 E**
3 beeps - program light On or Flashing
The new code will now be displayed back using the keypad LED's

To program a new user code for User 5 you would enter the following;

P 5 E
(If a code was there it would be displayed if not the display will be blank)
Then **567 E**
3 beeps - program light On or Flashing
The new code will now be displayed back using the keypad LED's

To replace a code simply enter the new code in the same address as the old code. This will overwrite the previous code but maintain the user permissions as mapped to that user number.

To clear or delete a code simply press the BYPASS button at the address where the old code is stored.

e.g. P 3 E <BYPASS> E
3 beeps - Program light On or Flashing

When flashing back codes and values Zone indicators 1-8 are used to indicate digits 1-8. The digit 0 is indicated by the "A" LED and 9 is indicated by the "B" LED

USER CODE OPTIONS

STANDARD USER CODE OPTIONS - P51E-P100E

- Option 1 - Code is assigned to Area A**
- Option 2 - Code is assigned to Area B**
- Option 3 - Code is assigned to Area C**
- Option 4 - Code can Arm Area**
- Option 5 - Code can Disarm Area**
- Option 6 - Code can turn on Stay Mode**
- Option 7 - Code can turn off Stay Mode**
- Option 8 - Code can Operate Control Functions.**

NOTE: Options 1, 2 & 3 set the Area/s the code is assigned to whereby options 4, 5, 6, 7 & 8 determine the functions the code can operate for the Area/s it has been assigned.

EXTENDED USER CODE OPTIONS - P101E-P150E

- Option 1 - Code can override DOTL timer**
- Option 2 - Code can change dialler telephone numbers**
- Option 3 - Code can alter the real time clock**
- Option 4 - User can start a print-out of the event buffer**
- Option 5 - User can answer an incoming call and start up/down load**
- Option 6 - User can enter Client Program and change their code only**
- Option 7 - User can enter Client Program and change all codes**
- Option 8 - User can allow access to Installer Program mode from Client Mode**

Option 1 - Code can override DOTL timer-The user can inhibit the door open too long function of the access control feature (Control) while in Client Mode. Refer to user manual for details.

Option 2 - Code can change dialler telephone numbers -The User can change telephone numbers from Client Mode.

Option 3 - Code can alter the real time clock -The User can adjust the Day ,Date & Time of the Panel Clock from Client Mode.

Option 4 - User can start a print-out of the event buffer -The User can cause a printout of the 255 event buffer to a serial printer from Client Mode.

Option 5 - User can answer an incoming call and start up/down load -The User can cause the panel to answer an in-coming call for upload/download from Client Mode. See P835E on Page 53.

Option 6 - User can enter Client Program and change their code only -The User can change their own code only from Client Mode.

Option 7 - User can enter Client Program and change all codes -The User can change any of the 24 User codes from Client Mode.

Option 8 - User can allow access to Installer Program mode from Client Mode – Access to Installer Mode can be granted by this user from Client Mode.

NOTE: If a user has option 7 or 8 assigned to their code then they can also initiate Walk-test Mode (P836E) from Client Program Mode.

USER CODE TIME ZONES - P151E-P200E

Users codes may have Time Zones assigned to control their operation. These Time Zones determine when a

particular user code will work. Addresses P151E - P200E are used to map the user code to the required Time Zones. The actual Time Zone parameters are defined at addresses P791E - P814E.

More than one time zone can be assigned to a code. The time zones are numbered 1-8 and are selected by the numeric buttons 1-8 on the keypad. A value of zero (0) entered at any of these addresses is fixed as 24 hour seven day access and is the default time zone for all 50 user codes.

P151E TZ E Where TZ represents any Time Zone from 1-8 valid for User Code #1
P200E TZ E Where TZ represents any Time Zone from 1-8 valid for User Code #50

NOTE: The ability to assign more than one Time Zone to each user allows for different time based controls for different days of the week.

INSTALLER CODE - P249E

This code is used to enter full Installer Program mode (Program light flashing) from Client Program mode (Program light steady) The default installer code is 000000. To change this code you Must first be in Installer Program Mode then enter your new installer code at address P249E. The new code will be flashed back to you automatically. The Installer Code may vary from 3-6 digits in length.

If the alarm is Disarmed then the Installer Code can gain access directly to Installer Program Mode provided Option 6 at address P310E is on.

DURESS DIGIT - P350E

P350E 0-9 Duress Digit (Default 0) - A Duress Alarm is activated only when the "Duress Digit" defined at this address is prefixed to a valid user code. The resulting Duress Alarm will disarm the Area in the normal way, operate an output if one is defined and report a duress event via the dialler if programmed to do so. Values of 0-9 may be entered at this address where 0 = option disabled and 1-9 represent a valid Duress digit from 1-9.

OUTPUT PROGRAM OPTIONS

PRIMARY OUTPUT OPTIONS - P201E-P208E

This block of addresses (P201E - P208E) is used to map output modifiers to each of the 8 outputs available on the Elite. The optional 4 way relay output board (OUTPUTX4) can be configured to follow the program options for any of the 8 outputs, the 4 relays can be assigned as output 1 or 5, 2 or 6, 3 or 7 & 4 or 8.

P201E 1E = Invert output #1 - Default off
2E = Flash output #1 - Default off
3E = Single pulse to output #1 - Default off
4E = Lockout output #1 once reset - Default off
5E = Output mapped to Remote Command Control - Default off
6E = Output mapped to local Command Control - Default off
7E = Day zones linked to pulse timer - Default off
8E = Output pulses on a 24 hour zone alarm - Default off

- Option 1 Invert Output** - This option is used to invert the normal state of the output. The Elite uses open collector type transistor switches and the default state of all outputs is off or high. When in alarm the transistor switch is turned on and the output is switched low. The invert option reverses this function.
- Option 2 Flash Output** - This option causes the output to switch on and off at a rate set by the pulse timer for the output when in alarm and is normally used to flash a lamp during an activation.
- Option 3 Single Pulse to Output** - This option, when applied, produces a single pulse set by the pulse timer at the output during an alarm.
- Option 4 Lockout Once Reset** - This option is used to limit the output to one operation per arming period.
- Option 5 Output mapped to Remote Command Control** - This option is used to map an output to the remote command control function whereby the output can be controlled via the telephone (this requires the optional VOICE or DTMF board to be fitted)

- Option 6 Output mapped to Local Command Control** - This option is used to map an output to the local command control feature whereby the output can be controlled directly from the keypad. The DTMF command control code at address P371 is used for this local control function.
- Option 7 Day Zones Linked to Pulse Timer** - Day Zones programmed to operate this output will pulse the output at the rate programmed for the pulse timer (e.g. if it is output #1 then the timer at P571E applies).
- Option 8 Pulsed 24 hour alarm** - If a 24 hour zone activates the alarm this option will cause the output to pulse at a rate equal to the value set for the pulse timer for this output. This feature is provided to differentiate between a burglar and fire alarm using the same siren.

P202E - P208E As per P201E above for Outputs 2-8

SPECIAL ALARMS TO OUTPUT OPTIONS - P211E - P218E

In this block of addresses P211E relates to output #1, P212E relates to output #2 etc

P211E **1E = Keypad Panic Alarm to Output #1**
 2E = Keypad Fire Alarm to Output #1
 3E = Keypad Medical Alarm to Output #1
 4E = Duress Alarm to Output #1
 5E = Wrong Code Tamper Alarm to Output #1
 6E = Radio Key Panic Alarm to Output #1
 7E = 24 Hour Zone Alarm to Output #1
 8E = 24 Hour Fire Zone Alarm to Output #1

- Option 1 Keypad Panic to Output** - This option is used to map the operation of the keypad panic button to an output i.e. when the Panic button (or 1 & 3) on a keypad is pressed any output with this option enabled will turn on.
- Option 2 Keypad Fire Alarm to Output** - This option is used to map the operation of the keypad Fire Alarm (buttons 4 & 6) to an output i.e. when the Fire Alarm (4 & 6) on a keypad is pressed any output with this option enabled will turn on.
- Option 3 Keypad Medical Alarm to Output** - This option is used to map the operation of the keypad Medical Alarm (buttons 7 & 9) to an output i.e. when the Medical Alarm (7 & 9) on a keypad is pressed any output with this option enabled will turn on.
- Option 4 Duress Alarm to Output** - This option is used to map a Duress Alarm to an output. A Duress Alarm is generated when the alarm is unset by a valid user that adds the duress digit to the beginning of their code.
- Option 5 Wrong Code Tamper Alarm to Output** - This option is used to map the Wrong Code Tamper Alarm to an output. A Wrong Code Tamper Alarm is generated if an invalid code is entered more than 4 times at a keypad. This option will cause the output to turn on when this alarm condition is present.
- Option 6 Radio Key Panic Alarm to Output** - This option is used to map the operation of the Radio Key Panic Alarm to an output i.e. when the Radio Panic is generated any output with this option enabled will turn on.
- Option 7 24 Hour Zone Alarm to Output** - This option is used to map 24 Hour Zone Alarms to an output i.e. when the 24 Hour Zone Alarm is generated any output with this option enabled will turn on.
- Option 8 24 Hour Fire Zone Alarm to Output** - This option is used to map 24 Hour Fire Alarm to an output. When the 24 Hour Fire Alarm is generated this will cause the output to flash at a rate set by the pulse timer for this output to identify the difference between a fire alarm and normal burglar alarm.

SECONDARY SPECIAL ALARMS TO OUTPUT OPTIONS - P221E - P228E

In this block of addresses P221E relates to output #1, P222E relates to output #2 etc

P221E **1E = Zone Tamper Alarm to Output #1**
 2E = System Tamper Alarm to Output #1
 3E = Mains Failure to Output #1
 4E = Panel Battery Low to Output #1

5E = Telephone Line Failure to Output #1
6E = Dialler Failure to get a Kiss-off to Output #1
7E = Automatic Pulse to Output #1
8E = 24 Hour Smoke Reset to Output #1

- Option 1 Zone Tamperers to Output** - Where dual end-of-line resistors are being used to provide individual zone tamperers this address is used to map the Zone Tamperers to an output.
- Option 2 System Tamper Alarm to Output** - This option is used to map activations of the common Tamper Input to an output. This common tamper input is normally used to monitor the panel cabinet and satellite tamper switches.
- Option 3 Mails Failure To Output** - A mains failure will be indicated at the output when this option is enabled. The Alarm Reset Timer for this output must be set to "0".
- Option 4 Panel Battery Low to Output** - A battery Low condition will be indicated at the output when this option is enabled. The Alarm Reset Timer for this output must be set to "0".
- Option 5 Telephone Line Failure to Output** - A telephone line failure will be indicated at this output when option is enabled. When the line restores this output will return to normal.
- Option 6 Dialler Failure to get a Kiss-off to Output** - If the dialler reaches its maximum dialling attempts for an alarm condition and is not kissed off, this failure will be indicated at the output. When this alarm event is accessed via Memory Mode at any keypad the output will reset back to normal.
- Option 7 Automatic Pulse to Output** - This option will cause the output to pulse (at a rate set by the pulse timer for the output) every 5 seconds. It is primarily designed to flash an external light to show that the alarm is still active (reassurance indication).
- Option 8 24 Hour Smoke Reset to Output** - This option will cause the output to pulse for 2 seconds on arming of any Area following a 24 Hour zone alarm. It is designed to allow automatic reset of smoke detectors following an alarm.

OUTPUT AUTO ON/OFF TIME ZONES - P231E - 238E

These addresses are used to map automatic ON and OFF periods to each of the outputs if required. When a time-zone starts it will cause the output to turn on and when the time-zone ends it will cause the output to turn off. The actual times assigned to each time-zone are defined at addresses P791E - P814E. Multiple Time Zones may be assigned to each output

P231E TZE Where TZ represents a Time-Zone # from 1-8 which defines the turn on and turn off times required for output #1
P232E TZE Where TZ represents a Time-Zone # from 1-8 which defines the turn on and turn off times required for output #2
P233E TZE Where TZ represents a Time-Zone # from 1-8 which defines the turn on and turn off times required for output #3

P234E - P238E As per above but for outputs 4-8

NOTE: A value of zero (0) at these addresses will disable any auto turn on turn off features at that output.

OUTPUT INHIBIT TIME ZONES - P241E - P248E

These addresses are used to map inhibit time-zones to each of the outputs as required. The assigned time-zone will enable the output so that it can be used during the time-zone. If an output has a time-zone assigned and that time-zone is off, the output cannot be turned on by any programmed function (the output is inhibited). The actual times assigned to each time-zone are defined at addresses P791E - P814E. This feature is normally used to restrict the Access Control functions to pre-determined times and days

P241E TZE Where TZ represents the time zone which enables output #1
P242E TZE Where TZ represents the time zone which enables output #2
P243E TZE Where TZ represents the time zone which enables output #3

P244E - P248E As per above but for outputs 4-8

NOTE: A value of zero (0) at these addresses will enable that output at all times.

PROGRAMMING KEYPAD OPTIONS

KEYPAD OPTIONS - P250E - P278E

The block of addresses from P250E to P278E are used to assign the basic options of each keypad in the system. Each of the addresses from P250E to P278E may have 8 options assigned where the 8 options represent the programmed keypad number. i.e. if options 1, 2 & 4 are enabled at address P250E then keypads 1, 2 and 4 would be assigned to area "A".

NOTE: A keypad can only be used to control the partition or area to which it has been assigned.

Within the display of the Elite V6 keypads you will find the indicators "A", "B" and "C". These indicators are used to show the Armed state of individual areas (LED on) or whether an area is in Stay Mode (LED flashing).

P250E	1-8E	Keypads assigned to Area A (Default 1-8) If the LED is On, the keypad is assigned to Area A.
P251E	1-8E	Keypads assigned to Area B (Default none) If the LED is On, the keypad is assigned to Area B.
P252E	1-8E	Keypads assigned to Area C (Default none) If the LED is On, the keypad is assigned to Area C.
P253E	1-8E	Keypads with permission to fully Arm (Default 1-8) If the LED is On, the keypad is allowed to Arm the assigned Area/s.
P254E	1-8E	Keypads with permission to arm Stay Mode (Default 1-8) If the LED is On, the keypad is allowed to Arm Stay Mode for the assigned Area/s.
P255E	1-8E	Keypads with permission to use the Control Function (Default 1-8) If the LED is On, the keypad can operate the "Control" function for the assigned Area/s.
P256E	1-8E	Keypads with permission to Bypass (Default 1-8) If the LED is On, the "Bypass" button on the keypad is enabled.
P257E	1-8E	Keypads with Panic button enabled (Default 1-8) If the LED is On, the "Panic" button on LED keypads is enabled and is instant.
P258E	1-8E	Keypads with delayed Panic button enabled (Default 1-8) If the LED is On, the "Panic" button on LED keypads must be held down for 2 seconds to create a panic alarm. The option at address P257E MUST be off for the delayed option to work.
P259E	1-8E	Keypads with Buttons 1 & 3 Panic Alarm enabled (Default 1-8) If the LED is On, pressing buttons 1&3 simultaneously will create a Panic alarm at the keypad.
P260E	1-8E	Keypads with Buttons 4 & 6 Fire Alarm enabled (Default 1-8) If the LED is On, pressing buttons 4&6 simultaneously will create a Fire alarm at the keypad
P261E	1-8E	Keypads with Buttons 7 & 9 Medical Alarm enabled (Default 1-8) If the LED is On, pressing buttons 7&9 simultaneously will create a Medical alarm at the keypad
P262E	1-8E	Keypads with buzzer mapped to normal zone alarms (Default 1-8) If the LED is On, a Zone alarm during the Armed state will cause the Keypad buzzer to sound (audible alarm) at the keypad.
P263E	1-8E	Keypads with buzzer mapped to stay mode zone alarms (Default 1-8) If the LED is On, a Stay Mode Zone alarm during the Armed state will cause the Keypad buzzer to sound (audible alarm) at the keypad.

P264E	1-8E	Keypads with buzzer mapped to 24 hour zone alarms (Default 1-8) If the LED is On, a 24 Hour Zone alarm will cause the Keypad buzzer to sound (audible alarm) at the keypad.
P265E	1-8E	Keypads with buzzer mapped to day mode alarms (Default 1-8) If the LED is On, a Day Zone alarm will cause the Keypad buzzer to sound (audible alarm) at the keypad.
P266E	1-8E	Keypads with buzzer mapped to armed mode exit delay beeps (Default 1-8) If the LED is On, the keypad will sound the exit beeps when the system is armed to indicate the exit delay has started.
P267E	1-8E	Keypads with buzzer mapped to stay mode exit delay beeps (Default 1-8) If the LED is On, the keypad will sound the exit beeps when stay mode is armed to indicate the exit delay has started.
P268E	1-8E	Keypads with buzzer mapped to entry delay beeps (Default 1-8) If the LED is On, the keypad will sound the entry beeps to indicate the entry delay has started.
P269E	1-8E	Keypad buzzer to warn of zone inactivity or supervised radio timeout alarm (Default 1-8) If the LED is On, a Supervised Radio signal failure or no activity on a zone for the programmed period will cause the buzzer at the keypad to sound. Pressing any button will silence the beep.
P270E	1-8E	Keypads with buzzer mapped to keypad tampers (Default 1-8) If the LED is On, a keypad tamper alarm (four incorrect attempts to enter in a code) or a Crowd keypad tamper switch alarm will cause the buzzer at the keypad to sound.
P271E	1-8E	Keypads with buzzer mapped to zone tampers (Default 1-8) If the LED is On, a zone tamper alarm will cause the buzzer at the keypad to sound.
P272E	1-8E	Keypads with buzzer mapped to system tampers (Default 1-8) If the LED is On, a system tamper alarm will cause the buzzer at the keypad to sound.
P273E	1-8E	Keypads with buzzer mapped to Pendant "Panic" Alarm (Default 1-8) If the LED is On, a radio Pendant Panic alarm will cause the buzzer at the keypad to sound.
P274E	1-8E	Keypads with buzzer mapped to keypad "Panic" or "(1 & 3)" Alarm (Default 1-8) If the LED is On, a Keypad Panic alarm will cause the buzzer at the keypad to sound.
P275E	1-8E	Keypads with buzzer mapped to keypad "Fire" (4 & 6) Alarm (Default 1-8) If the LED is On, a Keypad Fire alarm will cause the buzzer at the keypad to sound.
P276E	1-8E	Keypads with buzzer mapped to keypad "Medical" (7 & 9) Alarm (Default 1-8) If the LED is On, a Keypad Medical alarm will cause the buzzer at the keypad to sound.
P277E	1-8E	Keypads with buzzer mapped to phone line failure (Default none) If the LED is On, a Telephone Line Failure will cause the buzzer at the keypad to sound. Pressing any button will silence the beep.
P278E	1-8E	Keypads with facility to turn the LED's off after Exit Delay (Default none) If the LED is On, the Zone & System LED's on an the selected LED keypad will turn off when all areas assigned to the keypad are Armed or in Stay mode. On an LCD keypad, the LCD and the keypad button backlighting will turn off when Armed or in Stay Mode. The LED's and backlighting will automatically turn on again if there is an alarm, an entry delay is started, any button is pressed at the keypad or when the system is Disarmed.

PROGRAMMING AREA "A,B & C" PARAMETERS

AREA "A" PRIMARY OUTPUT OPTIONS - P281E - P288E

AREA "B" PRIMARY OUTPUT OPTIONS - P381E - P388E

AREA "C" PRIMARY OUTPUT OPTIONS - P481E - P488E

The addresses above allow a number Area based options to be assigned to any of the 8 outputs. Address P281 relates to Output 1 options for Area A, address P381 relates to Output 1 options for Area B and address P481 relates to Output 1 options for Area C.

- P281E** 1E = Normal zone alarms to output #1
2E = Stay Mode alarms to output #1
3E = Pendant chirps to output #1
4E = All zones sealed indication to output #1
5E = 2 second pulse on arming or disarming to output #1
6E = Spare
7E = Day zone alarms to output #1
8E = Spare

- Option 1** Normal zone alarms to output #1 - This option will map alarms from normal zone alarms from Area "A" to output #1. Normal zones are those which will only activate when the area is armed.
- Option 2** Stay Mode alarms to output #1 - This option will map alarms from zones defined as Area "A" Stay Mode to output #1. Zones are defined as being in Stay Mode at P445E and P465E
- Option 3** Pendant Chirps to output #1 - This option will map two short pulses (Chirps) to output #1 when Area "A" is armed via a radio key (Pendant) and four short pulses to output #1 when Area "A" is disarmed by a radio key. The length of the pulses (Chirps) are set by the pulse timer for this output.
- Option 4** All zones sealed indication to output #1 - This option will map an Area "A" "Ready" indication to output #1. A "Ready" indication is produced when all zones in an area are sealed, i.e. zone lights off.
- Option 5** 2 second pulse to output #1 on arming or disarming - This option will map a 2 second pulse to Output #1 each time Area "A" is armed or disarmed as defined at P302E options 6&7.
- Option 6** Spare
- Option 7** Day zone alarms (Chime) to output #1 - The option will map alarms from Area "A" zones defined as Day Zones to output #1. Zones are defined as Day Zones at P453/454E and P473/474E. Day zones are those which operate only during periods when the Area is disarmed and are normally used as door bells and shop minders etc.
- Option 8** Spare

Note: P282E through P288E are as above but apply to outputs 2-8 for Area A

Note: P382E through P388E are as above but apply to outputs 2-8 for Area B

Note: P482E through P488E are as above but apply to outputs 2-8 for Area C

AREA "A" SECONDARY OUTPUT OPTIONS - P291E - P298E

AREA "B" SECONDARY OUTPUT OPTIONS - P391E - P398E

AREA "C" SECONDARY OUTPUT OPTIONS - P491E - P498E

The addresses above allow a number of secondary Area based options to be assigned to any of the 8 outputs. Address P291 relates to Output 1 options for Area A, address P391 relates to Output 1 options for Area B and address P491 relates to Output 1 options for Area C.

- P291E** 1E = Any Bypass to output #1
2E = Auto-Bypass warning to output #1
3E = Entry beeps to output #1
4E = Exit beeps to output #1
5E = Control function to output #1
6E = Arm indication to output #1
7E = Stay Mode Arm indication to output #1
8E = Disarm indication to output #1

- Option 1 Any Bypass to output #1** - This option will produce a change of state at output #1 if any zones are bypassed, either manually or automatically. This change of state will occur at the end of the Exit delay. The output reset time (P551E) should be set to zero when this option is enabled.
- Option 2 Auto-Bypass warning to output #1** - This option will produce a 2 second pulse at output #1 at the end of the exit period if a zone has been Auto-Bypassed in Area "A". An Auto-Bypass occurs when a zone is left un-sealed at the end of the exit delay. At the end of the exit delay zones not defined as Auto-Bypass which are left un-sealed will produce an activation. Auto-Bypass assignments are found at P447E and P467E
- Option 3 Entry beeps to output #1** - This option will map the keypad entry beeps to output #1.
- Option 4 Exit beeps to output #1** - This option will map the keypad exit beeps to output #1.
- Option 5 Control function to output #1** - This option maps the control functions in Area "A" to output #1. Control function parameters for Area "A" are defined at P301E options 5-8
- Option 6 Arm indication to output #1** - This option will turn output #1 on when Area "A" is armed and turn output #1 off when Area "A" is disarmed. This change of state occurs at the start of the exit delay and when the Area is disarmed. Output reset time should be set to zero (P551E0E)
- Option 7 Stay Mode Arm indication to output 1** - This option will turn output #1 on when Area "A" is placed in Stay Mode and turn output #1 off when Area "A" Stay Mode is turned off. Like option 6 this change of state occurs either at the start of the exit delay or when the Area is disarmed. Output reset time should be set to zero (P551E0E)
- Option 8 Disarm indication to output #1** - This option will turn output #1 on when Area "A" is disarmed either from Full Arm or Stay Mode and turn output #1 off when Area "A" is Armed or in Stay Mode. Like option 6 this change of state occurs either at the start of the exit delay or when the Area is disarmed. Output reset time should be set to zero (P551E0E)

Note: P292E through P298E are as above but apply to outputs 2-8 for Area A

Note: P392E through P398E are as above but apply to outputs 2-8 for Area B

Note: P492E through P498E are as above but apply to outputs 2-8 for Area C

SPECIAL AREA ARM & STAY BUTTON OPTIONS FOR AREA A - P299E & P300E

SPECIAL AREA ARM & STAY BUTTON OPTIONS FOR AREA B - P399E & P400E

SPECIAL AREA ARM & STAY BUTTON OPTIONS FOR AREA C - P499E & P500E

P299E "ARM" key can disarm Area "A" during exit delay - This option enables the one key disarm during exit delay feature on a keypad by keypad basis for each area. Options 1-8 represent keypads 1-8.

P300E "STAY" key can disarm Area "A" during Stay Mode - This option enables single button disarm of Stay mode via the "STAY" key. Options 1-8 represent keypads 1-8

Note: P399E & P400E are as above but apply to keypads in Area B

Note: P499E & P500E are as above but apply to keypads in Area C

AREA "A" TIME ZONE AUTO ARM/DISARM OPTIONS - P290E

AREA "B" TIME ZONE AUTO ARM/DISARM OPTIONS - P390E

AREA "C" TIME ZONE AUTO ARM/DISARM OPTIONS - P490E

P290E 1-8 Time Zone to use for Auto Arm or Disarm of Area "A" (Default 0) - This option will determine which Time Zone/s will cause Area "A" to arm, disarm or both, based on the programmed options set at P303E for Area A.

Note: P390E is the same as above but applies to Area B Time Zone Arm/Disarm

Note: P490E is the same as above but applies to Area C Time Zone Arm/Disarm

AREA "A" TIME AND DELAY OPTIONS - P303E

AREA "B" TIME AND DELAY OPTIONS - P403E

AREA "C" TIME AND DELAY OPTIONS - P503E

P203E 1E = Arm area when time zone ends -Default off
 2E = Disarm area when time zone starts - Default off
 3E = Disable stay mode exit delay - Default off
 4E = Disable arm mode exit delay - Default off
 5E = Disable stay mode entry delay - Default off
 6E = Disable arm mode entry delay - Default off
 7E = Use special stay mode entry delay - Default off
 8E = Send alarms and bypasses in stay mode - Default off

- Option 1** **Arm area when time zone ends** - this option will automatically arm area "A" when the time zone programmed at address P290E finishes.
- Option 2** **Disarm area when the time zone starts** - this option will automatically disarm area "A" when the time zone programmed at address P290E starts.
- Option 3** **Disable stay mode exit delay** - If this option is on the exit delay for area "A" becomes "0" when arming stay mode (the delay will still apply to full arm unless option 4 is also on).
- Option 4** **Disable arm mode exit delay** - If this option is on the exit delay for area "A" becomes "0" when arming the panel (the delay will still apply to stay mode unless option 3 is also on).
- Option 5** **Disable stay mode entry delay** - If this option is on then all zones are instant in stay mode regardless of any entry delays programmed to zones (entry delays will still apply to zones in full arm mode unless option 6 is also on).
- Option 6** **Disable arm mode entry delay** - If this option is on then all zones are instant in full arm mode regardless of any entry delays programmed to zones (entry delays will still apply to zones in stay mode unless option 5 is also on).
- Option 7** **Use special stay mode entry delay** - If this option is on then all zones use the special Stay Mode entry delay (P540E) in stay mode and the normal delays programmed at addresses P511E—P526E are ignored.
- Option 8** **Send alarms and bypasses in stay mode** - If this option is on then all alarms and zone bypasses in Stay mode will be reported via the dialler in Contact ID. Only zone alarms will be reported if using Domestic/ Voice or Pager reporting formats. You should also note that if a Stay mode alarm is not kissed off in Domestic/ Voice or Pager mode and the alarm is not disarmed, when the dialler test time comes around, the zone alarms will report again. If this is not desired you can stop this from happening by turning of all days for the test time at address P815E.

Note: P403E is the same as above but applies to Area B Time & Delay options

Note: P503E is the same as above but applies to Area C Time & Delay options

PARTITION "A" MISCELLANEOUS KEYPAD OPTIONS - P301E

PARTITION "B" MISCELLANEOUS KEYPAD OPTIONS - P401E

PARTITION "C" MISCELLANEOUS KEYPAD OPTIONS - P501E

P301E 1E = Cannot Arm if not Ready
 2E = Arm key required before code to set
 3E = Stay key required before code to arm Stay Mode
 4E = Code required to arm area
 5E = Control function requires code
 6E = Control function toggles
 7E = Control function is momentary
 8E = Control Button disables "Day/Chime" mode or directly Controls Outputs

- Option 1** **Cannot Arm if not Ready** - This option if turned on will inhibit arming of Area "A" if any zone in area A is unsealed (Not Ready). If the option is off, the area can be armed with zones unsealed but the panel will either auto-bypass the zone or go into alarm at the end of the exit delay depending upon other option settings. If required, certain zones can be exempted from this feature if they are in low security areas, allowing the area to be armed with a zone/s unsealed, by selecting the zones at addresses P460E & P480E. This option does not apply to Stay mode.
- Option 2** **Arm key required before code to arm** - This option determines if the "ARM" key must be pressed before a code is entered to arm Area "A". This option must be enabled where a keypad is assigned to

more than one area.

- Option 3 Stay key required before code to arm Stay Mode** - This option determines if the "STAY" key is a single button function or must be pressed followed by a code to turn on Stay Mode in Area "A". This option must be enabled where a keypad is assigned to more than one area. If off, Stay mode is turned on by pressing the Stay button only, if on, you must enter a code after pressing the stay button. When Arming Stay Mode, if the user presses the "Enter" button during the exit delay, this will cancel any remaining exit delay time and make all Stay zones instant, even if they have an entry delay time programmed.
- Option 4 Code required to arm area** - If this option is off the area can be armed with a single press of the arm button, i.e. no code is required. If this option is on, a valid Area "A" user code is required to arm the area.
- Option 5 Control function requires code** - This option determines if a code is required to operate the Control function. The Control function provides the ability to operate an output from a key press rather than from an alarm event. If this option is off, pressing the "CONTROL" key will produce an output as assigned at P291E through P298E option 5. If the option is on, you must press "CONTROL" followed by a valid code assigned with the control feature to operate the control output.
- Option 6 Control function toggles** - If this function is enabled, the output which is mapped to the control function will toggle to the opposite state each time the control function is operated, i.e. if the output is on it will turn off etc. If the reset time mapped to the control output is zero the output will remain on until the control function operates again and toggles it off. If there is a reset time mapped to the control output, the output will turn off at the end of the reset time as expected. The next time the Control function is operated the output will come on again for the reset period then turn off.
- Option 7 Control function is momentary** - If this option is enabled, the output which is mapped to the control function will turn on for the time period as determined by the value of the pulse timer mapped to the control output.
- Option 8 Control Button disables "Day/Chime" mode or directly Controls Outputs** - If this option is enabled (LED 8 On), pressing the CONTROL button will put the LED keypads in the special "Control" mode, indicated by the Control LED turning on. At this point two operations may be performed. The first is that Outputs can be turned On or Off by selecting the Output number/s required. Then when you are finished, pressing the enter button will exit Control mode (for outputs to be controlled at this point option 6 at P201-P208 must be on). The second option is to press the "Program" button after pressing the "Control" button which will disable the day alarms for the area assigned to the keypad. When the day alarms disable mode is active the CONTROL light will be on. To restore the day function simply press Control then Program buttons again. A similar set of options are available on the LCD keypad but to disable day alarms you can either press and hold the "Chime" button or hold down the Control button and within 2 seconds also press the Program button to achieve the same result. On the LCD keypad it shows "Chime Off" when the day alarms are disabled.
If the option is disabled (LED 8 Off) then the control button is only used to operate the Control Output/s as assigned at addresses P291-298, 391-398, 491-498 option 5.

We advise that only one of the Control Function options be assigned at the above address.

Note: P401E is the same as above but applies to Area B Keypad options

Note: P501E is the same as above but applies to Area C Keypad options

AREA "A" MISCELLANEOUS SPECIAL OPTIONS - P302E

AREA "B" MISCELLANEOUS SPECIAL OPTIONS - P402E

AREA "C" MISCELLANEOUS SPECIAL OPTIONS - P502E

- P302E** 1E = Key-switch Input enabled
2E = Use 2nd Key-switch
3E = Key-switch is used for Arm or Stay
4E = Pendant chirps on Arming / disarming
5E = Pendant chirps on Stay Mode on / off
6E = 2 second output on Arming
7E = 2 second output on Disarming
8E = Access Control enabled even when Area is armed

- Option 1 Key-switch Input enabled** - This option will enable the Key-switch input. Operating the Key-switch input will arm Area "A" as determined by P302E option 3. The Key-switch type is programmed at P311E

options 2, 3 & 4.

- Option 2 Use 2nd Key-switch** - This option will enable dual end of line configuration of the Key-switch input and assign the high value end-of-line (8k2) to Area "A" (refer to the zone drawing on page 6 Type 3 or 4). Also option 2 at address P311E selects whether a tamper is available when the 2nd key-switch is used.
- Option 3 Key-switch is used for arm or Stay** - If this option is on, operating the Key-switch will arm Area "A". If this option is off, operating the Key-switch will turn Area "A" Stay Mode on and off.
- Option 4 Pendant Chirps on arming / disarming** - This option will send two short pulses (Chirps) to the output mapped at P281E - P288E option 3 when Area "A" is armed via a radio key (Pendant) and four short pulses to the output when Area "A" is disarmed by a radio key.
- Option 5 Pendant Chirps on Stay Mode on / off** - This option will send two short pulses (Chirps) to the output mapped at P281E - P288E option 3 when Stay Mode for Area "A" is turned on with a radio key (Pendant) and four short pulses to the output when Area "A" Stay Mode is turned off by a radio key.
- Option 6 2 second output on Arming** - If this option is on, the output which is assigned by P281E - P288E option 5 will turn on for 2 seconds when Area "A" is armed.
- Option 7 2 second output on Disarming** - If this option is on, the output which is assigned by P281E - P288E option 5 will turn on for 2 seconds when Area "A" is disarmed.
- Option 8 Access Control enabled even when area is armed** - If this option is enabled, the Access Control functions, as determined by P456E, P457E, P476E and P477E will work at all times, even when Area "A" is in the armed condition.

Note: P402E is the same as above but applies to Area B Miscellaneous options

Note: P502E is the same as above but applies to Area C Miscellaneous options

AREA BASED DIALLER REPORTING OPTIONS - P289E

P289E 1-8E Area A Reporting Options - Default 1,2

- 1 = Send Arm/Disarm**
- 2 = Send Stay Mode Arm/Disarm**
- 3 = Send Disarm only after activations**
- 4 = Send Stay Disarm only after activations**
- 5 = Send Arm at the end of the exit delay**
- 6 = Send all zone restores when disarmed**
- 7 = Spare**
- 8 = Spare**

- Option 1 Send Arm / Disarm** - If this option is on, the dialler will report Area "A" arms and disarms.
- Option 2 Send Stay Mode Arm / Disarm** - If this option is on, the dialler will report Area "A" stay mode arms and disarms.
- Option 3 Send Disarm only after activation** - If this option is on, the dialler will report an Area A disarm following an alarm activation only. This option is often used in conjunction with alarm only reporting and stops the normal arm/disarm signals from being sent. If this option is on it will override the option 1 setting.
- Option 4 Send Stay Mode Disarm only after activation** - If this option is on, the dialler will report an Area A Stay Mode disarm following an alarm activation only. This option is often used in conjunction with alarm only reporting and stops the normal Stay Mode arm/disarm signals from being sent. If this option is on it will override the option 2 setting.
- Option 5 Send Arm at the end of the exit delay** - If the LED is Off, the dialler will report an Arm immediately the panel is armed. If the LED is On, the Arm report is sent at the expiry of the exit delay.
- Option 6 Send all zone restores when disarmed** - If this option is off, the dialler will send all zone restores as they occur. If the option is on, the dialler will send all zone restores only when the panel is disarmed. If the option is On, only one restore will be sent for each zone that activates regardless of whether the zones can send multiple alarm reports

Option 7	Spare
Option 8	Spare
P389E 1-8E	Area "B" Reporting Options - (see above for details) Default 1,2
P489E 1-8E	Area "C" Reporting Options - (see above for details) Default 1,2

MISCELLANEOUS PANEL OPTIONS

MISCELLANEOUS PANEL OPTIONS - P310E

- P310E**
- 1E Ignore Mains input
 - 2E Horn Speaker Driver on Output # 1
 - 3E Horn Speaker Driver on Output # 2
 - 4E Alert Keypad LEDS off when Armed
 - 5E Ignore Zone tampers during exit delay
 - 6E Installer has direct access to program mode
 - 7E Installer lockout
 - 8E Area "C" zones are shared with Area "A" & "B", i.e. Area "C" zones become a common area.
- Option 1** **Ignore Mains Input** - If the panel must be run off a 12V DC supply only such as a solar application the 12V can be applied to the battery input and the mains input is ignored.
- Option 2** **Horn Speaker Driver on Output # 1** - The alarm panel has an on-board siren driver for driving horn speakers directly. If this option is On, the panel will drive an 8 ohm horn speaker directly from output 1. If the option is Off, the output will switch hard to 0v. NOTE: always ensure that this option is turned on first before connecting a horn speaker to the output otherwise damage will occur. Also, if the listen-in to output 1 feature is used (P313E) then this option must be turned on and a horn speaker connected to output 1 for the listen-in feature to work.
- Option 3** **Horn Speaker Driver on Output # 2** - The alarm panel has an on-board siren driver for driving horn speakers directly. If this option is On, the panel will drive an 8 ohm horn speaker directly from output 2. If the option is Off, the output will switch hard to 0v. NOTE: always ensure that this option is turned on first before connecting a horn speaker to the output otherwise damage will occur.
- Option 4** **Alert Keypad LEDS off when Armed** - If this option is on and an Alert Keypad is connected to the panel, the system LED's will turn off on the keypad when the alarm is armed. The LED's will come back on automatically when an alarm occurs, an entry delay is active, a button is pressed at the keypad or the system is disarmed.
- Option 5** **Ignore Zone tampers during exit delay** - If this option is on, any zone tampers created during the exit delay will be ignored. When the delay expires the zone tampers will be active again.
- Option 6** **Installer has direct access to program mode** - If this option is on, the installer code will allow access directly to Installer Program Mode provided no areas are armed or in stay mode.
- Option 7** **Installer lockout** - If this option is on, the installer "Back Door" power up access to program mode will be disabled. When this option is on the installer code is the only method of accessing installer program mode.
- Option 8** **Area "C" zones are shared with Areas "A" & "B"** - If the system uses zones which are common to Area "A" and Area "B" then Area "C" is used for those shared zones. If zones are not shared between A & B then Area "C" is available as a independent partition. LED's on = Shared.

MISCELLANEOUS KEY-SWITCH and TAMPER OPTIONS - P311E

- P311E**
- 1E = Cabinet tamper is loop or end-of-line
 - 2E = Key-switch input is loop or end-of-line
 - 3E = Low Key-switch is momentary or latching
 - 4E = High Key-switch is momentary or latching
 - 5E = Send Output data to keypad buss (Off = No O/P data on buss)
 - 6E = Restrict Access to Memory Mode
 - 7E = Turn off LCD backlighting during AC Fail
 - 8E = Spare
- Option 1** **Cabinet tamper is loop or end-of-line** - This option determines if the Cabinet tamper input uses

a closed loop or 2k2 end-of-line resistor. If this option is on the tamper is a 2k2.

- Option 2** **Key-switch input is loop or end-of-line** - This option determines if the Key-switch input uses a closed loop or 2k2 end-of-line resistor. If this option is on the 2k2 resistor must be fitted.
- Option 3** **Low Key-switch is momentary or latching** - This option determines if the low Key-switch (4k7) is momentary or latching. If option 3 is on the low Key-switch will be momentary.
- Option 4** **High Key-switch is momentary or latching** - This option determines if the high Key-switch (8k2) is momentary or latching. If option 4 is on the high Key-switch will be momentary.
- Option 5** **Send Output data to keypad buss** - This option allows the output updates to the keypad buss for the OUTPUTX4 board to be turned off if not needed. The LED Off means no updates to the buss.
- Option 6** **Restrict Access to Memory Mode** - If this option is off (LED 6 Off) the user has unrestricted access to memory mode (pressing the memory button will access memory mode). If this option is on, access to memory mode is restricted to code users only. To access memory mode you must press <MEMORY> <CODE> <ENTER>.
- Option 7** **Turn off LCD backlighting during AC Fail** - If this option is off (LED 7 Off) the LCD keypad backlighting will remain on during an AC fail. If this option is on, the LCD module and the LCD keypad button backlighting will turn off during AC failure. If a button is pressed on the keypad during an AC failure the backlighting will turn on for approximately 45 seconds to turn off again until the AC returns.

ZONE PROGRAMMING

SOAK TEST ZONES - P408E - P409E

If a zone is suspected of being faulty, it may be disabled by making it a Soak-test zone (excludes 24 hr Zones). This means that the zone will not cause an alarm or report via the dialler, but it will still be active during the Armed state. In this way any potential activations can be monitored via the event memory for a period of time to determine whether the detector connected to the zone input is faulty or not without creating nuisance alarms. Following any tests, if the zone is found to be OK, the Soak-test mode can be turned off for that zone which then returns it back to full operation.

P408E **SOAK-TEST ZONES - 1-8**
P409E **SOAK-TEST ZONES - 9-16**

ZONE VIBRATION SETTINGS - P411E - P418E

Only the first 8 zones may be defined as vibration sensor zones with a vibration sensitivity level as required. If a value other than zero is assigned at addresses P411E to P418E the zone which has been assigned that value automatically becomes a vibration zone. To turn a vibration zone back into a normal zone assign a zero value at the relevant address. Zero is the default setting.

P411E 0-8E **Zone 1 vibration sensitivity** - Where 0 = none, 1 is highest and 8 is lowest sensitivity level.
P412E 0-8E **Zone 2 vibration sensitivity** - Where 0 = none, 1 is highest and 8 is lowest sensitivity level.
P413E 0-8E **Zone 3 vibration sensitivity** - Where 0 = none, 1 is highest and 8 is lowest sensitivity level.
P414E 0-8E **Zone 4 vibration sensitivity** - Where 0 = none, 1 is highest and 8 is lowest sensitivity level.
P415E 0-8E **Zone 5 vibration sensitivity** - Where 0 = none, 1 is highest and 8 is lowest sensitivity level.
P416E 0-8E **Zone 6 vibration sensitivity** - Where 0 = none, 1 is highest and 8 is lowest sensitivity level.
P417E 0-8E **Zone 7 vibration sensitivity** - Where 0 = none, 1 is highest and 8 is lowest sensitivity level.
P418E 0-8E **Zone 8 vibration sensitivity** - Where 0 = none, 1 is highest and 8 is lowest sensitivity level.

SINGLE OR DUAL ZONE INPUT (8 or 16 zones) - P410E

P410E 1-8E **Single or dual zone input** - This option is used to define the Elite as an 8 or 16 zone panel where options 1-8 represent zone inputs 1-8. If a LED is on at this address it means that zone input has been assigned "Zone Doubling" whereby the zone input is used for both a low (1-8) and a high (9-16) zone. When zone doubling is used, zone 1 input is used for zones 1 & 9, Zone 2 input is used for zones 2 & 10, zones 3 input is used for zones 3 & 11 etc. Zone doubling is assigned on a zone-by-zone basis.

SHORT CIRCUIT OR END OF LINE ZONE INPUT - P419E

P419E 1-8E Short Circuit or End-of-line - This option controls whether the individual zone inputs require a 2k2 end of line (EOL) resistor or not. If zone doubling is turned off (LED off) for an input at address P410E and the corresponding input at this address is also off (LED off) then the input only requires a short circuit loop (no EOL) to seal the input and an open circuit is seen by the panel as an alarm. If this option is on and zone doubling for the same input is off then the input requires a 2k2 resistor to seal the input and if the 2k2 resistor is shorted out or open circuited then an alarm is created. If this option is off and zone doubling is on then there is no tamper monitoring on the input and only a 4k7 and 8k2 resistor are required for the two zones, an open circuit on the input in this configuration will be seen as both the low and high zones in alarm. Finally, if this option is on and zone doubling is on for the same input the 2k2 resistor must be fitted in conjunction with the 4k7 and 8k2 resistors. In this mode, a short or open circuit on the input will be seen as a zone tamper alarm.

ZONE RESPONSE TIME - P420E

P420E Zone Response Time Setting - 1-31E. Default = 6

The input response count sets the total time the zones must be in alarm before the state is recognised by the panel. A count of 1 = 45ms. The default setting of 6 therefore results in a zone response time of 270ms.

LOW ZONE PROGRAM OPTIONS (1-8) - P441E - P460E

Combinations of options in addresses P441E to P460E may be used to give the most suitable zone behaviour.

P441E 1-8E Zone is in Area "A" - Where options 1-8 represent zones 1-8. This option assigns a zone to Area "A" within a partitioned system. If the system is not partitioned, all zones must be assigned to Area "A". (Default all in Area "A") See P310E8E also.

P442E 1-8E Zone is in Area "B" - Where options 1-8 represent zones 1-8. This option assigns a zone to Area "B" within a partitioned system. (Default none in Area "B") See P310E8E also.

If a zone is defined in both Area "A" and Area "B" it is deemed to be in Area "C"

P443E 1-8E Zone is a normally open input - where options 1-8 represent zones 1-8. This option is used when normally open detectors such as smoke detectors are to be connected to a zone. The option only applies if zone doubling is turned On at P410E. Default is all zones normally closed.

P444E 1-8E Zone is a radio detector - Where options 1-8 represent zones 1-8. This option is used when Radio (wireless) devices are used as detectors. (Default none)

P445E 1-8E Stay Mode Zones - Where options 1-8 represent zones 1-8. Zones included at this address will become active when the panel is in Stay Mode. Zones not assigned at this address will be excluded. (Default 1-4) Note: Stay Mode Zones are linked to Area assignments.

P446E 1-8E Zone can be Bypassed - Where options 1-8 represent zones 1-8. This option determines if a zone can be Bypassed either manually or via the Auto-Bypass process. (Default all on)

P447E 1-8E Auto Bypass Zones - Where options 1-8 represent zones 1-8. Zones assigned Auto Bypass function at this address will be automatically bypassed by the system if they are unsealed when the exit timers expire. Zones not given Auto Bypass status will cause an activation if they are unsealed at the end of the exit delay period. (Default all on)

P448E 1-8E Zone is a handover - Where options 1-8 represent zones 1-8. Zones defined at this address as handover are given the unique ability to behave as both delay and instant zones. If a zone defined as an entry delay zone has been activated and the entry delay is running, a handover zone will behave as another entry delay zone with a delay time as defined at P511E to P526E. If an entry delay zone has not been activated and there is no entry delay running, a handover zone becomes an instant zone with no entry delay. The Handover zone **MUST** have an entry delay programmed.

P449E 1-8E Two Trigger Zones - Where options 1-8 represent zones 1-8. A zone defined as two trigger at this address will only cause an activation if one of the following conditions are met;
a The zone is triggered twice within the two trigger time period as defined by Address P534E,

P535E or P536E

- b** Any two zones defined as two trigger activate once each within the two trigger time period as defined by Address P534E, P535E or P536E
- c** A zone defined as two trigger is left violated for longer than the two trigger time period as defined by Address P534E, P535E or P536E

P450E	1-8E	Zone is 24 Hour - Where options 1-8 represent zones 1-8. 24 hour zones will activate whether the panel or area is armed or disarmed. If an entry delay is also assigned to a 24 hr zone, the alarm will not trigger unless the zone is in alarm longer than the delay time programmed. (Default none)
P451E	1-8E	Zone is 24 Hour Fire Zone - Where options 1-8 represent zones 1-8. 24 hour Fire zones will activate whether the panel or area is armed or disarmed. If an entry delay is also assigned to a 24 hr Fire zone, the alarm will not trigger unless the zone is in alarm longer than the delay time programmed. A Fire Zone will cause the output to pulse to differentiate it from a burglar alarm. (Default none)
P452E	1-8E	Zone is 24 Hour Auto-Reset - Where options 1-8 represent zones 1-8. 24 hour Auto-Reset zones will activate whether the panel or area is armed or disarmed. If an entry delay is also assigned to a 24 hr Auto-Reset zone, the alarm will not trigger unless the zone is in alarm longer than the delay time programmed. An Auto-reset zone will seal automatically when the zone input is restored back to normal i.e. does not require a code to reset an alarm. (Default none)
P453E	1-8E	Day Zones - Where options 1-8 represent zones 1-8. Day zones are active during periods where the panel or areas are disarmed and revert to normal zones during armed periods (Default none)
P454E	1-8E	Continuous Day Zone - Where options 1-8 represent zones 1-8. The zone acts as a day zone at all times (Armed and Disarmed) and will operate day alarms but not normal zone alarms (Default none)
P455E	1-8E	Siren Lockout Zones - Where options 1-8 represent zones 1-8. Zones with siren lockout designation will only cause their assigned output/s to operate once per armed period. Led on = zone locked out. (Default none)
P456E	1-8E	Access Control door position input - Where options 1-8 represent zones 1-8. The door position input becomes a 24 hour alarm zone and will alarm if the "Control" door is forced open or left open too long. It will also automatically re-lock the door after the "Control" operation has occurred and the door has been opened then closed again. (Default none)
P457E	1-8E	Access Control Request to exit input - Where options 1-8 represent zones 1-8. The Request to Exit input will operate the "Control" door output to release the door and start the Door open Too long Timer. (Default none)
P458E	1-8E	Zone will report multiple activations via dialler - Default 1-8. If this option is turned off then the relevant zone will only report one alarm to a monitoring company during any single armed period. If it is turned on, the zone can send multiple reports if activated more than once during a single armed period.
P459E	1-8E	Zone will be Monitored for Inactivity - Default none. A Zone with this option turned on will be checked to ensure that it is triggered on a regular basis. If the zone is not triggered within the time period set at P569E then an alarm will be generated as the detector may have become faulty or could be masked. The timer period as set at address P569E is only active during the disarmed period. If the timer has started due to inactivity of a zone input, the elapsed time is remembered at the time of arming and will resume when the alarm is disarmed.
P460E	1-8E	Can Arm if Zone is Unsealed - Default None. If a zone is unsealed (Not Ready) at the time of arming, by default the panel will Arm and the zone will be automatically bypassed at the end of the exit delay. If option #1 at P301,P401 or P501 is on then the panel will not Arm if a zone in that area is unsealed. If this option is set for any zone then the panel will ignore an unsealed condition on the selected zone/s and allow arming to happen.

HIGH ZONE PROGRAM OPTIONS (9-16) - P461E - P480E

Combinations of options in addresses P461E to P480E may be used to give the most suitable zone behaviour.

P461E	1-8E	Zone is in Area "A" - Where options 1-8 represent zones 9-16 respectively. This option assigns a zone to Area "A" within a partitioned system. If the system is not partitioned, all zones must be assigned to Area "A". (Default all in Area "A") See P310E8E also.
P462E	1-8E	Zone is in Area "B" - Where options 1-8 represent zones 9-16 respectively. This option assigns a zone to Area "B" within a partitioned system. (Default none in Area "B") See P310E8E also.
If a zone is defined in both Area "A" and Area "B" it is deemed to be in Area "C"		
P463E	1-8E	Zone is a normally open input - where options 1-8 represent zones 9-16 respectively. This option is used when normally open detectors such as smoke detectors are to be connected to a zone. The option only applies if zone doubling is turned On at P410E. Default is all zones normally closed.
P464E	1-8E	Zone is a radio detector - Where options 1-8 represent zones 9-16 respectively. This option is used when Radio (wireless) devices are used as detectors. (Default none)
P465E	1-8E	Stay Mode Zones - Where options 1-8 represent zones 9-16 respectively. Zones included at this address will become active when the panel is in Stay Mode. Zones not assigned at this address will be excluded. (Default 1-4) Note: Stay Mode Zones are linked to Area assignments.
P466E	1-8E	Zone can be Bypassed - Where options 1-8 represent zones 9-16 respectively. This option determines if a zone can be Bypassed either manually or via the Auto-Bypass process. (Default all on)
P467E	1-8E	Auto Bypass Zones - Where options 1-8 represent zones 9-16 respectively. Zones assigned Auto Bypass function at this address will be automatically bypassed by the system if they are unsealed when the exit timers expire. Zones not given Auto Bypass status will cause an activation if they are unsealed at the end of the exit delay period. (Default all on)
P468E	1-8E	Zone is a handover - Where options 1-8 represent zones 9-16 respectively. Zones defined at this address as handover are given the unique ability to behave as both delay and instant zones. If a zone defined as an entry delay zone has been activated and the entry delay is running, a handover zone will behave as another entry delay zone with a delay time as defined at P511E to P526E. If an entry delay zone has not been activated and there is no entry delay running, a handover zone becomes an instant zone with no entry delay. The Handover zone MUST have an entry delay programmed.
P469E	1-8E	Two Trigger Zones - Where options 1-8 represent zones 9-16 respectively. A zone defined as two trigger at this address will only cause an activation if one of the following conditions are met; a The zone is triggered twice within the two trigger time period as defined by Address P534E, P535E or P536E b Any two zones defined as two trigger activate once each within the two trigger time period as defined by Address P534E, P535E or P536E c A zone defined as two trigger is left violated for longer than the two trigger time period as defined by Address P534E, P535E or P536E
P470E	1-8E	Zone is 24 Hour - Where options 1-8 represent zones 9-16 respectively. 24 hour zones will activate whether the panel or area is armed or disarmed. If an entry delay is also assigned to a 24hr zone, the alarm will not trigger unless the zone is in alarm longer than the delay time programmed. (Default none)
P471E	1-8E	Zone is 24 Hour Fire Zone - Where options 1-8 represent zones 9-16. 24 hour Fire zones will activate whether the panel or area is armed or disarmed. If an entry delay is also assigned to a 24 hr Fire zone, the alarm will not trigger unless the zone is in alarm longer than the delay time programmed. A Fire Zone will cause the output to pulse to differentiate it from a burglar alarm. (Default none)
P472E	1-8E	Zone is 24 Hour Auto-Reset - Where options 1-8 represent zones 9-16. 24 hour Auto-Reset zones will activate whether the panel or area is armed or disarmed. If an entry delay is also assigned to a 24 hr Auto-Reset zone, the alarm will not trigger unless the zone is in alarm longer than the delay time programmed. An Auto-reset zone will seal automatically when the zone input is restored back to normal i.e. does not require a code to reset an alarm. (Default none)
P473E	1-8E	Day Zones - Where options 1-8 represent zones 9-16 respectively. Day zones are active during periods where the panel or areas are disarmed and revert to normal zones during armed periods

(Default none)

- P474E 1-8E Continuous Day Zone** - Where options 1-8 represent zones 9-16 respectively. The zone acts as a day zone at all times (Armed and Disarmed) and will operate day alarms but not normal zone alarms (Default none)
- P475E 1-8E Siren Lockout Zones** - Where options 1-8 represent zones 9-16 respectively. Zones with siren lockout designation will only cause their assigned outputs to operate once per armed period. Led on = zone locked out. (Default none)
- P476E 1-8E Access Control door position input** - Where options 1-8 represent zones 9-16 respectively. The door position input becomes a 24 hour alarm zone and will alarm if the "Control" door is forced open or left open too long. It will also automatically re-lock the door after the "Control" operation has occurred and the door has been opened then closed again. (Default none)
- P477E 1-8E Access Control Request to exit input** - Where options 1-8 represent zones 9-16 respectively. The Request to Exit input will operate the "Control" door output to release the door and start the Door open Too long Timer. (Default none)
- P478E 1-8E Zone will report multiple activations via dialler** - Where options 1-8 represent zones 9-16 respectively. If this option is turned off then the relevant zone will only report one alarm to a monitoring company during any single armed period. If it is turned on, the zone can send multiple reports if activated more than once during a single armed period.
- P479E 1-8E Zone will be Monitored for Inactivity** - Where options 1-8 represent zones 9-16 respectively. A Zone with this option turned on will be checked to ensure that it is triggered on a regular basis. If the zone is not triggered within the time period set at P569E then an alarm will be generated as the detector may have become faulty or could be masked. The timer period as set at address P569E is only active during the disarmed period. If the timer has started due to inactivity of a zone input, the elapsed time is remembered at the time of arming and will resume when the alarm is disarmed.
- P480E 1-8E Can Arm if Zone is Unsealed** - Where options 1-8 represent zones 9-16 respectively. Default None. If a zone is unsealed (Not Ready) at the time of arming, by default the panel will Arm and the zone will be automatically bypassed at the end of the exit delay. If option #1 at P301,P401 or P501 is on then the panel will not Arm if a zone in that area is unsealed. If this option is set for any zone then the panel will ignore an unsealed condition on the selected zone/s and allow arming to happen.

PROGRAMMING DELAYS & TIMERS

ZONE ENTRY DELAY TIMES - P511E to P516E

P511E	0-9999E	Zone 1 entry delay - 0-9999 seconds - default 20 seconds
P512E	0-9999E	Zone 2 entry delay - 0-9999 seconds - default 20 seconds
P513E	0-9999E	Zone 3 entry delay - 0-9999 seconds - default 0 (Instant)
P514E	0-9999E	Zone 4 entry delay - 0-9999 seconds - default 0 (Instant)
P515E	0-9999E	Zone 5 entry delay - 0-9999 seconds - default 0 (Instant)
P516E	0-9999E	Zone 6 entry delay - 0-9999 seconds - default 0 (Instant)
P517E	0-9999E	Zone 7 entry delay - 0-9999 seconds - default 0 (Instant)
P518E	0-9999E	Zone 8 entry delay - 0-9999 seconds - default 0 (Instant)
P519E	0-9999E	Zone 9 entry delay - 0-9999 seconds - default 0 (Instant)
P520E	0-9999E	Zone 10 entry delay - 0-9999 seconds - default 0 (Instant)
P521E	0-9999E	Zone 11 entry delay - 0-9999 seconds - default 0 (Instant)
P522E	0-9999E	Zone 12 entry delay - 0-9999 seconds - default 0 (Instant)
P523E	0-9999E	Zone 13 entry delay - 0-9999 seconds - default 0 (Instant)
P524E	0-9999E	Zone 14 entry delay - 0-9999 seconds - default 0 (Instant)
P525E	0-9999E	Zone 15 entry delay - 0-9999 seconds - default 0 (Instant)
P526E	0-9999E	Zone 16 entry delay - 0-9999 seconds - default 0 (Instant)

120 sec	2 min
180 sec	3 min
240 sec	4 min
300 sec	5 min
360 sec	6 min
420 sec	7 min
480 sec	8min
540 sec	9 min
600 sec	10min

AREA EXIT DELAY TIMES - P531E to P533E

P531E	0-999E	Area "A" exit delay - 0-999 seconds - Default 60 seconds
P532E	0-999E	Area "B" exit delay - 0-999 seconds - Default 60 seconds
P533E	0-999E	Area "C" exit delay - 0-999 seconds - Default 60 seconds

TWO TRIGGER TIMERS - P534E to P536E

P534E	0-999E	Area "A" Two Trigger time period - Default 60 seconds
P535E	0-999E	Area "B" Two Trigger time period - Default 60 seconds
P536E	0-999E	Area "C" Two Trigger time period - Default 60 seconds

STAY MODE ENTRY DELAY TIMES - P540E to P542E

P540E	0-999E	Area "A" Special Stay Mode entry delay - Default 20 seconds
P541E	0-999E	Area "B" Special Stay Mode entry delay - Default 20 seconds
P542E	0-999E	Area "C" Special Stay Mode entry delay - Default 20 seconds

DAY ZONE TO KEYPAD BUZZER TIMES - P543E to P545E

P543E	1-999E	Area "A" Day Zone keypad buzzer duration - Default 2 seconds
P544E	1-999E	Area "B" Day Zone keypad buzzer duration - Default 2 seconds
P545E	1-999E	Area "C" Day Zone keypad buzzer duration - Default 2 seconds

DAY ZONE TO OUTPUT TIMES - P546E to P548E

P546E	1-999E	Area "A" Day Zone to Output duration - Default 2 seconds
P547E	1-999E	Area "B" Day Zone to Output duration - Default 2 seconds
P548E	1-999E	Area "C" Day Zone to Output duration - Default 2 seconds

OUTPUT RESET TIMES - P551E to P558E

P551E	0-999E	Output #1 reset time - Default 600 seconds (10 min)
P552E	0-999E	Output #2 reset time - Default 600 seconds (10 min)
P553E	0-999E	Output #3 reset time - Default 600 seconds (10 min)
P554E	0-999E	Output #4 reset time - Default 600 seconds (10 min)
P555E	0-999E	Output #5 reset time - Default 0 (latching)
P556E	0-999E	Output #6 reset time - Default 0 (latching)
P557E	0-999E	Output #7 reset time - Default 0 (latching)
P558E	0-999E	Output #8 reset time - Default 0 (latching)

MAINS FAIL REPORTING DELAY TIME - P559E

P559E	0-999E	Mains Fail Dialler Report Delay - Default 600 seconds
-------	--------	---

ZONE ALARM REPORT DELAY TIME - P560E

P560E	0-999E	Zone Alarm Report Delay to Dialler - Default 0 seconds
-------	--------	--

OUTPUT DELAY ON TIMES - P561E to P568E

P561E	0-999E	Output #1 delay on timer - Default 0 (instant)
P562E	0-999E	Output #2 delay on timer - Default 0 (instant)
P563E	0-999E	Output #3 delay on timer - Default 0 (instant)
P564E	0-999E	Output #4 delay on timer - Default 0 (instant)
P565E	0-999E	Output #5 delay on timer - Default 0 (instant)
P566E	0-999E	Output #6 delay on timer - Default 0 (instant)
P567E	0-999E	Output #7 delay on timer - Default 0 (instant)
P568E	0-999E	Output #8 delay on timer - Default 0 (instant)

ZONE INACTIVITY DELAY TIME - P569E

P569E	0-999E	Zone Inactivity Timer (0-999 hours) - Default 120 hours
-------	--------	---

SUPERVISED RADIO SIGNAL TIME - P570E

P570E	0-999E	Supervised Radio Timer (0-999 minutes) - Default 240 minutes
-------	--------	--

OUTPUT PULSE TIMES - P571E to P578E

P571E	0-999E	Output #1 pulse time -Default 0 (0 = Minimum 0.1 sec pulse) Times are in 1/10 second
P572E	0-999E	Output #2 pulse time -Default 0 (0 = Minimum 0.1 sec pulse) increments
P573E	0-999E	Output #3 pulse time -Default 0 (0 = Minimum 0.1 sec pulse)
P574E	0-999E	Output #4 pulse time -Default 0 (0 = Minimum 0.1 sec pulse)
P575E	0-999E	Output #5 pulse time -Default 0 (0 = Minimum 0.1 sec pulse)
P576E	0-999E	Output #6 pulse time -Default 0 (0 = Minimum 0.1 sec pulse)
P577E	0-999E	Output #7 pulse time -Default 0 (0 = Minimum 0.1 sec pulse)
P578E	0-999E	Output #8 pulse time -Default 0 (0 = Minimum 0.1 sec pulse)

ELITE ACCESS CONTROL FEATURE

The Elite V6 provides a basic Access Control function which utilises the keypad "Control" Function, one of the outputs as a switching device and separate zone inputs as Request-to-Exit and door position monitoring. Addresses P456E or P476E are used to assign a zone to be the door position monitor input and address P457E or P477E are used to assign a zone as the request to exit input. Once options have been programmed, a door which is fitted with a reed switch, monitored by the zone as defined at P456E or P476E will cause a 24 hour alarm if it is opened without the Control Function being operated. Once the control function has been operated with a valid code, a door open too long (DOTL) timer is started and if the door is not closed again within the time determined by P537E (Area "A"), P538E (Area "B") or P539E (Area "C") a 24 Hr alarm will be created. The control function to output mapping is defined at addresses P291E through P298E for Area "A", P391E through P398E for Area "B" and P491E through P498E for Area "C".

P537E	1-999E	Area "A" door open too long time period - default 10 sec
P538E	1-999E	Area "B" door open too long time period - default 10 sec
P539E	1-999E	Area "C" door open too long time period - default 10 sec

PROGRAMMING RADIO DETECTORS

ENROLLING RADIO ZONES - P620E 1-16E

This address is where radio PIR's and other wireless detectors are enrolled into the Elite and assigned to zones. Assigning a zone as radio at addresses P444E & P464E will enable the zone as a wireless zone and disable the hardwired zone input at the terminals on the control board.

To load a radio detector whilst in installer program mode, for example Zone 1, press P620E1E. The keypad will beep at 1 second intervals and the green learn mode LED on the Radio receiver board (RX-16) will flash on & off. Trigger the detector you wish to enrol at this address (Zone 1) The keypad will stop beeping and the receiver learn LED will go out when the detectors code has been stored. Repeat this sequence for all of the radio detectors moving through the addresses which correspond to the zones you require.

For example;	P620E2E	Radio Zone #2
	P620E3E	Radio Zone #3
	P620E16E	Radio Zone #16

To delete a single radio code, repeat the learning process above but while in learn mode press the "Enter" button , while no transmitters are operating, and this will remove any radio code from that address.

ASSIGNING RADIO ZONE OPTIONS - P621E - P636E

This block of addresses are used to specify a specific type of radio detector. Special functions such as detector tamper alarms, low battery indication and supervised signals can be selected based on the list below.

- 1 = Crow AE Series Battery low**
- 2 = Crow AE Radio Reed Switch**
- 3 = Crow Merlin PIR (Non-supervised)**
- 4 = Crow Merlin PIR (supervised signal active)**
- 5 = Crow Fremlink checksum (supervised signal active)**
- 6 = Crow Fremlink checksum (Non-supervised)**
- 11 = Ness Devices battery Low**
- 12 = Ness Radio Reed Switch**
- 21 = Electronics Line Radio PIR**

31 = Visonic K900 Radio PIR
32 = Visonic Powercode (supervised signal ignored)
33 = Visonic Powercode (supervised signal active)

Where P621E assigns options to the radio detector at zone 1, P622E assigns options to the radio detector at zone 2 etc.

P621E Radio detector zone 1 options
P622E Radio detector zone 2 options
P623E Radio detector zone 3 options
P624E Radio detector zone 4 options
P625E Radio detector zone 5 options
P626E Radio detector zone 6 options
P627E Radio detector zone 7 options
P628E Radio detector zone 8 options

P629E Radio detector zone 9 options
P630E Radio detector zone 10 options
P631E Radio detector zone 11 options
P632E Radio detector zone 12 options
P633E Radio detector zone 13 options
P634E Radio detector zone 14 options
P635E Radio detector zone 15 options
P636E Radio detector zone 16 options

PROGRAMMING RADIO KEYS

ENROLLING RADIO KEYS - P640E 1-20E

In the Elite V6 we refer to wireless pendant transmitters as "Radio Keys". Because the Elite recognises each button as a separate function or user we refer to each button or user separately in that if you are loading a three button radio key, you would actually be enrolling 3 separate radio users. It is possible to enrol several radio users as one where you are able to program the transmitter code of the radio key (usually via dip switches) to key them alike. Where you can not program the transmitter code of the radio keys you must enrol them as separate users.

To load a radio key whilst in installer program mode, for example radio key 1, press P640E1E. The keypad will beep at 1 second intervals and the green learn mode LED on the Radio receiver board (RX-16) will flash on & off. Trigger the transmitter you wish to enrol at this address (Radio key 1). The keypad will stop beeping and the receiver learn LED will go out when the transmitters code has been stored. Repeat this sequence for all of the radio keys moving through the addresses which correspond to the keys you require.

For example;	P640E2E	Radio Key #2
	P640E3E	Radio Key #3
	P640E20E	Radio Key #20

To delete a single radio key, repeat the learning process above but while in learn mode press the "Enter" button , while no transmitters are operating, and this will remove any radio key code from that address.

ASSIGNING THE RADIO KEY TYPE - P641E-P660E

If the Radio key has any special characteristics (such as a battery low signal) then assigning a specific type here will allow the special functions to work.

P641E Radio user #1 Type - Default 0
P642E Radio user #2 Type - Default 0
P643E Radio user #3 Type - Default 0
P644E Radio user #4 Type - Default 0
P645E Radio user #5 Type - Default 0
P646E Radio user #6 Type - Default 0
P647E Radio user #7 Type - Default 0
P648E Radio user #8 Type - Default 0
P649E Radio user #9 Type - Default 0
P650E Radio user #10 Type - Default 0
P651E Radio user #11 Type - Default 0
P652E Radio user #12 Type - Default 0
P653E Radio user #13 Type - Default 0
P654E Radio user #14 Type - Default 0
P655E Radio user #15 Type - Default 0
P656E Radio user #16 Type - Default 0
P657E Radio user #17 Type - Default 0
P658E Radio user #18 Type - Default 0
P659E Radio user #19 Type - Default 0
P660E Radio user #20 Type - Default 0

RADIO KEY TYPES

0 = Non-specific
1 = Crow
21 = Ness
31 = Visonic

ASSIGNING AREA & ARM DISARM OPTIONS TO RADIO KEYS - P661E - P680E

In the same way that permissions are set for user codes, Radio Keys are also assigned permissions which determine their functionality.

P661E 1E = Radio user #1 is assigned to Area "A" (Default 1,4,5)
2E = Radio user #1 is assigned to Area "B"
3E = Radio user #1 is assigned to Area "C"
4E = Radio user #1 will arm
5E = Radio user #1 will disarm
6E = Radio user #1 can Arm Stay Mode on
7E = Radio user #1 can Disarm Stay Mode off
8E = Radio user #1 is disabled during alarm state

- Option 1** Radio user #1 is assigned to Area "A" - The functions set by options 4-7 will be active in Area "A"
- Option 2** Radio user #1 is assigned to Area "B" - The functions set by options 4-7 will be active in Area "B"
- Option 3** Radio user #1 is assigned to Area "C" - The functions set by options 4-7 will be active in Area "C"
- Option 4** Radio user #1 will arm - When this option is enabled, radio user #1 will arm whichever area is assigned by options 1-3
- Option 5** Radio user #1 will disarm - When this option is enabled, radio user #1 will disarm whichever area is assigned by options 1-3
- Option 6** Radio user #1 can Arm Stay Mode - When this option is enabled, radio user #1 will turn Stay Mode on in whichever area is assigned by options 1-3
- Option 7** Radio user #1 can Disarm Stay Mode - When this option is enabled, radio user #1 will turn Stay Mode off in whichever area is assigned by options 1-3
- Option 8** Radio user #1 is disabled during alarm state - When this option is enabled, radio user #1 can not be used to reset an alarm, i.e. it must be reset at the keypad.

Where P661E sets options for radio user #1, P662 sets options for radio user #2 etc

P661E	Radio user #1 options	P671E	Radio user #11 options
P662E	Radio user #2 options	P672E	Radio user #12 options
P663E	Radio user #3 options	P673E	Radio user #13 options
P664E	Radio user #4 options	P674E	Radio user #14 options
P665E	Radio user #5 options	P675E	Radio user #15 options
P666E	Radio user #6 options	P676E	Radio user #16 options
P667E	Radio user #7 options	P677E	Radio user #17 options
P668E	Radio user #8 options	P678E	Radio user #18 options
P669E	Radio user #9 options	P679E	Radio user #19 options
P670E	Radio user #10 options	P680E	Radio user #20 options

ASSIGNING OUTPUT & PANIC OPTIONS TO RADIO KEYS - P681E - P700E

P681E 1E = Radio user #1 turns control function on
2E = Radio user #1 turns control function off (Toggles if 1 on)
3E = Radio user #1 turns output on
4E = Radio user #1 turns output off (Toggles if 3 ON)
5E = Radio user #1 is instant panic
6E = Radio user #1 is delayed panic (1.5 sec)
7E = Spare
8E = Spare

- Option 1** Radio user #1 turns control function on - When this option is enabled, the radio user will turn on the Control Function as if it were operated from the keypad.
- Option 2** Radio user #1 turns control function off - When this option is enabled, the radio user will turn the control output off as if it were operated from the keypad. (Dependant on control options)

Option 3	Radio user #1 turns output on - When this option is enabled, the radio user will turn on the output as assigned by P581E.
Option 4	Radio user #1 turns output off - When this option is enabled, the radio user will turn off the output as assigned by P581E. This function is only valid when there is no reset time assigned to the output in question.
Option 5	Radio user #1 is instant panic - When this option is enabled, the radio user will produce an instant panic.
Option 6	Radio user #1 is delayed panic - When this option is enabled, the radio user will produce a delayed panic after transmitting continuously for 1.5 seconds.
Option 7	Spare
Option 8	Spare

Where P681E sets the second set of options for radio user #1, P682 sets options for radio user #2 etc

P681E	Radio user #1 options	P691E	Radio user #11 options
P682E	Radio user #2 options	P692E	Radio user #12 options
P683E	Radio user #3 options	P693E	Radio user #13 options
P684E	Radio user #4 options	P694E	Radio user #14 options
P685E	Radio user #5 options	P695E	Radio user #15 options
P686E	Radio user #6 options	P696E	Radio user #16 options
P687E	Radio user #7 options	P697E	Radio user #17 options
P688E	Radio user #8 options	P698E	Radio user #18 options
P689E	Radio user #9 options	P699E	Radio user #19 options
P690E	Radio user #10 options	P700E	Radio user #20 options

ASSIGNING RADIO KEYS TO OUTPUTS - P701E to P720E

This block of addresses are used to map radio keys to outputs in conjunction with P681E - P700E. All output modifiers such as reset timers and lock out functions are maintained and will determine the behaviour of the assigned output.

P701E	1-8E	Radio user #1 to output 1-8 - Where options 1-8 represent outputs 1-8
P702E	1-8E	Radio user #2 to output 1-8 - Where options 1-8 represent outputs 1-8
P703E	1-8E	Radio user #3 to output 1-8 - Where options 1-8 represent outputs 1-8
P704E	1-8E	Radio user #4 to output 1-8 - Where options 1-8 represent outputs 1-8
P705E	1-8E	Radio user #5 to output 1-8 - Where options 1-8 represent outputs 1-8
P706E	1-8E	Radio user #6 to output 1-8 - Where options 1-8 represent outputs 1-8
P707E	1-8E	Radio user #7 to output 1-8 - Where options 1-8 represent outputs 1-8
P708E	1-8E	Radio user #8 to output 1-8 - Where options 1-8 represent outputs 1-8
P709E	1-8E	Radio user #9 to output 1-8 - Where options 1-8 represent outputs 1-8
P710E	1-8E	Radio user #10 to output 1-8 - Where options 1-8 represent outputs 1-8
P711E	1-8E	Radio user #11 to output 1-8 - Where options 1-8 represent outputs 1-8
P712E	1-8E	Radio user #12 to output 1-8 - Where options 1-8 represent outputs 1-8
P713E	1-8E	Radio user #13 to output 1-8 - Where options 1-8 represent outputs 1-8
P714E	1-8E	Radio user #14 to output 1-8 - Where options 1-8 represent outputs 1-8
P715E	1-8E	Radio user #15 to output 1-8 - Where options 1-8 represent outputs 1-8
P716E	1-8E	Radio user #16 to output 1-8 - Where options 1-8 represent outputs 1-8
P717E	1-8E	Radio user #17 to output 1-8 - Where options 1-8 represent outputs 1-8
P718E	1-8E	Radio user #18 to output 1-8 - Where options 1-8 represent outputs 1-8
P719E	1-8E	Radio user #19 to output 1-8 - Where options 1-8 represent outputs 1-8
P720E	1-8E	Radio user #20 to output 1-8 - Where options 1-8 represent outputs 1-8

PROGRAMMING REAL TIME CLOCK AND TIME ZONES

SETTING THE REAL TIME CLOCK - P823E - P827E

These addresses are used to set the internal real time clock used by the time zone functions, time & date stamping

of events in the event buffer and the time for any automatic test calls to a monitoring station.

P823E 1-7E Set day of the week - where values of 1-7 represent Sunday to Saturday (Sunday = 1)
P824E 0000 - 2359E Set time - Use 24 hour format
P825E 1-31E Set day of the month - where values of 1-31 represent days in the month.
P826E 1-12E Set Month - where values of 1-12 represent the month.
P827E 0-99 Set Year - Where 0-99 represent years, i.e. 02 = 2002.

PROGRAMMING DAYLIGHT SAVING ADJUSTMENTS - P817E - P822E

As the Elite controller has a real time clock compliant with minutes & hours of the day, days of the week and months of the year, provision has been made for automatic adjustments for daylight saving. This block of addresses provides the Elite with the information required to perform the daylight saving adjustments as required.

P817E 0-5E Daylight Saving Start Sunday - This is the Sunday number in the month that daylight saving will begin (values of 1-5 are allowed). Default = 1
P818E 0-12E Daylight Saving Start Month - This is month in which the above Sunday will occur. (Values of 1-12 are allowed). Default = 10
P819E 0-24E Daylight Saving Start Hour - This is the hour that daylight savings will begin (values of 0-24 are allowed). Default = 2
P820E 0-5E Daylight Saving End Sunday - This is the Sunday number in the month that daylight savings will end (values of 1-5 are allowed). Default = 3
P821E 0-12E Daylight Saving End Month - This is the month in which the Sunday number will occur (values of 1-12 are allowed). Default = 3
P822E 0-24E Daylight Saving End Hour - This is the hour that daylight savings will end (values of 0-24 are allowed). Default = 3

TIME ZONE PROGRAMMING - P791E - P814E

This block of addresses are used to define the time zones used by outputs, users and the Auto Arm/Disarm feature. Time zones require a start and a finish time with the effective window as the difference between start and finish. For this reason the finish time value must be higher than the start value. All times are set in 24 hour clock format.

P791E 1-8E TZ1 days of the week - Where 1-7 represent the days of the week which the time zone will operate where 1 = Sunday, 2 = Monday etc. A value of 8 at this address will invert the TZ function so that instead of being effective during the window created by the start and finish times, the TZ is effective during the times outside the window set by the start and finish times.
P792E 0000 - 2359E TZ1 Start time - This is the time when the TZ will start. Use 24 hour format. (HHMM)
P793E 0000 - 2359E TZ1 Finish time - This is the time of day when the TZ will finish. The finish time must be greater than the start time. Use 24 hour format. (HHMM)

There are 8 time zones available and they occupy addresses P791E to P814E. Each time zone requires 3 addresses to be assigned.

P791E TZ1 Day of the week	P803E TZ5 Day of the week
P792E TZ1 Start Time	P804E TZ5 Start Time
P793E TZ1 Finish Time	P805E TZ5 Finish Time
P794E TZ2 Day of the week	P806E TZ6 Day of the week
P795E TZ2 Start Time	P807E TZ6 Start Time
P796E TZ2 Finish Time	P808E TZ6 Finish Time
P797E TZ3 Day of the week	P809E TZ7 Day of the week
P798E TZ3 Start Time	P810E TZ7 Start Time
P799E TZ3 Finish Time	P811E TZ7 Finish Time
P800E TZ4 Day of the week	P812E TZ8 Day of the week
P801E TZ4 Start Time	P813E TZ8 Start Time
P802E TZ4 Finish Time	P814E TZ8 Finish Time

MISCELLANEOUS SETUP AND DIAGNOSTIC DATA

TEMPORARY OUTPUT DISABLE - P837E

P837E **Temporary Output Disable** - This address allows a technician to select any output/s to be temporarily disabled for one alarm or armed cycle, e.g. by turning on LEDS 1-8 at P837E then leaving program mode, outputs 1-8 will not turn on following any alarms. The technician is now free to arm the system to test all monitoring signals without having all of the internal & external alarms activating. When the alarm is reset or disarmed all outputs will now work normally again.

CLEAR OUTPUT DEFAULTS - P846E

P846E 1-8E **Clear Output Defaults 1-8** - This option is used to remove ALL default options assigned to any output. This is a particularly useful tool when reassigning outputs to special functions such as smoke detector reset, where you need to remove the standard defaults from an output. In addition to removing all default programming this option will also make the reset time for the selected output/s "0".

DATA TRANSFER USING EE² BOARD (DTU)

P838E **Write to EE² Board** - with the optional back-up EE² board plugged into the serial connector on the panel and the write enable link fitted on the EE² board, entering P838E will write a copy of the panel program files to the EE² board.

P839E **Read from EE² Board** - this address allows a copy of a panel program files to be downloaded into a panel (the program files must first have been copied to the EE² board - refer P838E). Note: When transferring data from this board to a panel, the software versions of the two panels (the one where the data files were created and the panel receiving the files) must be the same otherwise the panel may not work correctly.

DYNAMIC DATA - P830E - P833E & P849E

These addresses are used to provide real time feedback from the panel as to the current status. These are intended as view only addresses and only available in installer program mode.

P830E **Misc System Flags** - This address currently has only one option that shows the status of Daylight Saving. If LED 8 is On then Daylight Saving is currently active.
8 = Daylight Saving active

P831E **Display keyboard address** - This option will cause the keypad you are operating to display it's currently assigned address from 1-8. This feature is only available in installer program mode.

P832E **Display partitions assigned to this keypad** - This option will cause the keypad you are operating to display it's currently assigned Areas. This feature is only available in installer program mode.

P833E **Display software version** - This address will cause the panel software version to be flashed back at the keypad.

P849E **Active Time-Zones** - If Time Zones are being used, by entering in this address while in Installation Program Mode the panel will display any of the 8 time zones currently active. If LED's 1-8 are On they indicate active time zones.

START PRINTING THE EVENT BUFFER - P834E

P834E **Start Event Printing** - The alarm system stores the last 255 events in a printer buffer. These events include time, date and an event description. To print the events, assuming the Serial Board is plugged into the panel (with the link set to printer on the serial board) and connected to a printer with an RS232 input, a user with permission to print (e.g. P101-P150 option 4) enters client program mode (P-code-E, program LED on solid), then enters P834E, the entire contents of the event buffer will be sent to the printer.

START WALK TEST MODE - P836E

P836E Walk-test mode - When in Installation or Client Program mode, entering P836E will turn On walk-test mode. The keypad buzzer will beep at one second intervals to show that walk-test mode is active. When in walk test mode the zone LED's will latch on at the keypad display when the zone has been activated. The Installer or User can then walk past all of the detectors and return to the keypad to verify that they are functioning correctly at the panel. The walk-test results are also stored in memory so they can be viewed at a later time if required. Pressing any button will terminate walk-test mode.

RESET TO DEFAULTS

RESET TO DEFAULTS - P840E - P848E

These addresses are used to reset sections of the programming back to defaults. Defaults are the factory settings. Most of the addresses below default only one part of the programming. To reset the entire configuration, including the event memory buffer you must use P845E.

P840E Reset user codes
P841E Reset dialler parameters
P842E Reset Radio parameters
P843E Reset PA & Voice board settings
P844E Reset the balance of the panel settings not included above
P845E Reset all panel parameters to default and clear the event memory buffer

P847E Clear event memory
P848E Reset PA board to clear all existing alarm messages

COMMAND CONTROL OPTIONS

Another powerful feature available from your Elite V6 is Command Control. This feature is a remote control facility which allows valid users to access the panel via a standard touch tone telephone and check or change the Arm/Disarm status of each of the areas, operate each of the eight outputs or turn on an optional Microphone.

The Command Control feature is only available on panels fitted with a Voice or DTMF board (see page 15). The Voice board provides voice prompts to guide you through Command control operations whereas the DTMF board provides tones (one Long Tone for ON or three short beeps for OFF).

Before Command Control features can be used the 4 digit DTMF control codes must be programmed. The DTMF codes can be 1-4 digits in length. There is a code for each partition, another to control all of the 8 outputs and one more to turn on or off the optional Microphone input. When programming the command control messages, ensure that the messages are a minimum of 2 seconds long. The addresses for these codes are;

P371E code E 4 Digit Code for Output Command Control - This is the code used to access the Output Command menu. A number from 1-8 is entered after this code to select the output you wish to control (for this feature to work, option 5 at addresses P201E to P208E must be turned on).

P372E code E 4 Digit Code for Area "A" Command Control - This is the code used to Arm or Disarm Area "A" via the telephone.

P373E code E 4 Digit Code for Area "B" Command Control - This is the code used to Arm or Disarm Area "B" via the telephone.

P374E code E 4 Digit Code for Area "C" Command Control - This is the code used to Arm or Disarm Area "C" via the telephone.

P375E code E 4 Digit Code to Turn ON Microphone - This is the code used to turn the microphone input on so that the user can listen to any foreign sounds at the secured premises.

RECORDING STATUS MESSAGES

The Command Control messages are recorded into the voice board using the plug-in speech programmer in the same way as alarm reporting messages are stored (refer to page 15). In general, to save confusion, it is advisable to record all of the alarm reporting messages first then record the Command Control messages. When recording

the command control messages the **ON** message **MUST** always be recorded **FIRST** followed immediately by the **OFF** message e.g. For the Area “A” command control messages the Area A Armed message must be recorded first followed by the Area A Disarmed message. The same rule applies to the outputs in that the output ON message must be recorded first followed by the Outputs’ OFF message. This is because the panel is told where to find the On message Number for a specific Command Control function and it then is assumed that the OFF message is the next message.

START OF VOICE STATUS MESSAGES FOR ARM/DISARM

If the ON message number is left blank i.e. “0”, the panel will assume that there is no voice message for this Command Control function and revert to the DTMF board tones e.g. One long tone for ON and three short beeps for OFF.

P777E # E Area “A” ON message number - This is the message number where the Area “A” armed message starts. The Area “A” disarmed message must be the next message.

P778E # E Area “B” ON message number - This is the message number where the Area “B” armed message starts. The Area “A” disarmed message must be the next message.

P779E # E Area “C” ON message number - This is the message number where the Area “C” armed message starts. The Area “A” disarmed message must be the next message.

START OF VOICE STATUS MESSAGES FOR OUTPUTS

If the ON message number is left blank i.e. “0”, the panel will assume that there is no voice message for this Command Control function and revert to the DTMF board tones e.g. One long tone for ON and three short beeps for OFF.

P781E # E Output #1 ON message number - This is the message number where the Output #1 ON message starts. The Output #1 OFF message must be the next message.

P782E # E Output #2 ON message number - This is the message number where the Output #2 ON message starts. The Output #2 OFF message must be the next message.

P783E # E Output #3 ON message number - This is the message number where the Output #3 ON message starts. The Output #3 OFF message must be the next message.

P784E # E Output #4 ON message number - This is the message number where the Output #4 ON message starts. The Output #4 OFF message must be the next message.

P785E # E Output #5 ON message number - This is the message number where the Output #5 ON message starts. The Output #5 OFF message must be the next message.

P786E # E Output #6 ON message number - This is the message number where the Output #6 ON message starts. The Output #6 OFF message must be the next message.

P787E # E Output #7 ON message number - This is the message number where the Output #7 ON message starts. The Output #7 OFF message must be the next message.

P788E # E Output #8 ON message number - This is the message number where the Output #8 ON message starts. The Output #8 OFF message must be the next message.

EXAMPLE OF HOW THE COMMAND CONTROL MESSAGE ADDRESSING WORKS.

We have assumed that there are 3 voice alarm reporting messages programmed for warning of alarm conditions via the telephone. These messages could be;

Message #1 *“Burglar alarm at Acme Building Products”*

Message #2 *“Fire alarm at Acme Building Products”*

Message #3 *“Panic alarm at Acme Building Products”*.

Next, we require arm/disarm capability for Areas A & B plus we need to be able to turn Outputs 5 & 8 On and Off remotely. The messages could be set-up as follows;

Message #4 "Area A alarm is Armed"
 Message #5 "Area A alarm is Disarmed"
 Message #6 "Area B alarm is Armed"
 Message #7 "Area B alarm is Disarmed"
 Message #8 "External lights are On" (external lights are connected to Output 5)
 Message #9 "External lights are Off" (external lights are connected to Output 5)
 Message #10 "After hours delivery gate is unlocked" (electric gate lock is connected to Output 8)
 Message #11 "After hours delivery gate is locked" (electric gate lock is connected to Output 8)
 (Please Note that the ON message is always programmed first)

Now, to access the correct message for the desired Command Control function we have to program the start message numbers for each function.

The programming to match the above example would be done as follows;

P777E	4E	Message # 4. (Area A ON status message)
P778E	6E	Message # 6. (Area B ON status message)
P785E	8E	Message # 8. (Output # 5 ON status message)
P788E	10E	Message # 10. (Output # 8 ON status message)

COMMAND CONTROL OPERATION

Elite Command Control provides a powerful, easy to use remote telephone control of your alarm system. User operation of the Elite Command Control has been designed to be as simple and user friendly as possible. Pre-recorded voice status messages guide you through the many control options, or the more simplified DTMF only board gives you long and short tones providing a status report of the section of the system which you are currently commanding. Because the voice status messages are recorded on-site they can be customised to suit each specific application. For example, rather than the status message saying "Output #1 off" you can record a message which describes exactly what is being controlled like "Factory heating off"

In the previous section you would have seen how you program access codes for each of the Command Areas and outputs. These are the codes you will enter over the phone to access the command menus. In order to start the Command Control feature you must first ring the phone number which the panel is connected to. The panel may be set up to answer after a specific number of rings or it may be set-up to use a fax defeat option. Either way, when you ring the phone number and finally get through to the Elite, the first thing you will hear over the phone is a burst of modem tone for two seconds. After this tone has stopped you must enter the access code which is associated with the Command menu option you wish to access. *Remember, the code you enter will determine which menu option you access.* If you miss the pause, the communicator will repeat the modem tone and then again pause for 5 seconds looking for your access code. This process will be repeated 4 times before hanging up if no valid code is received. When entering codes or other information in Command Control the "#" key acts as a "Clear" button.

When you have entered the required 4 digit access code the panel will reply with the status message associated with that menu option. For example, let's say we have a code of 2045 programmed at address P372E, (the code for Arming & Disarming Area A). Once the code "2045" has been received the panel checks the current status of Area A and replies with the pre-programmed voice message programmed at address P777E relating to that status e.g. if Area A is Armed then the Armed message will be sent, if Disarmed then the Disarmed message will be sent. If the data at address P777E is "0" then the panel will give a long beep if Area A is Armed, and three short beeps if it is disarmed.

Once the status message has informed you of the actual state, you can use the "*" key to toggle the option on & off or Arm and Disarm, e.g. in our example above, code 2045 accesses the Area "A" menu. Assuming the status message we received was "Area A alarm is Armed" If we press the "*" key, Area "A" will be Disarmed and we would receive a status message "Area A alarm is Disarmed".

While you are on-line with the panel you can move between menu options by entering the code of the option you want to control. Assuming there was a code of 4321 programmed at address P371E, to control outputs. After having used code 2045 to control the Arm/Disarm status of Area A we first press the "#" button to reset all previous entries then we can then enter the digits 43215 (that is 4321 for the output control and 5 to select output #5). The current status of output #5 will be given either by the voice message or the appropriate tone and then the status can be changed with the "*" button on the remote telephone (Note; For output control you must enter in the 4 digit code e.g. 4321 followed by the output number you wish to control, in this case 5).

At any stage, if you enter in an incorrect code you can press the "#" button on the remote telephone to clear all code entries and then start again.

To end a Command Control session simply hang up the phone. The panel is monitoring the line at all times and 15 seconds after the last key press it will automatically hang up the line. This 15 second timer is active during the whole command control process so a period of 15 seconds without a key press will cause the panel to hang-up.

LOCAL COMMAND CONTROL OF OUTPUTS

If a command control code for outputs is programmed (P371E) and the output/s are allowed to be locally controlled (P201-P208, option 6) then entering the 4 digit code at a keypad will blank the display and the zone LED's will now indicate the output status e.g. if output 1 is on zone 1 LED will be on. By now pressing the "1" button at the panel keypad, output 1 can be turned off provided it is allowed to be locally controlled. To leave local command control mode simply press the "Enter" button and the keypad will return to normal operation. If option 8 at addresses P301, P401 or P501 are on, you can access this Local Command Control mode directly by simply pressing the "Control" button at the keypad followed by the output number/s that are allowed to be controlled.

DIALLER PROGRAMMING

ENABLING DIALLER & SETTING DIALLING PARAMETERS - P370E

P370E 1-8E System Options (Default = 7)

1 = Enable dialler
2 = Fax defeat
3 = Disable line monitoring
4 = DTMF or Pulse Dial
5 = Normal or Reverse Pulse Dial
6 = Long DTMF Dialling Tones
7 = Auto-Detect Modem Format
8 = Force Bell103/V21

- Option 1** **Enable Dialler** - This option is used to activate the dialler hardware. If this option is Off, all dialler reporting activity will be disabled. - Default = Off
- Option 2** **Fax Defeat** - This option enables fax defeat mode. When enabled the panel will look for incoming rings between 1-4 rings (inclusive). If the incoming call is then terminated the panel will answer the next incoming call after one ring. If another call is not established within 45 sec of the first call, the fax defeat mode is reset. For fax defeat to work the auto answer rings must be enabled by putting in a suitable ring count (e.g. 25).
- Option 3** **Disable Line Monitoring** -If this option is enabled, then the panel no longer tests the telephone line.
- Option 4** **DTMF or Pulse Dial** - Selects DTMF or Pulse dialling. Led Off = DTMF Dial.
- Option 5** **Normal or Reverse Pulse Dial** - With this option off, the dialling pulses are normal i.e. a 1 = 1 pulse, a 9 = 9 pulses. If the option is on, then the pulses are reversed i.e. a 1 = 9 pulses, a 9 = 1 pulse.
- Option 6** **Long DTMF Dialling Tones** - If Option 7 is ON, the dialling tone duration/gap will be 100ms, if off, the duration/gap will be 75ms.
- Option 7** **Auto-Detect Modem Format** - The panel can connect using Bell103 or V21 formats when performing upload/download connections. If this option is On the panel generates the V21 tones first and if no connection is established it then generates the Bell103 tones. If this option is turned off then the format is fixed by the selection made at option 8.
- Option 8** **Force Bell103/V21 Modem Format** - If option 7 above is turned off then the modem format to be used for upload/download is specified here. If this option is Off the format is Bell103, On is V21.

REPORTING SCENARIOS - P321E - P324E

P321E 1-16E Reporting Scenario #1 options (Default=1 7)
P322E 1-16E Reporting Scenario #2 options (Default = 0)
P323E 1-16E Reporting Scenario #3 options (Default = 0)
P324E 1-16E Reporting Scenario #4 options (Default = 0)

In order to provide you with the best flexibility when reporting alarms we have developed a unique system called "Reporting Scenarios". The Scenarios define what action is taken by the panel for each alarm event, e.g. alternate between numbers 1&2 until one is kissed-off or dual report to numbers 1&2 until both kissed-off. There are four individual scenarios available each with up to 16 possible steps. The Scenarios consist of a string of digits that define the reporting action to be taken by the panel. The digits in a Scenario are pre-defined. What the various digits are and their meaning are listed below.

Scenario Options;

1 = Call Telephone Number 1
2 = Call Telephone Number 2
3 = Call Telephone Number 3
4 = Call Telephone Number 4
5 = Call Telephone Number 5

6 = Call Telephone Number 6
7 = Return to step 1 until all numbers are kissed-off
8 = Return to previous step if not kissed-off
9 = Stop if kissed-off, if not proceed to next step

Example 1 (alternate dialling) 1 9 2 9 7

In this example we have defined a scenario with five steps as follows.

Step 1 - Dial Ph # 1.

Step 2 - If not Kissed-off (defined by the 9) continue to next step

Step 3 - Dial Ph # 2

Step 4 - If not Kissed-off (defined by the 9) continue to next step

Step 5 - If not kissed-off return to Ph #1 (the 7 causes a return to the start)

This process is repeated until kissed-off or the maximum number of dialling attempts have been reached for this scenario.

Example 2 (dual reporting) 172 7

In this example we have defined a scenario with four steps as follows.

Step 1 - Dial Ph # 1.

Step 2 - If not Kissed-off return to Ph # 1 (the 7 causes a return to the start). When kissed-off or the maximum re-tries reached, move forward to the next step.

Step 3 - Dial Ph # 2

Step 4 - If not kissed-off return to Ph # 2 (the 7 causes a return to the start). When kissed-off or the maximum re-tries reached, move forward to the next step. If no further steps, stop.

The first step must be completed i.e. kissed-off or the maximum re-tries reached, before the panel can move past the first "7", then it can step forward and execute additional instructions up to the next 7. When the format is Contact ID or 4+2 the use of the two sevens in the scenario forces the panel to report the same signal to both numbers (Dual reporting).

MAXIMUM DIAL ATTEMPTS PER SCENARIO NUMBER

P325E Maximum dialling attempts for Scenario # 1-Value 1-99 (Default=10)

P326E Maximum dialling attempts for Scenario # 2-Value 1-99 (Default=10)

P327E Maximum dialling attempts for Scenario # 3-Value 1-99 (Default=10)

P328E Maximum dialling attempts for Scenario # 4-Value 1-99 (Default=10)

TELEPHONE NUMBER PREFIX

P330E 1-16E Telephone Number Prefix - 16 Characters Maximum (Pauses and special characters allowed)

This Prefix can be added to the beginning of any of the 6 telephone numbers by turning on option 6 at addresses P343E-P348E.

PROGRAM TELEPHONE NUMBERS - P331E - P336E

There are 16 characters available in each of the telephone numbers including five special characters. To program the special characters that include dialling pauses, the * and # characters, etc, refer to the table below.

Character	LED KP Button	Displayed as On 8LED KP	Displayed as On 16LED KP	Displayed as On Alert KP	LCD KP Button	Displayed as On LCD KP
# Character	PANIC	Line	11	Ready	"Control" "2"	#
* Character	MEMORY	Memory	12	System	"Control" "3"	*
2.5 sec pause	CONTROL	Control	13	Trouble	"Control" "4"	-
Wait for 2nd	ARM	Armed	14	Ready/System	"Control" "5"	W
5 sec pause	STAY	Bypass	15	Ready/Trouble	"Control" "6"	=

P331E 1-16E Telephone Number 1 - where options 1-16 represent up to 16 digits

P332E 1-16E Telephone Number 2 - where options 1-16 represent up to 16 digits

P333E 1-16E Telephone Number 3 - where options 1-16 represent up to 16 digits

P334E 1-16E Telephone Number 4 - where options 1-16 represent up to 16 digits

P335E 1-16E Telephone Number 5 - where options 1-16 represent up to 16 digits

P336E 1-16E Telephone Number 6 - where options 1-16 represent up to 16 digits

DEFINE REPORTING FORMATS FOR EACH TELEPHONE NUMBER - P337E - P342E

These addresses define which format the panel will use when dialling each of the six phone numbers.

P337E Reporting Format for Ph # 1 (Default= 1)

1 = Contact ID	8 = 4+2 10pps (Handshake 2300/ Tone 1900)
2 = Domestic Dial	9 = 4+2 20pps (Handshake 1400/ Tone 1800)
3 = Pager	10= 4+2 20pps (Handshake 1400/ Tone 1900)
4 = Speech Dialler	11= 4+2 20pps (Handshake 2300/ Tone 1800)
5 = 4+2 10pps (Handshake 1400/ Tone 1800)	12= 4+2 20pps (Handshake 2300/ Tone 1900)
6 = 4+2 10pps (Handshake 1400/ Tone 1900)	13= 4+2 DTMF
7 = 4+2 10pps (Handshake 2300/ Tone 1800)	

- Option 1** **Contact ID** - Use Contact ID format to report alarm and system events to a monitoring companies receiving equipment.
- Option 2** **Domestic Alarm Tone** - Use "Domestic" format to report alarm events. This format uses alternating tones to report alarms and can be kissed-off by pressing any digit in the right hand two columns on a touch tone phone. This alternating alarm tone continues for 5 seconds followed by a 5 second pause, at which time the panel is looking for a kiss-off. If a kiss-off is not received another round of alarm tones will be sent followed by another pause to check for kiss-off. This routine is repeated 4 times, at which point if a kiss-off has not been received, the panel will hang up and dial the next phone number. Domestic dial will only report Zone activations, Manual Fire & Medical alarms, Panic alarms, Mains failure and Battery low alarms.
- Option 3** **Pager** - Report alarm events using the Elite "Pager" format. This format sends a 12 digit numeric code to a pager . This format is restricted to reporting only the same alarm events as the Domestic Dial format above. The event report is in the form of a 12 digit message which consists of a unique 4 digit account code (NOTE: The client account number should not start with a "0"), a space character, a 3 digit event code another space character then a 3 digit identifier extension. The spaces between the account code, event code and extension make up the 12 bits of the message. There is no kiss-off required in Pager Format reporting. The account and event codes are the Contact ID codes programmed into the system.
As an example, a pager which displays this message;
1 2 3 4 1 3 0 0 0 1
Would have received an alarm message from alarm 1234 (Area A account code), that there is a burglar activation 130 (contact ID burglar alarm report code), on zone 001 (zone one extension number)
- Option 4** **Speech Dialler** - Report alarm events by using the optional add-on Voice Board. This format is similar to the Domestic Dial format in that it reports alarm events via private phone numbers and is kissed-off by pressing a button on the telephone but there is one important difference. This format will report the alarm events using pre-recorded voice messages. These messages are recorded directly into the speech module which is a "plug on" option to your Elite V6 control panel. When an alarm event is reported using the Speech Dial format the messages assigned at addresses P757E to P776E, P789E & P790E are played when the alarm occurs and like the Domestic Dial format a 5 second pause follows in which the panel is looking to be kissed-off. If not kissed-off the dialler will repeat the messages and pause again. This routine is repeated 4 times at which point, if a kiss-off has not been received the panel will hang up and dial the next phone number. To kiss-off the panel during the pause period all you do is press any of the buttons on your touch tone telephone. If a kiss-off is not received from any of the phone numbers dialled, the panel will make the maximum number of calls allowed for the scenario and shut down awaiting a new alarm trigger.
- Option 5-12** **4+2 Pulsed** - This option sends a 4+2 signal to a monitoring station. The various options allow for 10 or 20 pulses per second and either a 1800 Hz or 1900 Hz transmit tone. There is also a selection for the initial Handshake tone from the monitoring receiver to be 1400 Hz or 2300 Hz. Please refer to the options listed above. This format consists of sending a 4 digit account code followed by a 2 digit event code. There are many forms of 4+2 in use and the correct choice must be made in consultation with the individual monitoring stations.
- Option 13** **4+2 DTMF** - This option sends a 4+2 DTMF (Dual Tone Multi-Frequency) signal to a monitoring station. The alarm transmission consists of a 4 digit account code, a 2 digit event code and a checksum.

The panel will automatically cease reporting in Domestic, Pager or Speech Modes if reset with a valid code.

Contact ID or 4+2 modes Must be kissed off by a monitoring station receiver.

Note: P338E through P342E are as above but applied to telephone numbers 2-6 (Default=0)

DEFINE OPTIONS FOR EACH TELEPHONE NUMBER - P343E - P348E

This group of addresses is used to define various options for each of the six phone numbers.

P343E Options for Ph # 1 (Default= 1,5)

- | | |
|---|--|
| 1 = Monitor Call Progress | 5 = Send Automatic Test calls |
| 2 = Blind Dial | 6 = Add Prefix to this Telephone Number |
| 3 = Use Group Numbers for Contact ID | 7 = Auto Kiss-off in Domestic Mode |
| 4 = Send Restores | 8 = Spare |

- Option 1 Monitor Call Progress** - Monitor call progress means that the dialler monitors the status of the dialling tone to determine whether the call is valid or not. If the call is not valid, i.e. Engaged, the panel will know and hang up the call and try again.
- Option 2 Blind Dial** - When the dialler makes a call it looks for dial tone before making the call. If no dial tone is detected the panel hangs up and attempts another call. The panel will do this 3 times and if dial tone is still not detected it will make the call anyway. If blind dial is on, the panel skips the dial tone detection and dials 4 seconds after looping the line. (used where non standard or low level dial tone exists)
- Option 3 Use Separate Accounts or Group Number** - When sending an alarm using Contact ID, the panel can either send separate account codes to report the three separate areas or, use one account code (Partition A) and use the group number to identify the two partitions.
- Option 4 Send Restores** - When an alarm is generated the panel automatically sends a restore when the alarm is reset. If the monitoring company does not want restores they may be turned off with this option.
- Option 5 Send Test call to Monitoring Station** - The automatic daily test call to a monitoring station can be disabled if not required by turning off this option.
- Option 6 Add Pre-fix to this Telephone Number** - The dialling Prefix at address P330E can add preset dialling parameters to all or any of the telephone numbers. This is useful if special characters are required to bypass Toll Bars or other similar restrictions that must be dialled before the telephone number. This also allows a number to be longer than the 16 characters as the Prefix is also 16 characters long.
- Option 7 Auto Kiss-off in Domestic Mode** - If this option is turned ON, the panel will not look for a kiss-off when reporting domestic mode alarms and will run to the maximum re-tries for the scenario then stop. NOTE: the event must be reported for auto-kiss-off to work, so "call progress" should be turned off if it is anticipated that a call could be engaged or unanswered, otherwise it will not get reported and then will not be kissed off automatically. If a DTMF board is fitted and this option is turned OFF, the panel can only be kissed off with a DTMF tone.

Note: P345E through P348E are as above but applied to telephone numbers 2-6 (Default=0)

ZONE ACTIVATION SCENARIO MAPPING - P351E - P366E

These addresses are used to map activations from each of the 16 possible alarm zones to one of the 4 possible reporting scenarios. If a value of zero (0) is assigned at an address in this block, alarms from that zone will not be reported by the panel.

- | | | |
|--------------|-------------|---|
| P351E | 1-4E | Zone 1 Activations mapped to Scenario 1-4 - Default 1 |
| P352E | 1-4E | Zone 2 Activations mapped to Scenario 1-4 - Default 1 |
| P353E | 1-4E | Zone 3 Activations mapped to Scenario 1-4 - Default 1 |
| P354E | 1-4E | Zone 4 Activations mapped to Scenario 1-4 - Default 1 |
| P355E | 1-4E | Zone 5 Activations mapped to Scenario 1-4 - Default 1 |
| P356E | 1-4E | Zone 6 Activations mapped to Scenario 1-4 - Default 1 |
| P357E | 1-4E | Zone 7 Activations mapped to Scenario 1-4 - Default 1 |
| P358E | 1-4E | Zone 8 Activations mapped to Scenario 1-4 - Default 1 |
| P359E | 1-4E | Zone 9 Activations mapped to Scenario 1-4 - Default 1 |
| P360E | 1-4E | Zone 10 Activations mapped to Scenario 1-4 - Default 1 |
| P361E | 1-4E | Zone 11 Activations mapped to Scenario 1-4 - Default 1 |
| P362E | 1-4E | Zone 12 Activations mapped to Scenario 1-4 - Default 1 |
| P363E | 1-4E | Zone 13 Activations mapped to Scenario 1-4 - Default 1 |
| P364E | 1-4E | Zone 14 Activations mapped to Scenario 1-4 - Default 1 |
| P365E | 1-4E | Zone 15 Activations mapped to Scenario 1-4 - Default 1 |
| P366E | 1-4E | Zone 16 Activations mapped to Scenario 1-4 - Default 1 |

ZONE BYPASS SCENARIO MAPPING - P581E - P596E

These addresses are used to map zone bypasses (isolations) from each of the 16 possible alarm zones to one of the 4 possible reporting scenarios. If a value of zero (0) is assigned at an address in this block, bypasses from that zone will not be reported by the panel.

P581E	1-4E	Zone 1 Bypass mapped to Scenario 1-4 - Default 1
P582E	1-4E	Zone 2 Bypass mapped to Scenario 1-4 - Default 1
P583E	1-4E	Zone 3 Bypass mapped to Scenario 1-4 - Default 1
P584E	1-4E	Zone 4 Bypass mapped to Scenario 1-4 - Default 1
P585E	1-4E	Zone 5 Bypass mapped to Scenario 1-4 - Default 1
P586E	1-4E	Zone 6 Bypass mapped to Scenario 1-4 - Default 1
P587E	1-4E	Zone 7 Bypass mapped to Scenario 1-4 - Default 1
P588E	1-4E	Zone 8 Bypass mapped to Scenario 1-4 - Default 1
P589E	1-4E	Zone 9 Bypass mapped to Scenario 1-4 - Default 1
P590E	1-4E	Zone 10 Bypass mapped to Scenario 1-4 - Default 1
P591E	1-4E	Zone 11 Bypass mapped to Scenario 1-4 - Default 1
P592E	1-4E	Zone 12 Bypass mapped to Scenario 1-4 - Default 1
P593E	1-4E	Zone 13 Bypass mapped to Scenario 1-4 - Default 1
P594E	1-4E	Zone 14 Bypass mapped to Scenario 1-4 - Default 1
P595E	1-4E	Zone 15 Bypass mapped to Scenario 1-4 - Default 1
P596E	1-4E	Zone 16 Bypass mapped to Scenario 1-4 - Default 1

LOW ZONE TAMPERS SCENARIO MAPPING - P601E - P608E

This group of addresses is used to map the eight possible low zone tampers to one of the four possible reporting scenarios. If a value of zero (0) is assigned at an address in this block, low tampers from that zone will not be reported by the panel. Low Zone Tamper is a short circuit input.

P601E	1-4E	Short Circuit Tamper Alarm on Input 1 mapped to Scenario 1-4 - Default 1
P602E	1-4E	Short Circuit Tamper Alarm on Input 2 mapped to Scenario 1-4 - Default 1
P603E	1-4E	Short Circuit Tamper Alarm on Input 3 mapped to Scenario 1-4 - Default 1
P604E	1-4E	Short Circuit Tamper Alarm on Input 4 mapped to Scenario 1-4 - Default 1
P605E	1-4E	Short Circuit Tamper Alarm on Input 5 mapped to Scenario 1-4 - Default 1
P606E	1-4E	Short Circuit Tamper Alarm on Input 6 mapped to Scenario 1-4 - Default 1
P607E	1-4E	Short Circuit Tamper Alarm on Input 7 mapped to Scenario 1-4 - Default 1
P608E	1-4E	Short Circuit Tamper Alarm on Input 8 mapped to Scenario 1-4 - Default 1

HIGH ZONE TAMPERS SCENARIO MAPPING - P609E - P616E

This group of addresses is used to map the eight possible High zone tampers to one of the four possible reporting scenarios. If a value of zero (0) is assigned at an address in this block, high tampers from that zone will not be reported by the panel. High Zone Tamper is an open circuit input.

P609E	1-4E	Open Circuit Tamper Alarm on Input 1 mapped to Scenario 1-4 - Default 1
P610E	1-4E	Open Circuit Tamper Alarm on Input 2 mapped to Scenario 1-4 - Default 1
P611E	1-4E	Open Circuit Tamper Alarm on Input 3 mapped to Scenario 1-4 - Default 1
P612E	1-4E	Open Circuit Tamper Alarm on Input 4 mapped to Scenario 1-4 - Default 1
P613E	1-4E	Open Circuit Tamper Alarm on Input 5 mapped to Scenario 1-4 - Default 1
P614E	1-4E	Open Circuit Tamper Alarm on Input 6 mapped to Scenario 1-4 - Default 1
P615E	1-4E	Open Circuit Tamper Alarm on Input 7 mapped to Scenario 1-4 - Default 1
P616E	1-4E	Open Circuit Tamper Alarm on Input 8 mapped to Scenario 1-4 - Default 1

SYSTEM EVENTS SCENARIO MAPPING - P421E - P438E

This group of addresses is used to map System Events as listed below to one of the four possible reporting scenarios. If a value of zero (0) is assigned at an address in this block, that event will not be reported by the panel.

P421E	Area A Arm/Disarm reports mapped to scenario 1-4	default 1
P422E	Area B Arm/Disarm reports mapped to scenario 1-4	default 1
P423E	Area C Arm/Disarm reports mapped to scenario 1-4	default 1
P424E	Keypad Panic (& buttons 1 & 3) mapped to scenario 1-4	default 1
P425E	Keypad Fire (buttons 4 & 6) mapped to scenario 1-4	default 1
P426E	Keypad Medical (buttons 7 & 9) mapped to scenario 1-4	default 1
P427E	Battery low mapped to scenario 1-4	default 1

P428E Mains fail mapped to scenario 1-4 default 1
 P429E Phone line restore mapped to scenario 1-4 default 1
 P430E Radio PIR battery low mapped to scenario 1-4 default 1
 P431E Radio-key battery low mapped to scenario 1-4 default 1
 P432E Keypad tamper mapped to scenario 1-4 default 1
 P433E Cabinet tamper mapped to scenario 1-4 default 1
 P434E Radio panic mapped to scenario 1-4 default 1
 P435E Test calls mapped to scenario 1-4 default 1
 P436E Duress alarm mapped to scenario 1-4 default 1
 P437E Supervised radio timeout mapped to scenario 1-4 default 1
 P438E Zone inactivity timeout mapped to scenario 1-4 default 1

MULTIPLE ZONE REPORTING - P446E & P466E

P458E 1-8E Zone will report multiple activations for zones 1-8 (Default ON)
 P478E 1-8E Zone will report multiple activations for zones 9-16 (Default ON)

PROGRAMMING TEST CALL OPTIONS - P815E - P816E

Because the Elite V6 runs a real time clock, it is possible to assign test calls by day of the week and time of day rather than the more common practice of spacing test calls so many hours apart,.

P815E 0-7E Test Call Days of the Week - Where 1 = Sunday and 7 = Saturday. 0 = No Test

P816E XXXXE Test Call Time of Day - Where the time of the day you wish the panel to make its daily test call is programmed in 24 hour format.

CONTACT ID CODE & SPEECH MESSAGE PROGRAMMING

CONTACT ID AREA ACCOUNT CODES - P376E - P378E

P376E XXXXE Account Code for Area "A" Reports - The Account code set at this address will be used to report all system events Arms and Disarms, zone activations, restores and bypasses etc from Area "A" - Default Account = 0000

P377E XXXXE Account Code for Area "B" Reports - The account code set at this address will be used to report Arms and Disarms, zone activations, restores and bypasses etc from Area "B"

P378E XXXXE Account Code for Area "C" Reports - The account code set at this address will be used to report Arms and Disarms, zone activations, restores and bypasses etc from Area "C"

ZONE CONTACT ID ALARM REPORTING CODE - P721E-P736E

P721E	XXE	Zone 1 Activation	Default = 130	0 = No Report
P722E	XXE	Zone 2 Activation	Default = 130	
P723E	XXE	Zone 3 Activation	Default = 130	
P724E	XXE	Zone 4 Activation	Default = 130	
P725E	XXE	Zone 5 Activation	Default = 130	
P726E	XXE	Zone 6 Activation	Default = 130	
P727E	XXE	Zone 7 Activation	Default = 130	
P728E	XXE	Zone 8 Activation	Default = 130	
P729E	XXE	Zone 9 Activation	Default = 130	
P730E	XXE	Zone 10 Activation	Default = 130	
P731E	XXE	Zone 11 Activation	Default = 130	
P732E	XXE	Zone 12 Activation	Default = 130	
P733E	XXE	Zone 13 Activation	Default = 130	
P734E	XXE	Zone 14 Activation	Default = 130	
P735E	XXE	Zone 15 Activation	Default = 130	
P736E	XXE	Zone 16 Activation	Default = 130	

MANUAL ALARM CONTACT ID REPORTING CODES - P737E-P739E

P737E	XXxE	“Panic” or “1&3” Keypad Alarm	Default = 120
P738E	XXxE	“Fire” (4&6) Keypad Alarm	Default = 110
P739E	XXxE	“Medical” (7&9) Keypad Alarm	Default = 100

ZONE TAMPER ALARM CONTACT ID REPORTING CODES - P741E-P756E

P741E	XXxE	Input 1 Short Circuit Tamper	Default = 137	0 = No Report
P742E	XXxE	Input 2 Short Circuit Tamper	Default = 137	
P743E	XXxE	Input 3 Short Circuit Tamper	Default = 137	
P744E	XXxE	Input 4 Short Circuit Tamper	Default = 137	
P745E	XXxE	Input 5 Short Circuit Tamper	Default = 137	
P746E	XXxE	Input 6 Short Circuit Tamper	Default = 137	
P747E	XXxE	Input 7 Short Circuit Tamper	Default = 137	
P748E	XXxE	Input 8 Short Circuit Tamper	Default = 137	

P749E	XXxE	Input 1 Open Circuit Tamper	Default = 137	0 = No Report
P750E	XXxE	Input 2 Open Circuit Tamper	Default = 137	
P751E	XXxE	Input 3 Open Circuit Tamper	Default = 137	
P752E	XXxE	Input 4 Open Circuit Tamper	Default = 137	
P753E	XXxE	Input 5 Open Circuit Tamper	Default = 137	
P754E	XXxE	Input 6 Open Circuit Tamper	Default = 137	
P755E	XXxE	Input 7 Open Circuit Tamper	Default = 137	
P756E	XXxE	Input 8 Open Circuit Tamper	Default = 137	

ALARM VOICE MESSAGE MAPPING - P757E - P776E, P789E, P790E

These addresses are used to assign the voice messages to the manually generated Panic, Fire, Medical, battery low and mains failure messages plus the 16 zone activation's. The voice messages will be replayed over the phone in response to an alarm activation to those phone numbers which have been assigned Speech Dial format at options P337E to P342E.

P757E	0-99E	Voice Message Mapped to Keypad “Panic” Alarm - Default 0
P758E	0-99E	Voice Message Mapped to Keypad “Fire” Alarm - Default 0
P759E	0-99E	Voice Message Mapped to Keypad “Medical” Alarm - Default 0

P761E	0-99E	Voice Message Mapped to Zone 1 Activation's - Default 1
P762E	0-99E	Voice Message Mapped to Zone 2 Activation's - Default 1
P763E	0-99E	Voice Message Mapped to Zone 3 Activation's - Default 1
P764E	0-99E	Voice Message Mapped to Zone 4 Activation's - Default 1
P765E	0-99E	Voice Message Mapped to Zone 5 Activation's - Default 1
P766E	0-99E	Voice Message Mapped to Zone 6 Activation's - Default 1
P767E	0-99E	Voice Message Mapped to Zone 7 Activation's - Default 1
P768E	0-99E	Voice Message Mapped to Zone 8 Activation's - Default 1
P769E	0-99E	Voice Message Mapped to Zone 9 Activation's - Default 1
P770E	0-99E	Voice Message Mapped to Zone 10 Activation's - Default 1
P771E	0-99E	Voice Message Mapped to Zone 11 Activation's - Default 1
P772E	0-99E	Voice Message Mapped to Zone 12 Activation's - Default 1
P773E	0-99E	Voice Message Mapped to Zone 13 Activation's - Default 1
P774E	0-99E	Voice Message Mapped to Zone 14 Activation's - Default 1
P775E	0-99E	Voice Message Mapped to Zone 15 Activation's - Default 1
P776E	0-99E	Voice Message Mapped to Zone 16 Activation's - Default 1

P789E	0-99E	Voice Message Mapped to Mains Failure Alarm - Default 0
-------	-------	---

P790E	0-99E	Voice Message Mapped to Battery Low Alarm - Default 0
-------	-------	---

MISCELLANEOUS DIALLER OPTIONS

AREA ARM/DISARM REPORTING OPTIONS - P289E

P289E	1-8E	Area A Reporting Options - Default 1,2
-------	------	--

- 1 = Send Arm/Disarm
- 2 = Send Stay Mode Arm/Disarm
- 3 = Send Disarm only after activations
- 4 = Send Stay Disarm only after activations
- 5 = Send Arm at the end of the exit delay
- 6 = Send all zone restores when disarmed
- 7 = Spare
- 8 = Spare

Option 1	Send Arm / Disarm - If this option is on, the dialler will report Area "A" arms and disarms.
Option 2	Send Stay Mode Arm / Disarm - If this option is on, the dialler will report Area "A" stay mode arms and disarms.
Option 3	Send Disarm only after activation - If this option is on, the dialler will report an Area A disarm following an alarm activation only. This option is often used in conjunction with alarm only reporting and stops the normal arm/disarm signals from being sent. If this option is on it will override the option 1 setting.
Option 4	Send Stay Mode Disarm only after activation - If this option is on, the dialler will report an Area A Stay Mode disarm following an alarm activation only. This option is often used in conjunction with alarm only reporting and stops the normal Stay Mode arm/disarm signals from being sent. If this option is on it will override the option 2 setting.
Option 5	Send Arm at the end of the exit delay - If the LED is Off, the dialler will report an Arm immediately the panel is armed. If the LED is On, the Arm report is sent at the expiry of the exit delay.
Option 6	Send all zone restores when disarmed - If this option is Off, the dialler will send all zone restores as they occur. If the option is On, the dialler will send all zone restores only when the panel is disarmed. If the option is On, only one restore will be sent for each zone that activates regardless of whether the zones can send multiple alarm reports.
Option 7	Spare
Option 8	Spare
P389E 1-8E	Area "B" Reporting Options - (see above for details) Default 1,2
P489E 1-8E	Area "C" Reporting Options - (see above for details) Default 1,2

ENABLING VARIOUS DIALLER REPORTING OPTIONS A

P314E 1-8E	Various Reporting Options A (Default = all) On = Send, Off = Don't Send
	1 = Report Duress via Dialler
	2 = Report Mains or 12V fuse (F1 & F2 on control board) Failure via Dialler
	3 = Report System Battery Low via Dialler
	4 = Report Radio Battery Low via Dialler
	5 = Report System Tamper via Dialler
	6 = Report Telephone Line Failure via Dialler
	7 = Report Supervised Radio alarm via Dialler
	8 = Report Zone Inactivity Timeout via Dialler

ENABLING VARIOUS DIALLER REPORTING OPTIONS B

P315E 1-8E	Various Reporting Options B (Default = 1,2,3) On = Send, Off = Don't Send
	1 = Report Panic Alarms via Dialler
	2 = Report Fire Alarms via Dialler
	3 = Report Medical Alarms via Dialler
	4 = Report 24 Hour alarms for Voice/Domestic/Pager Mode

KEYPAD LISTEN-IN OPTIONS

P312E Keypad Listen-in Options (Default = 1,7)

- 1 = Enabled During Dialling in Disarm State only
- 2 = Enabled During Dialling in Armed State only
- 3 = Enabled During Dialling in Monitor Mode State only
- 4 = Enabled Throughout the call in Disarm State only
- 5 = Enabled Throughout the call in Armed State only
- 6 = Enabled Throughout the call in Monitor Mode State only
- 7 = Listen-in Enabled when the panel answers a call
- 8 = Enabled at All Times

OUTPUT #1 LISTEN-IN OPTIONS

P313E Output # 1 Listen-in Options (Default = None)

- 1 = Enabled During Dialling in Disarm State only
- 2 = Enabled During Dialling in Armed State only
- 3 = Enabled During Dialling in Monitor Mode State only
- 4 = Enabled Throughout the call in Disarm State only
- 5 = Enabled Throughout the call in Armed State only
- 6 = Enabled Throughout the call in Monitor Mode State only
- 7 = Listen-in Enabled when the panel answers a call
- 8 = Enabled at All Times

AUTO-ANSWER RING COUNT

P369E 1-99E Auto-Answer Rings - This option defines the number of rings before the panel will auto-answer the incoming call. (Default = 25)

MAINS FAIL REPORT DELAY

P559E 1-999E Mains Fail Report Delay - When there is a mains supply failure, the mains must fail for longer than the programmed delay at this address before the panel will report the alarm. A value from 1-999 seconds can be programmed as the delay. A value of 0 will result in an instant report of mains failure.
(Default = 600 seconds)

ZONE ALARM REPORT DELAY

P560E 0-999E Report Delay on Zones - This delay pauses the zone reporting of alarms via the panel for the programmed period (0 = No delay or 1-999 seconds). If the alarm is reset before this delay expires no alarms will be reported.

This delay pauses the reporting of zone alarms for all reporting formats. This delay can be used to prevent false alarms from reporting if the alarm is cancelled before this delay expires.

UPLOAD/DOWNLOAD SECURITY OPTIONS

P828E XXXXXXXX. Up to 8 digit security code for upload/download.

P835E **Answer incoming call** - provided a user with option 5 set (P101-P150) enters in P835E while in client program mode and the telephone line is currently ringing the panel will answer the incoming call and initiate an upload/download connection.

PROGRAMMING 4+2 EVENT CODES

PROGRAMMING 4+2 SPECIAL CHARACTERS

When programming 4+2 event codes (see pages 76-80) you can enter in digits 1234567890 plus the following special characters BCDEF. If you enter in a value of "00" or press the "Exclude" button after a 4+2 program address then the appropriate option will not report via the dialler e.g. P865E-00-E or P865E-exclude-E will disable the keypad panic alarm reporting function in 4+2 mode. The "Control" "0" keys are used to remove an entry when using the LCD keypad. The 4+2 event codes must be 2 digits but they can be in any order e.g.;

P865E-01-E, or P865E-C6-E, or P865E-4F-E, etc.

In the above examples, the letters are programmed using the special function keys listed in the table below. When displaying the address back at the keypad the associated keypad LED's are also listed against the special letters B-F. (NOTE: A value of "0" in 4+2 will be transmitted as 10 pulses to the monitoring station).

Character	LED KP Special Function Key	Displayed as On 8LED KP	Displayed as On 16LED KP	Displayed as On Alert KP	LCD KP Special Function Key	Displayed as On LCD KP
"B"	PANIC	Line	11	Ready	"Control" "2"	B
"C"	MEMORY	Memory	12	System	"Control" "3"	C
"D"	CONTROL	Control	13	Trouble	"Control" "4"	D
"E"	ARM	Armed	14	Ready/System	"Control" "5"	E
"F"	STAY	Bypass	15	Ready/Trouble	"Control" "6"	F

COMMON CONTACT ID CODES

Medical Alarm	100
Medical Pendant	101
Fire Alarm	110
Smoke Detector	111
Heat Detector	114
Manual Call Point	115
Duct Detector	116
Silent Panic	122
Audible Panic	123
Perimeter Zone	131
24 Hour Zone	133
Entry Exit Zone	134

Low Temperature	159
High Temperature	158
Refrigeration Alarm	152
Water Leakage	154
Gas Detector	151

ELITE PROGRAM SUMMARY GUIDE

The following program summary is an abbreviated version of all the Elite program addresses. This is intended as a quick guide to finding a program address. The program addresses are in numerical order with page references beside them so you can get more detailed information if required. **Because this section is in numerical order, any addresses relating to the Dialler are not necessarily grouped together. To identify Dialler options each heading relating to the Dialler are highlighted by an “**” either side of the heading.**

CLIENT MODE PROGRAMMING

Programming User Codes

P1E	User Code #1 (Master Code) if deleted code is reset to 987654 - Default 123	Page 17
P2E	User Code #2	Page 17
P3E	User Code #3	Page 17
P4E	User Code #4	Page 17
P5E	User Code #5	Page 17
P6E	User Code #6	Page 17
P7E	User Code #7	Page 17
P8E	User Code #8	Page 17
P9E	User Code #9	Page 17
P10E	User Code #10	Page 17
P11E	User Code #11	Page 17
P12E	User Code #12	Page 17
P13E	User Code #13	Page 17
P14E	User Code #14	Page 17
P15E	User Code #15	Page 17
P16E	User Code #16	Page 17
P17E	User Code #17	Page 17
P18E	User Code #18	Page 17
P19E	User Code #19	Page 17
P20E	User Code #20	Page 17
P21E	User Code #21	Page 17
P22E	User Code #22	Page 17
P23E	User Code #23	Page 17
P24E	User Code #24	Page 17
P25E	User Code #25	Page 17
P26E	User Code #26	Page 17
P27E	User Code #27	Page 17
P28E	User Code #28	Page 17
P29E	User Code #29	Page 17
P30E	User Code #30	Page 17
P31E	User Code #31	Page 17
P32E	User Code #32	Page 17
P33E	User Code #33	Page 17
P34E	User Code #34	Page 17
P35E	User Code #35	Page 17
P36E	User Code #36	Page 17
P37E	User Code #37	Page 17
P38E	User Code #38	Page 17
P39E	User Code #39	Page 17
P40E	User Code #40	Page 17
P41E	User Code #41	Page 17
P42E	User Code #42	Page 17
P43E	User Code #43	Page 17
P44E	User Code #44	Page 17
P45E	User Code #45	Page 17
P46E	User Code #46	Page 17
P47E	User Code #47	Page 17
P48E	User Code #48	Page 17
P49E	User Code #49	Page 17
P50E	User Code #50	Page 17

INSTALLER MODE PROGRAMMING

Programming User Code Permissions

P51E	Standard Access Permissions for user #1 - Default 1-8	P51E-100E OPTIONS	Page 18
P52E	Standard Access Permissions for user #2 - Default 1-8	1 = Area "A"	Page 18
P53E	Standard Access Permissions for user #3 - Default 1-8	2 = Area "B"	Page 18
P54E	Standard Access Permissions for user #4 - Default 1-8	3 = Area "C"	Page 18
P55E	Standard Access Permissions for user #5 - Default 1-8	4 = Code can arm	Page 18
P56E	Standard Access Permissions for user #6 - Default 1-8	5 = Code can disarm	Page 18
P57E	Standard Access Permissions for user #7 - Default 1-8	6 = Code can monitor	Page 18
P58E	Standard Access Permissions for user #8 - Default 1-8	7 = Code can un-monitor	Page 18
P59E	Standard Access Permissions for user #9 - Default 1-8	8 = Code can operate Control	Page 18
P60E	Standard Access Permissions for user #10 - Default 1-8		Page 18
P61E	Standard Access Permissions for user #11 - Default 1-8		Page 18
P62E	Standard Access Permissions for user #12 - Default 1-8		Page 18
P63E	Standard Access Permissions for user #13 - Default 1-8		Page 18
P64E	Standard Access Permissions for user #14 - Default 1-8		Page 18
P65E	Standard Access Permissions for user #15 - Default 1-8		Page 18
P66E	Standard Access Permissions for user #16 - Default 1-8		Page 18
P67E	Standard Access Permissions for user #17 - Default 1-8		Page 18
P68E	Standard Access Permissions for user #18 - Default 1-8		Page 18
P69E	Standard Access Permissions for user #19 - Default 1-8		Page 18
P70E	Standard Access Permissions for user #20 - Default 1-8		Page 18
P71E	Standard Access Permissions for user #21 - Default 1-8		Page 18
P72E	Standard Access Permissions for user #22 - Default 1-8		Page 18
P73E	Standard Access Permissions for user #23 - Default 1-8		Page 18
P74E	Standard Access Permissions for user #24 - Default 1-8		Page 18
P75E	Standard Access Permissions for user #25 - Default 1-8		Page 18
P76E	Standard Access Permissions for user #26 - Default 1-8		Page 18
P77E	Standard Access Permissions for user #27 - Default 1-8		Page 18
P78E	Standard Access Permissions for user #28 - Default 1-8		Page 18
P79E	Standard Access Permissions for user #29 - Default 1-8		Page 18
P80E	Standard Access Permissions for user #30 - Default 1-8		Page 18
P81E	Standard Access Permissions for user #31 - Default 1-8		Page 18
P82E	Standard Access Permissions for user #32 - Default 1-8		Page 18
P83E	Standard Access Permissions for user #33 - Default 1-8		Page 18
P84E	Standard Access Permissions for user #34 - Default 1-8		Page 18
P85E	Standard Access Permissions for user #35 - Default 1-8		Page 18
P86E	Standard Access Permissions for user #36 - Default 1-8		Page 18
P87E	Standard Access Permissions for user #37 - Default 1-8		Page 18
P88E	Standard Access Permissions for user #38 - Default 1-8		Page 18
P89E	Standard Access Permissions for user #39 - Default 1-8		Page 18
P90E	Standard Access Permissions for user #40 - Default 1-8		Page 18
P91E	Standard Access Permissions for user #41 - Default 1-8		Page 18
P92E	Standard Access Permissions for user #42 - Default 1-8		Page 18
P93E	Standard Access Permissions for user #43 - Default 1-8		Page 18
P94E	Standard Access Permissions for user #44 - Default 1-8		Page 18
P95E	Standard Access Permissions for user #45 - Default 1-8		Page 18
P96E	Standard Access Permissions for user #46 - Default 1-8		Page 18
P97E	Standard Access Permissions for user #47 - Default 1-8		Page 18
P98E	Standard Access Permissions for user #48 - Default 1-8		Page 18
P99E	Standard Access Permissions for user #49 - Default 1-8		Page 18
P100E	Standard Access Permissions for user #50 - Default 1-8		Page 18

Programming Extended User Code Permissions

P101E	Extended Access Permissions for user #1 - Default 1-4,6-8	P101E-P150E OPTIONS	Page 18
P102E	Extended Access Permissions for user #2 - Default 0	1 = Code can override DOTL	Page 18
P103E	Extended Access Permissions for user #3 - Default 0	2 = Can change phone numbers	Page 18
P104E	Extended Access Permissions for user #4 - Default 0	3 = Can change real time clock	Page 18
P105E	Extended Access Permissions for user #5 - Default 0	4 = Can start a printout	Page 18
P106E	Extended Access Permissions for user #6 - Default 0	5 = Can answer call for u/d load	Page 18
P107E	Extended Access Permissions for user #7 - Default 0	6 = Can change their code only	Page 18
P108E	Extended Access Permissions for user #8 - Default 0	7 = Can change all codes	Page 18
P109E	Extended Access Permissions for user #9 - Default 0	8 = Allows access to installer mode via client mode.	Page 18
P110E	Extended Access Permissions for user #10 - Default 0		Page 18

P173E	Access Time Zones for user #23 - Default 0 (24 Hr 7 Days)	Page 18
P174E	Access Time Zones for user #24 - Default 0 (24 Hr 7 Days)	Page 18
P175E	Access Time Zones for user #25 - Default 0 (24 Hr 7 Days)	Page 18
P176E	Access Time Zones for user #26 - Default 0 (24 Hr 7 Days)	Page 18
P177E	Access Time Zones for user #27 - Default 0 (24 Hr 7 Days)	Page 18
P178E	Access Time Zones for user #28 - Default 0 (24 Hr 7 Days)	Page 18
P179E	Access Time Zones for user #29 - Default 0 (24 Hr 7 Days)	Page 18
P180E	Access Time Zones for user #30 - Default 0 (24 Hr 7 Days)	Page 18
P181E	Access Time Zones for user #31 - Default 0 (24 Hr 7 Days)	Page 18
P182E	Access Time Zones for user #32 - Default 0 (24 Hr 7 Days)	Page 18
P183E	Access Time Zones for user #33 - Default 0 (24 Hr 7 Days)	Page 18
P184E	Access Time Zones for user #34 - Default 0 (24 Hr 7 Days)	Page 18
P185E	Access Time Zones for user #35 - Default 0 (24 Hr 7 Days)	Page 18
P186E	Access Time Zones for user #36 - Default 0 (24 Hr 7 Days)	Page 18
P187E	Access Time Zones for user #37 - Default 0 (24 Hr 7 Days)	Page 18
P188E	Access Time Zones for user #38 - Default 0 (24 Hr 7 Days)	Page 18
P189E	Access Time Zones for user #39 - Default 0 (24 Hr 7 Days)	Page 18
P190E	Access Time Zones for user #40 - Default 0 (24 Hr 7 Days)	Page 18
P191E	Access Time Zones for user #41 - Default 0 (24 Hr 7 Days)	Page 18
P192E	Access Time Zones for user #42 - Default 0 (24 Hr 7 Days)	Page 18
P193E	Access Time Zones for user #43 - Default 0 (24 Hr 7 Days)	Page 18
P194E	Access Time Zones for user #44 - Default 0 (24 Hr 7 Days)	Page 18
P195E	Access Time Zones for user #45 - Default 0 (24 Hr 7 Days)	Page 18
P196E	Access Time Zones for user #46 - Default 0 (24 Hr 7 Days)	Page 18
P197E	Access Time Zones for user #47 - Default 0 (24 Hr 7 Days)	Page 18
P198E	Access Time Zones for user #48 - Default 0 (24 Hr 7 Days)	Page 18
P199E	Access Time Zones for user #49 - Default 0 (24 Hr 7 Days)	Page 18
P200E	Access Time Zones for user #50 - Default 0 (24 Hr 7 Days)	Page 18

Programming Output Options

P201E	Output #1 Primary options - Default none	P201E-P208E OPTIONS	
P202E	Output #2 Primary options - Default none	1 = Invert	Page 19
P203E	Output #3 Primary options - Default none	2 = Flashing	Page 19
P204E	Output #4 Primary options - Default none	3 = Single pulse	Page 19
P205E	Output #5 Primary options - Default none	4 = One Shot (lock-out)	Page 19
P206E	Output #6 Primary options - Default none	5 = DTMF remote control	Page 19
P207E	Output #7 Primary options - Default none	6 = Local command control	Page 19
P208E	Output #8 Primary options - Default none	7 = Day zone linked to pulse timer	Page 19
		8 = Pulsed 24 Hour alarm	Page 19
P211E	Output #1 Expanded options - Default 1,3,4,6	P211E-P218E OPTIONS	Page 20
P212E	Output #2 Expanded options - Default 1,3,4,6	1 = Keypad panic to output	Page 20
P213E	Output #3 Expanded options - Default 1,3,4,6	2 = Keypad fire to output	Page 20
P214E	Output #4 Expanded options - Default 1,3,4,6	3 = Keypad medical to output	Page 20
P215E	Output #5 Expanded options - Default 1,3,4,6	4 = Duress Alarm to output	Page 20
P216E	Output #6 Expanded options - Default 1,3,4,6	5 = Keypad tamper to output	Page 20
P217E	Output #7 Expanded options - Default 1,3,4,6	6 = Radio key panic to output	Page 20
P218E	Output #8 Expanded options - Default 1,3,4,6	7 = 24 hour alarms	Page 20
		8 = 24 hour fire alarms	
P221E	Output #1 Expanded options 2 - Default 1,2	P221E-P228E OPTIONS	Page 20
P222E	Output #2 Expanded options 2 - Default 1,2	1 = Zone tampers to output	Page 20
P223E	Output #3 Expanded options 2 - Default 1,2	2 = Cabinet tamper to output	Page 20
P224E	Output #4 Expanded options 2 - Default 1,2	3 = Mains fail to output	Page 20
P225E	Output #5 Expanded options 2 - Default 1,2	4 = Battery low to output	Page 20
P226E	Output #6 Expanded options 2 - Default 1,2	5 = Phone Line failure	Page 20
P227E	Output #7 Expanded options 2 - Default 1,2	6 = Failure to get kiss-off	Page 20
P228E	Output #8 Expanded options 2 - Default 1,2	7 = Automatic pulse every 5 sec.	Page 20
		8 = 24 Hour alarm reset pulse	
P231E	Output #1 Automatic on / off time zones - Default 0 (never)		Page 21
P232E	Output #2 Automatic on / off time zones - Default 0 (never)		Page 21
P233E	Output #3 Automatic on / off time zones - Default 0 (never)		Page 21
P234E	Output #4 Automatic on / off time zones - Default 0 (never)		Page 21

P235E	Output #5 Automatic on / off time zones - Default 0 (never)	Page 21
P236E	Output #6 Automatic on / off time zones - Default 0 (never)	Page 21
P237E	Output #7 Automatic on / off time zones - Default 0 (never)	Page 21
P238E	Output #8 Automatic on / off time zones - Default 0 (never)	Page 21
P241E	Output #1 Enable time zones - Default 0 (always)	Page 21
P242E	Output #2 Enable time zones - Default 0 (always)	Page 21
P243E	Output #3 Enable time zones - Default 0 (always)	Page 21
P244E	Output #4 Enable time zones - Default 0 (always)	Page 21
P245E	Output #5 Enable time zones - Default 0 (always)	Page 21
P246E	Output #6 Enable time zones - Default 0 (always)	Page 21
P247E	Output #7 Enable time zones - Default 0 (always)	Page 21
P248E	Output #8 Enable time zones - Default 0 (always)	Page 21

Programming Installer Code

P249E	Installer Code - Default 000000 - must be more than 3 digits long	Page 19
--------------	---	---------

Programming Keypad Options

P250E	Keypads assigned to Area "A" - Default 1-8	Page 22
P251E	Keypads assigned to Area "B" - Default none	Page 22
P252E	Keypads assigned to Area "C" - Default none	Page 22
P253E	Keypads with permission to Arm - Default 1-8	Page 22
P254E	Keypads with permission to Arm Stay Mode - Default 1-8	Page 22
P255E	Keypads with permission to use control function - Default 1-8	Page 22
P256E	Keypads with permission to bypass zones - Default 1-8	Page 22
P257E	Keypads (LED) with Panic Button enabled - Default 1-8	Page 22
P258E	Keypads (LED) with Delayed Panic Button enabled - Default 1-8	Page 22
P259E	Keypads with buttons 1 & 3 Panic Alarm enabled - Default 1-8	Page 22
P260E	Keypads with buttons 4 & 6 Fire Alarm enabled - Default 1-8	Page 22
P261E	Keypads with buttons 7 & 9 Medical Alarm enabled - Default 1-8	Page 22
P262E	Keypads with buzzer mapped for alarm tone for armed zone alarms - Default 1-8	Page 22
P263E	Keypads with buzzer mapped for alarm tone for stay mode zone alarms - Default 1-8	Page 22
P264E	Keypads with buzzer mapped for alarm tone for 24 hour zone alarms - Default 1-8	Page 23
P265E	Keypads with buzzer mapped for alarm tone for day mode zones - Default 1-8	Page 23
P266E	Keypads with buzzer mapped to indicate Arm Mode exit delay beeps - Default 1-8	Page 23
P267E	Keypads with buzzer mapped to indicate Stay Mode exit delay beeps - Default 1-8	Page 23
P268E	Keypads with buzzer mapped to indicate entry delay beeps - Default 1-8	Page 23
P269E	Keypads with buzzer mapped for supervised radio timeout, or zone inactivity alarm - Default 1-8	Page 23
P270E	Keypads with buzzer mapped to keypad tamper - Default 1-8	Page 23
P271E	Keypads with buzzer mapped to zone tamper - Default 1-8	Page 23
P272E	Keypads with buzzer mapped to cabinet tamper - Default 1-8	Page 23
P273E	Keypads with buzzer mapped to Radio Pendant "Panic" Alarm - Default 1-8	Page 23
P274E	Keypads with buzzer mapped to "Panic" Alarm - Default 1-8	Page 23
P275E	Keypads with buzzer mapped to "Fire" Alarm - Default 1-8	Page 23
P276E	Keypads with buzzer mapped to "Medical" Alarm - Default 1-8	Page 23
P277E	Keypads with buzzer mapped to line failure - Default none	Page 23
P278E	Keypads with facility to turn off LED's after exit delay - Default none	Page 23

Partition "A" Primary Output Options

P281E	Area "A" primary options for output #1 - Default 1	P281E-P288E OPTIONS 1 = Standard zone activation's	Page 24
P282E	Area "A" primary options for output #2 - Default 1 & 2	2 = Stay Mode activation's	Page 24
P283E	Area "A" primary options for output #3 - Default 1	3 = Radio key chirps	Page 24
P284E	Area "A" primary options for output #4 - Default 1	4 = All zones sealed (ready)	Page 24
P285E	Area "A" primary options for output #5 - Default 1	5 = 2 sec pulse on arm / disarm	Page 24
P286E	Area "A" primary options for output #6 - Default 1	6 = Spare	Page 24
P287E	Area "A" primary options for output #7 - Default 1	7 = Day zone activation's	Page 24
P288E	Area "A" primary options for output #8 - Default 1	8 = Spare	Page 24

** Dialler Reporting Options for partition "A" **

P289E	Area A reporting options -Default = 1,2	Page 28
--------------	---	---------

- | | |
|---|--|
| 1 = Send set / unset | 5 = Send set at the end of the exit delay (LED On) |
| 2 = Send Stay Mode set/unset | 6 = Send all zone restores at disarm only |
| 3 = Send unset only after activation's | 7 = Spare |
| 4 = Send Stay Mode unset only after alarm | 8 = Spare |

Programming Partition "A" Parameters

P290E Time Zones used for Area "A" auto arming /disarming- Default 0 Page 25

Partition "A" Specific Output Options

P291E Area "A" specific options for output #1 - Default 0
P292E Area "A" specific options for output #2 - Default 0
P293E Area "A" specific options for output #3 - Default 0
P294E Area "A" specific options for output #4 - Default 0
P295E Area "A" specific options for output #5 - Default 0
P296E Area "A" specific options for output #6 - Default 0
P297E Area "A" specific options for output #7 - Default 0
P298E Area "A" specific options for output #8 - Default 0

P291E-P298E OPTIONS

1 = Any bypass Page 24
 2 = Auto-bypass warning Page 24
 3 = Entry beeps Page 24
 4 = Exit beeps Page 24
 5 = Control Page 24
 6 = Follow Set Arming Page 24
 7 = Follow Stay Arming Page 24
 8 = Follow Unset Page 24

Partition "A" Keypad Options

P299E Arm key can disarm during exit - Default 1-8 Page 25
P300E Stay key can disarm during Stay armed state. - Default 1-8 Page 25

P301E Misc partition options 1 - Default = 0 Page 26

1 = Cannot Arm if not sealed
 2 = "Arm" required before code
 3 = "Stay" required before code
 4 = Code required to arm
 5 = Code required for control
 6 = Control toggles
 7 = Momentary control
 8 = Control/Chime disables day zones

Partition "A" Misc Options

P302E Misc partition options 2 - Default 3,4,6 Page 27

1 = Key-switch enabled
 2 = Use 2nd Key-switch
 3 = Key-switch ARM's/STAY
 4 = Pendant chirps when Armed
 5 = Pendant chirps when in Stay Mode
 6 = 2 sec pulse at set
 7 = 2 sec pulse at unset
 8 = Access control even when armed

P303E **PARTITION "A" TIME AND DELAY OPTIONS-Default = 0** Page 25

1 = Set partition When Time Zone Ends
 2 = Unset Partition When Time Zone Starts
 3 = Disable Stay Mode Exit Delay
 4 = Disable Set Mode Exit Delay
 5 = Disable Stay Mode Entry Delay
 6 = Disable Set Mode Entry Delay
 7 = Use special Stay Mode entry timer
 8 = Report Stay Mode alarms & Bypasses via dialer

Miscellaneous System Options "A"

P310E Options - Default 6,8 Page 29

1 = Ignore Mains fail
 2 = Horn Speaker Driver on O/P # 1
 3 = Horn Speaker Driver on O/P # 2
 4 = Turn Off Alert KP LED's when armed
 5 = Ignore Zone Tamper's during exit delay

- 6 = Installer code direct access
- 7 = Installer lockout
- 8 = Area "C" is zones shared with Area A & B

Miscellaneous System Options "B"

P311E Options - Default 1,2,3,4

- 1 = System Tamper EOL or short circuit loop
- 2 = Key-switch Tamper EOL or short circuit loop
- 3 = Low Key-switch is momentary or latching
- 4 = High Key-switch is momentary or latching
- 5 = Send O/P data to keypad buss (Off = No O/P data on buss)
- 6 = Restrict Access to Memory Mode
- 7 = Turn off LCD backlighting during AC Fail
- 8 = Spare

Page 29

Keypad Listen-in Options

P312E Keypad Listen-in Options

P312E Options (Default = 1-7 On)

Page 53

- 1 = Enabled During Dialling in Disarm State only
- 2 = Enabled During Dialling in Armed State only
- 3 = Enabled During Dialling in Monitor Mode State only
- 4 = Enabled Throughout the call in Disarm State only
- 5 = Enabled Throughout the call in Armed State only
- 6 = Enabled Throughout the call in Monitor Mode State only
- 7 = Listen-in Enabled when the panel answers a call
- 8 = Enabled at All Times

Output #1 Listen-in Options

P313E Output # 1 Listen-in Options

P313E Options (Default = Off)

Page 53

- 1 = Enabled During Dialling in Disarm State only
- 2 = Enabled During Dialling in Armed State only
- 3 = Enabled During Dialling in Monitor Mode State only
- 4 = Enabled Throughout the call in Disarm State only
- 5 = Enabled Throughout the call in Armed State only
- 6 = Enabled Throughout the call in Monitor Mode State only
- 7 = Listen-in Enabled when the panel answers a call
- 8 = Enabled at All Times

Miscellaneous Dialler Reporting Options A

P314E Dialler Misc Report Options A

P314E Options (Default = 1,2,3,4,5,6,7,8)

Page 53

- 1 = Report Duress via Dialler
- 2 = Report Mains Failure via Dialler
- 3 = Report System Battery Low via Dialler
- 4 = Report Radio Battery Low via Dialler
- 5 = Report System Tamper via Dialler
- 6 = Report Telephone Line Failure via Dialler
- 7 = Report Supervised Radio Timeout via Dialler
- 8 = Report Zone Inactivity Timeout via Dialler

Miscellaneous Dialler Reporting Options B

P315E Dialler Misc Report Options B

P315E Options (Default = 1,2,3,4)

Page 53

- 1 = Report Panic Alarms via Dialler
- 2 = Report Fire Alarms via Dialler
- 3 = Report Medical Alarms via Dialler
- 4 = Report 24 Hour alarms in Domestic/Voice Mode.

** Reporting Scenarios **

P321E Reporting Scenario #1 options (Default = 1,7)

Page 46

P322E Reporting Scenario #2 options (Default = 0)

Page 46

P323E Reporting Scenario #3 options (Default = 0)

Page 46

** Maximum Dialling Attempts per Scenario **

P325E	Max Dial Attempts for Scenario Number 1-Value 1-99 (Default=20)	Page 47
P326E	Max Dial Attempts for Scenario Number 2-Value 1-99 (Default=20)	Page 47
P327E	Max Dial Attempts for Scenario Number 3-Value 1-99 (Default=20)	Page 47
P328E	Max Dial Attempts for Scenario Number 4-Value 1-99 (Default=20)	Page 47

**Telephone Number Pre-fix **

P330E	Telephone Number Pre-fix - 16 Characters Maximum	Page 47
--------------	--	---------

** Programming Telephone Numbers **

P331E	Telephone Number 1 - 16 Characters Maximum	Page 47
P332E	Telephone Number 2 - 16 Characters Maximum	Page 47
P333E	Telephone Number 3 - 16 Characters Maximum	Page 47
P334E	Telephone Number 4 - 16 Characters Maximum	Page 47
P335E	Telephone Number 5 - 16 Characters Maximum	Page 47
P336E	Telephone Number 6 - 16 Characters Maximum	Page 47

Telephone Number Reporting Options

P337E	Reporting Opts. Ph # 1 (Default= 1)	P337E-P342E Options	Page 47
P338E	Reporting Opts. Ph # 2 (Default= None)	1 = Contact ID	
P339E	Reporting Opts. Ph # 3 (Default= None)	2 = Domestic Dial	
P340E	Reporting Opts. Ph # 4 (Default= None)	3 = Pager	
P341E	Reporting Opts. Ph # 5 (Default= None)	4 = Speech Dialler	
P342E	Reporting Opts. Ph # 6 (Default= None)	5 = 4+2 10pps (Handshake 1400/ Tone 1800)	
		6 = 4+2 10pps (Handshake 1400/ Tone 1900)	
		7 = 4+2 10pps (Handshake 2300/ Tone 1800)	
		8 = 4+2 10pps (Handshake 2300/ Tone 1900)	
		9 = 4+2 20pps (Handshake 1400/ Tone 1800)	
		10= 4+2 20pps (Handshake 1400/ Tone 1900)	
		11= 4+2 20pps (Handshake 2300/ Tone 1800)	
		12= 4+2 20pps (Handshake 2300/ Tone 1900)	
		13= 4+2 DTMF	

Telephone Number Reporting Options

P343E	Options for Telephone # 1	P343E-P348E Options (Default =1,4,5)	Page 48
P344E	Options for Telephone # 2	1 = Monitor Call Progress	
P345E	Options for Telephone # 3	2 = Blind Dial	
P346E	Options for Telephone # 4	3 = Use Group Numbers for Contact ID	
P347E	Options for Telephone # 5	4 = Send Restores	
P348E	Options for Telephone # 6	5 = Send Test Calls	
		6 = Add Telephone Number Pre-fix (P330E) to this number	
		7 = Auto Kiss-off in Domestic Mode	
		8 = Spare	

Programming Duress Digit

P350E	Duress Digit (Value can be 1-9, 0 = disabled) default 0	Page 19
--------------	---	---------

** Zone Activation to Scenario Mapping **

P351E	Zone 1 activation's mapped to scenario 1-4	default 1	Page 49
P352E	Zone 2 activation's mapped to scenario 1-4	default 1	Page 49
P353E	Zone 3 activation's mapped to scenario 1-4	default 1	Page 49
P354E	Zone 4 activation's mapped to scenario 1-4	default 1	Page 49
P355E	Zone 5 activation's mapped to scenario 1-4	default 1	Page 49
P356E	Zone 6 activation's mapped to scenario 1-4	default 1	Page 49
P357E	Zone 7 activation's mapped to scenario 1-4	default 1	Page 49
P358E	Zone 8 activation's mapped to scenario 1-4	default 1	Page 49
P359E	Zone 9 activation's mapped to scenario 1-4	default 1	Page 49

P360E	Zone 10 activation's mapped to scenario 1-4	default 1	Page 49
P361E	Zone 11 activation's mapped to scenario 1-4	default 1	Page 49
P362E	Zone 12 activation's mapped to scenario 1-4	default 1	Page 49
P363E	Zone 13 activation's mapped to scenario 1-4	default 1	Page 49
P364E	Zone 14 activation's mapped to scenario 1-4	default 1	Page 49
P365E	Zone 15 activation's mapped to scenario 1-4	default 1	Page 49
P366E	Zone 16 activation's mapped to scenario 1-4	default 1	Page 49

**** Auto Answer Ring Count ****

P369E	Auto-answer ring count - default = 25	Page 54
--------------	---------------------------------------	---------

**** System reporting Options ****

P370E	System options (Default = 2,7)	Page 46
	1 = Enable communicator	5 = Reverse Style Pulse
	2 = Fax defeat	6 = Long DTMF Dialling tones
	3 = Disable line monitoring	7 = Auto-Detect Modem Format
	4 = DTMF or Pulse	8 = Force Bell103/V21

**** Command Control Options ****

P371E	Command code for output control	Page 42
P372E	Command code for Area "A" control	Page 42
P373E	Command code for Area "B" control	Page 42
P374E	Command code for Area "C" control	Page 42
P375E	Command code to turn "MICROPHONE" On	Page 42

**** Contact ID Account Codes ****

P376E	Account number for Area "A" - default 0000	Page 51
P377E	Account number for Area "B"	Page 51
P378E	Account number for Area "C"	Page 51

Partition "B" Primary Output Options

P381E-P388E OPTIONS

P381E	Area "B" primary options for output #1 - Default 1	1 = Standard zone activation's	Page 24
P382E	Area "B" primary options for output #2 - Default 1 & 2	2 = Stay Mode activation's	Page 24
P383E	Area "B" primary options for output #3 - Default 1	3 = Radio key chirps	Page 24
P384E	Area "B" primary options for output #4 - Default 1	4 = All zones sealed (Ready)	Page 24
P385E	Area "B" primary options for output #5 - Default 1	5 = 2 sec pulse arm/disarm	Page 24
P386E	Area "B" primary options for output #6 - Default 1	6 = Spare	Page 24
P387E	Area "B" primary options for output #7 - Default 1	7 = Day zone activation's	Page 24
P388E	Area "B" primary options for output #8 - Default 1	8 = Spare	Page 24

**** Dialler Reporting Options for partition "B" ****

P389E	Area B reporting options -Default = 1,2	Page 28
	1 = Send set / unset	5 = Send set at the end of the exit delay (LED On)
	2 = Send Stay Mode set/unset	6 = Send all zone restores at disarm only
	3 = Send unset only after activation's	7 = Spare
	4 = Send Stay Mode unset only after alarm	8 = Spare

Programming Partition "B" Parameters

P390E	Time zones used for Area "B" auto arming/disarming - Default 0	Page 25
--------------	--	---------

Partition "B" Specific Output Options

P391E-P398E OPTIONS

P391E	Area "B" specific options for output #1 - Default 0	1 = Any bypass	Page 24
P392E	Area "B" specific options for output #2 - Default 0	2 = Auto-bypass warning	Page 24
P393E	Area "B" specific options for output #3 - Default 0	3 = Entry beeps	Page 24

P394E	Area "B" specific options for output #4 - Default 0	4 = Exit beeps	Page 24
P395E	Area "B" specific options for output #5 - Default 0	5 = Control	Page 24
P396E	Area "B" specific options for output #6 - Default 0	6 = Follow Set Arming	Page 24
P397E	Area "B" specific options for output #7 - Default 0	7 = Follow Stay Arming	Page 24
P398E	Area "B" specific options for output #8 - Default 0	8 = Follow Unset	Page 24

Partition "B" Keypad Options

P399E	Arm key can disarm during exit - Default 1-8	Page 25
P400E	Stay key can disarm during Stay armed state - Default 1-8	Page 25

Partition "B" Misc Options

P401E	Misc partition options 1 - Default 0	1 = Cannot Arm if not sealed 2 = "Arm" required before code 3 = "Stay" required before code 4 = Code required to arm 5 = Code required for control 6 = Control toggles 7 = Momentary control 8 = Control/Chime disables day zones	Page 26
P402E	Misc partitions options 2 - Default 3,4,6	1 = Key-switch enabled 2 = Use 2nd Key-switch 3 = Key-switch ARM's/STAY 4 = Pendant chirps when armed 5 = Pendant chirps when in Stay Mode 6 = 2 sec pulse at set 7 = 2 sec pulse at unset 8 = Access control even when armed	Page 27

P403E	PARTITION "B" TIME AND DELAY OPTIONS	Page 25
	1 = Set partition When Time Zone Ends	
	2 = Unset Partition When Time Zone Starts	
	3 = Disable Stay Mode Exit Delay	
	4 = Disable Set Mode Exit Delay	
	5 = Disable Stay Mode Entry Delay	
	6 = Disable Set Mode Entry Delay	
	7 = Use special Stay Mode entry timer	
	8 = Report Stay Mode alarms & Bypasses via dialer	

Soak-Test Zones

P408E	SOAK-TEST ZONES - 1-8	Page 30
P409E	SOAK-TEST ZONES - 9-16	Page 30

Single or Dual Zone Input (8 or 16 Zones)

P410E	Single or dual zone input - Default-All Off (zones 1-8 only)	Page 30
--------------	--	---------

Vibration Sensor Zone Sensitivity Settings (Zones 1-8)

P411E	Zone 1 vibration sensitivity - Default 0	0 = No vibration sensor	Page 30
P412E	Zone 2 vibration sensitivity - Default 0	Sensitivity 1-8	Page 30
P413E	Zone 3 vibration sensitivity - Default 0	1 = High sensitivity	Page 30
P414E	Zone 4 vibration sensitivity - Default 0	8 = Low sensitivity	Page 30
P415E	Zone 5 vibration sensitivity - Default 0		Page 30
P416E	Zone 6 vibration sensitivity - Default 0		Page 30
P417E	Zone 7 vibration sensitivity - Default 0		Page 30
P418E	Zone 8 vibration sensitivity - Default 0		Page 30

Zone End of Line Options

P419E	Zone End-of-Line Options default = All On (Inputs 1-8 require EOL resistor)	Page 30
--------------	---	---------

P420E Zone response settings default = 6 (value 1-31E)

** System Events to Scenario Mapping **

P421E	Area A reports mapped to scenario 1-4	default 1	Page 50
P422E	Area B reports mapped to scenario 1-4	default 1	Page 50
P423E	Area C reports mapped to scenario 1-4	default 1	Page 50
P424E	Keypad "Panic" (& buttons 1 & 3) mapped to scenario 1-4	default 1	Page 50
P425E	Keypad "Fire" (buttons 4 & 6) mapped to scenario 1-4	default 1	Page 50
P426E	Keypad "Medical" (buttons 7 & 9) mapped to scenario 1-4	default 1	Page 50
P427E	Battery low mapped to scenario 1-4	default 0	Page 50
P428E	Mains fail mapped to scenario 1-4	default 1	Page 50
P429E	Phone line restore mapped to scenario 1-4	default 1	Page 50
P430E	Radio PIR battery low mapped to scenario 1-4	default 1	Page 50
P431E	Radiokey battery low mapped to scenario 1-4	default 1	Page 50
P432E	Keypad tamper mapped to scenario 1-4	default 1	Page 50
P433E	Cabinet tamper mapped to scenario 1-4	default 1	Page 50
P434E	Radio panic mapped to scenario 1-4	default 1	Page 50
P435E	Test calls mapped to scenario 1-4	default 1	Page 50
P436E	Duress Alarm mapped to scenario 1-4	default 1	Page 50
P437E	Supervised Radio Timeout mapped to scenario 1-4	default 1	Page 50
P438E	Zone Inactivity Timeout mapped to scenario 1-4	default 1	Page 50

Low Zone Assignments (Zones 1-8)

P441E	Zone is in Area "A" - Default all	)	Page 31
P442E	Zone is in Area "B" - Default none	) If zone is in both it is then a partition "C" zone	Page 31
P443E	Zone is a normally open/closed output - Default N/C	Off = N/C On = N/O	Page 31
P444E	Zone is a radio detector - Default Off		Page 31
P445E	Stay mode zones - Default zones 1-4		Page 31
P446E	Zone can be bypassed - Default all		Page 31
P447E	Auto-bypass zones - Default all		Page 31
P448E	Zone is a handover - Default none		Page 31
P449E	Two trigger zones -Default none		Page 31
P450E	Zone is 24Hr - Default none		Page 31
P451E	Zone is 24Hr Fire zone - Default none		Page 32
P452E	Zone is 24Hr Non-Latching zone - Default none		Page 32
P453E	Day zones - Default none		Page 32
P454E	Continuous day zone - Default none		Page 32
P455E	Siren lockout zones - Default none		Page 32
P456E	Access control door position input - Default none		Page 32
P457E	Access control request to exit input - Default none		Page 32

** Multiple Zone Activation Reporting **

P458E	Zones 1-8 will report multiple activation's - default on	Page 32
--------------	--	---------

Zones 1-8 Monitored for Inactivity

P459E	Zones 1-8 will be monitored for inactivity - default none	Page 32
--------------	---	---------

Can Arm if Zone is Unsealed-Zones 1-8

P460E	Can Arm if Zone Unsealed-Zones 1-8 - default none	Page 32
--------------	---	---------

High Zone Assignments (Zones 9-16)

P461E	Zone is in Area "A" - Default all	)	Page 32
P462E	Zone is in Area "B" - Default none	) If zone is in both it is then a partition "C" zone	Page 32
P463E	Zone is a normally open/closed output - Default N/C	Off = N/C On = N/O	Page 32
P464E	Zone is a radio detector - Default Off		Page 33
P465E	Stay mode zones - Default zones none		Page 33
P466E	Zone can be bypassed - Default all		Page 33
P467E	Auto-bypass zones - Default all		Page 33
P468E	Zone is a handover - Default none		Page 33
P469E	Two trigger zones -Default none		Page 33

P470E	Zone is 24Hr - Default none	Page 33
P471E	Zone is 24Hr Fire zone - Default none	Page 33
P472E	Zone is 24Hr Non-Latching zone - Default none	Page 33
P473E	Day zones - Default none	Page 33
P474E	Continuous day zone - Default none	Page 33
P475E	Siren lockout zones - Default none	Page 33
P476E	Access control door position input - Default none	Page 33
P477E	Access control request to exit input - Default none	Page 34

** Multiple Zone Activation Reporting **

P478E	Zones 9-16 will report multiple activation's - default on	Page 34
--------------	---	---------

Zones 9-16 Monitored for Inactivity

P479E	Zones 9-16 will be monitored for inactivity - default none	Page 34
--------------	--	---------

Can Arm if Zone is Unsealed-Zones 9-16

P480E	Can Arm if Zone Unsealed-Zones 9-16 - default none	Page 34
--------------	--	---------

Partition "C" Primary Output Options

P481E-P488E OPTIONS

P481E	Area "C" primary options for output #1 - Default 1	1 = Standard zone activation's	Page 24
P482E	Area "C" primary options for output #2 - Default 1 & 2	2 = Stay Mode activation's	Page 24
P483E	Area "C" primary options for output #3 - Default 1	3 = Radio key chirps	Page 24
P384E	Area "C" primary options for output #4 - Default 1	4 = All zones sealed (ready)	Page 24
P485E	Area "C" primary options for output #5 - Default 1	5 = 2 sec pulse on arm/disarm	Page 24
P486E	Area "C" primary options for output #6 - Default 1	6 = Spare	Page 24
P487E	Area "C" primary options for output #7 - Default 1	7 = Day zone activation's	Page 24
P488E	Area "C" primary options for output #8 - Default 1	8 = Spare	Page 24

** Dialler Reporting Options for partition "C" **

P489E	Area C reporting options -Default = 1,2	Page 28
	1 = Send set / unset	5 = Send set at the end of the exit delay (LED On)
	2 = Send Stay Mode set/unset	6 = Send all zone restores at disarm only
	3 = Send unset only after activation's	7 = Spare
	4 = Send Stay Mode unset only after alarm	8 = Spare

Programming Partition "C" Parameters

P490E	Time zones used for Area "C" auto-arming/disarming - Default 0	Page 25
--------------	--	---------

Partition "C" Specific Output Options

P491E-P498E OPTIONS

P491E	Area "C" specific options for output #1 - Default 0	1 = Any bypass	Page 24
P492E	Area "C" specific options for output #2 - Default 0	2 = Auto-bypass warning	Page 24
P493E	Area "C" specific options for output #3 - Default 0	3 = Entry beeps	Page 24
P494E	Area "C" specific options for output #4 - Default 0	4 = Exit Beeps	Page 24
P495E	Area "C" specific options for output #5 - Default 0	5 = Control	Page 24
P496E	Area "C" specific options for output #6 - Default 0	6 = Follow Set Arming	Page 24
P497E	Area "C" specific options for output #7 - Default 0	7 = Follow Stay Arming	Page 24
P498E	Area "C" specific options for output #8 - Default 0	8 = Follow Unset	Page 24

Partition "C" Keypad Options

P499E	Arm key can disarm during exit - Default 1-8	Page 25
P500E	Stay key can disarm during Stay armed state - Default 1-8	Page 25

Partition "C" Misc Options

P501E	Misc partition options 1 - Default 0	Page 26
	1 = Cannot Arm if not sealed	
	2 = "Arm" required before code	
	3 = "Stay" required before code	
	4 = Code required to arm	
	5 = Code required for control	

6 = Control toggles
 7 = Momentary control
 8 = Control disables day zones

P502E Misc partition options 2 - Default 3,4,6

1 = Key-switch enabled
 2 = Use 2nd Key-switch
 3 = Key-switch ARM's/STAY
 4 = Pendant chirps when armed
 5 = Pendant chirps when in Stay Mode
 6 = 2 sec pulse at set
 7 = 2 sec pulse at unset
 8 = Access control even when armed

Page 27

P503E PARTITION "C" TIME AND DELAY OPTIONS (Default 0)

Page 25

1 = set partition When Time Zone Ends
 2 = Unset Partition When Time Zone Starts
 3 = Disable Stay Mode Exit Delay
 4 = Disable Set Mode Exit Delay
 5 = Disable Stay Mode Entry Delay
 6 = Disable Set Mode Entry Delay
 7 = Use special Stay Mode entry timer
 8 = Report Stay Mode alarms & Bypasses via dialer

System Delays & Timers

P511E Zone 1 entry delay - Default 20 sec

Delay timer values

Page 34

P512E Zone 2 entry delay - Default 20 sec

0 = instant, no delay

Page 34

P513E Zone 3 entry delay - Default 0

1-9999 = 1 -9999 seconds

Page 34

P514E Zone 4 entry delay - Default 0

Page 34

P515E Zone 5 entry delay - Default 0

Page 34

P516E Zone 6 entry delay - Default 0

Page 34

P517E Zone 7 entry delay - Default 0

Page 34

P518E Zone 8 entry delay - Default 0

Page 34

P519E Zone 9 entry delay - Default 0

Page 34

P520E Zone 10 entry delay - Default 0

Page 34

P521E Zone 11 entry delay - Default 0

Page 34

P522E Zone 12 entry delay - Default 0

Page 34

P523E Zone 13 entry delay - Default 0

Page 34

P524E Zone 14 entry delay - Default 0

Page 34

P525E Zone 15 entry delay - Default 0

Page 34

P526E Zone 16 entry delay - Default 0

Page 34

P531E Area "A" exit delay - Default = 60 sec

Page 34

P532E Area "B" exit delay - Default = 60 sec

Page 34

P533E Area "C" exit delay - Default = 60 sec

Page 34

P534E Area "A" two trigger time period - Default 60 sec

Page 34

P535E Area "B" two trigger time period - Default 60 sec

Page 34

P536E Area "C" two trigger time period - Default 60 sec

Page 34

P537E Area "A" door open too long timer (DOTL) - Default 10 sec

Page 36

P538E Area "B" door open too long timer (DOTL) - Default 10 sec

Page 36

P539E Area "C" door open too long timer (DOTL) - Default 10 sec

Page 36

P540E Area "A" Special Stay Mode entry delay - Default 20 sec

Page 34

P541E Area "B" Special Stay Mode entry delay - Default 20 sec

Page 34

P542E Area "C" Special Stay Mode entry delay - Default 20 sec

Page 34

P543E Area "A" day zone keypad buzzer duration - Default 2 sec

Page 35

P544E Area "B" day zone keypad buzzer duration - Default 2 sec

Page 35

P545E Area "C" day zone keypad buzzer duration - Default 2 sec

Page 35

P546E Area "A" day zone to Output duration - Default 2 sec

Page 35

P547E	Area "B" day zone to Output duration - Default 2 sec		Page 35
P548E	Area "C" day zone to Output duration - Default 2 sec		Page 35
P551E	Output #1 reset time - Default 600 sec	Reset time values	Page 35
P552E	Output #2 reset time - Default 600 sec	0 = latching	Page 35
P553E	Output #3 reset time - Default 600 sec	1-999 = 1 to 999 seconds	Page 35
P554E	Output #4 reset time - Default 600 sec		Page 35
P555E	Output #5 reset time - Default 0 sec		Page 35
P556E	Output #6 reset time - Default 0 sec		Page 35
P557E	Output #7 reset time - Default 0 sec		Page 35
P558E	Output #8 reset time - Default 0 sec		Page 35
P559E	Mains Fail Reporting Delay to Dialler (0-999 sec) - Default = 600		Page 54
P560E	Zone Reporting Delay to Dialler (0-9999 sec) - Default = 0		Page 54
P561E	Output #1 delay on timer - Default 0	Delay time values	Page 35
P562E	Output #2 delay on timer - Default 0	0 = no delay	Page 35
P563E	Output #3 delay on timer - Default 0	1 - 999 = 1 to 999 seconds	Page 35
P564E	Output #4 delay on timer - Default 0		Page 35
P565E	Output #4 delay on timer - Default 0		Page 35
P566E	Output #5 delay on timer - Default 0		Page 35
P567E	Output #6 delay on timer - Default 0		Page 35
P568E	Output #7 delay on timer - Default 0		Page 35
P569E	Zone Inactivity Timer (0-255 hour) - Default = 120 Hours		Page 35
P570E	Supervised Radio Timer (0-255 minutes) - Default = 240 Minutes		Page 35
P571E	Output #1 pulse time - Default 1	Pulse time values	Page 35
P572E	Output #2 pulse time - Default 1	1-999 (min of 1)	Page 35
P573E	Output #3 pulse time - Default 1	1 to 999 in 1/10 secs	Page 35
P574E	Output #4 pulse time - Default 1	e.g. 1 = 0.1 second	Page 35
P575E	Output #5 pulse time - Default 1	10 = 1 second	Page 35
P576E	Output #6 pulse time - Default 1		Page 35
P577E	Output #7 pulse time - Default 1		Page 35
P578E	Output #8 pulse time - Default 1		Page 35

** Bypass to Scenario Mapping **

P581E	Zone 1 bypass mapped to scenario 1-4	default 1	Page 49
P582E	Zone 2 bypass mapped to scenario 1-4	default 1	Page 49
P583E	Zone 3 bypass mapped to scenario 1-4	default 1	Page 49
P584E	Zone 4 bypass mapped to scenario 1-4	default 1	Page 49
P585E	Zone 5 bypass mapped to scenario 1-4	default 1	Page 49
P586E	Zone 6 bypass mapped to scenario 1-4	default 1	Page 49
P587E	Zone 7 bypass mapped to scenario 1-4	default 1	Page 49
P588E	Zone 8 bypass mapped to scenario 1-4	default 1	Page 49
P589E	Zone 9 bypass mapped to scenario 1-4	default 1	Page 49
P590E	Zone 10 bypass mapped to scenario 1-4	default 1	Page 49
P591E	Zone 11 bypass mapped to scenario 1-4	default 1	Page 49
P592E	Zone 12 bypass mapped to scenario 1-4	default 1	Page 49
P593E	Zone 13 bypass mapped to scenario 1-4	default 1	Page 49
P594E	Zone 14 bypass mapped to scenario 1-4	default 1	Page 49
P595E	Zone 15 bypass mapped to scenario 1-4	default 1	Page 49
P596E	Zone 16 bypass mapped to scenario 1-4	default 1	Page 49

** Low Zone Tamper to Scenario Mapping **

P601E	Low zone 1 tamper alarms mapped to scenario 1-4	default 1	Page 50
P602E	Low zone 2 tamper alarms mapped to scenario 1-4	default 1	Page 50
P603E	Low zone 3 tamper alarms mapped to scenario 1-4	default 1	Page 50
P604E	Low zone 4 tamper alarms mapped to scenario 1-4	default 1	Page 50
P605E	Low zone 5 tamper alarms mapped to scenario 1-4	default 1	Page 50

P606E	Low zone 6 tamper alarms mapped to scenario 1-4	default 1	Page 50
P607E	Low zone 7 tamper alarms mapped to scenario 1-4	default 1	Page 50
P608E	Low zone 8 tamper alarms mapped to scenario 1-4	default 1	Page 50

** High Zone Tamperers to Scenario Mapping **

P609E	High zone 1 tamper alarms mapped to scenario 1-4	default 1	Page 50
P610E	High zone 2 tamper alarms mapped to scenario 1-4	default 1	Page 50
P611E	High zone 3 tamper alarms mapped to scenario 1-4	default 1	Page 50
P612E	High zone 4 tamper alarms mapped to scenario 1-4	default 1	Page 50
P613E	High zone 5 tamper alarms mapped to scenario 1-4	default 1	Page 50
P614E	High zone 6 tamper alarms mapped to scenario 1-4	default 1	Page 50
P615E	High zone 7 tamper alarms mapped to scenario 1-4	default 1	Page 50
P616E	High zone 8 tamper alarms mapped to scenario 1-4	default 1	Page 50

Enrolling Radio Detectors (Zones 1-16)-see also P444E & P464E Addresses

P620E 1-16E	Enrol Radio Detector Zones 1-16	Page 36
--------------------	---------------------------------	---------

Radio Zone Detector Options

P621E	Options for Zone # 1 (Default= 0)	P621E-P636E Options	Page 36
P622E	Options for Zone # 2 (Default= 0)	1 = Crow AE Series Battery low	
P623E	Options for Zone # 3 (Default= 0)	2 = Crow AE Radio Reed Switch	
P624E	Options for Zone # 4 (Default= 0)	3 = Crow Merlin PIR (Non-supervised)	
P625E	Options for Zone # 5 (Default= 0)	4 = Crow Merlin PIR (supervised signal active)	
P626E	Options for Zone # 6 (Default= 0)	5 = Crow Fremlink (supervise sig. active)	
P627E	Options for Zone # 7 (Default= 0)	6 = Crow Fremlink (supervise sig. ignored)	
P628E	Options for Zone # 8 (Default= 0)	11 = Ness Devices battery Low	
P629E	Options for Zone # 9 (Default= 0)	12 = Ness Radio Reed Switch	
P630E	Options for Zone # 10 (Default= 0)	21 = Electronics Line Radio PIR	
P631E	Options for Zone # 11 (Default= 0)	31 = Visonic K900 Radio PIR	
P632E	Options for Zone # 12 (Default= 0)	32 = Visonic Powercode (supervised signal ignored)	
P633E	Options for Zone # 13 (Default= 0)	33 = Visonic Powercode (supervised signal active)	
P634E	Options for Zone # 14 (Default= 0)		
P635E	Options for Zone # 15 (Default= 0)		
P636E	Options for Zone # 16 (Default= 0)		

Enrolling Radio Keys

P640E 1-20E	Enrol Radio Users 1-20	Page 37
--------------------	------------------------	---------

Radio Key Type

P641E	Radio user #1 Type - Default 0	P641E - P660E OPTIONS	Page 37
P642E	Radio user #2 Type - Default 0	0 = Non-specific	Page 37
P643E	Radio user #3 Type - Default 0	1 = Crow	Page 37
P644E	Radio user #4 Type - Default 0	21 = Ness	Page 37
P645E	Radio user #5 Type - Default 0	31 = Visonic	Page 37
P646E	Radio user #6 Type - Default 0		Page 37
P647E	Radio user #7 Type - Default 0		Page 37
P648E	Radio user #8 Type - Default 0		Page 37
P649E	Radio user #9 Type - Default 0		Page 37
P650E	Radio user #10 Type - Default 0		Page 37
P651E	Radio user #11 Type - Default 0		Page 37
P652E	Radio user #12 Type - Default 0		Page 37
P653E	Radio user #13 Type - Default 0		Page 37
P654E	Radio user #14 Type - Default 0		Page 37
P655E	Radio user #15 Type - Default 0		Page 37
P656E	Radio user #16 Type - Default 0		Page 37
P657E	Radio user #17 Type - Default 0		Page 37
P658E	Radio user #18 Type - Default 0		Page 37
P659E	Radio user #19 Type - Default 0		Page 37
P660E	Radio user #20 Type - Default 0		Page 37

Radio Key Options 1st Set

P661E	Radio user #1 options - Default 1,4,5	
P662E	Radio user #2 options - Default 1,4,5	
P663E	Radio user #3 options - Default 1,4,5	
P664E	Radio user #4 options - Default 1,4,5	
P665E	Radio user #5 options - Default 1,4,5	
P666E	Radio user #6 options - Default 1,4,5	
P667E	Radio user #7 options - Default 1,4,5	
P668E	Radio user #8 options - Default 1,4,5	
P669E	Radio user #9 options - Default 1,4,5	
P670E	Radio user #10 options - Default 1,4,5	
P671E	Radio user #11 options - Default 1,4,5	
P672E	Radio user #12 options - Default 1,4,5	
P673E	Radio user #13 options - Default 1,4,5	
P674E	Radio user #14 options - Default 1,4,5	
P675E	Radio user #15 options - Default 1,4,5	
P676E	Radio user #16 options - Default 1,4,5	
P677E	Radio user #17 options - Default 1,4,5	
P678E	Radio user #18 options - Default 1,4,5	
P679E	Radio user #19 options - Default 1,4,5	
P680E	Radio user #20 options - Default 1,4,5	

P661E - P680E OPTIONS		
1 = Area "A" permission		Page 37
2 = Area "B" permission		Page 37
3 = Area "C" permission		Page 37
4 = User can arm		Page 37
5 = User can disarm		Page 37
6 = User can Arm Stay Mode		Page 37
7 = User can Disarm Stay Mode		Page 37
8 = User disabled if in alarm		Page 37

Radio Key Options 2nd Set

P681E	Radio user #1 options - Default 0	
P682E	Radio user #2 options - Default 0	
P683E	Radio user #3 options - Default 0	
P684E	Radio user #4 options - Default 0	
P685E	Radio user #5 options - Default 0	
P686E	Radio user #6 options - Default 0	
P687E	Radio user #7 options - Default 0	
P688E	Radio user #8 options - Default 0	
P689E	Radio user #9 options - Default 0	
P690E	Radio user #10 options - Default 0	
P691E	Radio user #11 options - Default 0	
P692E	Radio user #12 options - Default 0	
P693E	Radio user #13 options - Default 0	
P694E	Radio user #14 options - Default 0	
P695E	Radio user #15 options - Default 0	
P696E	Radio user #16 options - Default 0	
P697E	Radio user #17 options - Default 0	
P698E	Radio user #18 options - Default 0	
P699E	Radio user #19 options - Default 0	
P700E	Radio user #20 options - Default 0	

P681E-P700E OPTIONS		Page 38
1 = User turns control on		Page 38
2 = User turns control off		Page 38
3 = User turns output on		Page 38
4 = User turns output off		Page 38
5 = User causes immediate panic		Page 38
6 = User causes delayed panic		Page 38
7 = Spare		Page 38
8 = Spare		Page 38

Mapping Radio Users to Outputs

P701E	Radio user #1 to output 1-8 - Default 0	Page 39
P702E	Radio user #2 to output 1-8 - Default 0	Page 39
P703E	Radio user #3 to output 1-8 - Default 0	Page 39
P704E	Radio user #4 to output 1-8 - Default 0	Page 39
P705E	Radio user #5 to output 1-8 - Default 0	Page 39
P706E	Radio user #6 to output 1-8 - Default 0	Page 39
P707E	Radio user #7 to output 1-8 - Default 0	Page 39
P708E	Radio user #8 to output 1-8 - Default 0	Page 39
P709E	Radio user #9 to output 1-8 - Default 0	Page 39
P710E	Radio user #10 to output 1-8 - Default 0	Page 39
P711E	Radio user #11 to output 1-8 - Default 0	Page 39
P712E	Radio user #12 to output 1-8 - Default 0	Page 39
P713E	Radio user #13 to output 1-8 - Default 0	Page 39
P714E	Radio user #14 to output 1-8 - Default 0	Page 39

P715E	Radio user #15 to output 1-8 - Default 0	Page 39
P716E	Radio user #16 to output 1-8 - Default 0	Page 39
P717E	Radio user #17 to output 1-8 - Default 0	Page 39
P718E	Radio user #18 to output 1-8 - Default 0	Page 39
P719E	Radio user #19 to output 1-8 - Default 0	Page 39
P720E	Radio user #20 to output 1-8 - Default 0	Page 39

**** Contact ID Zone Alarm Code Assignments ****

P721E	Zone 1 activation - default = 130	Page 51
P722E	Zone 2 activation - default = 130	Page 51
P723E	Zone 3 activation - default = 130	Page 51
P724E	Zone 4 activation - default = 130	Page 51
P725E	Zone 5 activation - default = 130	Page 51
P726E	Zone 6 activation - default = 130	Page 51
P727E	Zone 7 activation - default = 130	Page 51
P728E	Zone 8 activation - default = 130	Page 51
P729E	Zone 9 activation - default = 130	Page 51
P730E	Zone 10 activation - default = 130	Page 51
P731E	Zone 11 activation - default = 130	Page 51
P732E	Zone 12 activation - default = 130	Page 51
P733E	Zone 13 activation - default = 130	Page 51
P734E	Zone 14 activation - default = 130	Page 51
P735E	Zone 15 activation - default = 130	Page 51
P736E	Zone 16 activation - default = 130	Page 51

****Keypad Panic Alarm Contact ID Reporting Code****

P737E	Keypad Panic Alarm (& button 1 & 3) Contact ID Code (Default=120)	Page 51
--------------	---	---------

****Keypad Fire Alarm Contact ID Reporting Code****

P738E	Keypad Fire Alarm (button 4 & 6) Contact ID Code (Default=110)	Page 51
--------------	--	---------

****Keypad Medical Alarm Contact ID Reporting Code****

P739E	Keypad Medical Alarm (button 7 & 9) Contact ID Code (Default=100)	Page 51
--------------	---	---------

**** Contact ID Zone Tamper Code Assignments ****

P741E	Zone 1 Tamper activation - default = 137	Page 51
P742E	Zone 2 Tamper activation - default = 137	Page 51
P743E	Zone 3 Tamper activation - default = 137	Page 51
P744E	Zone 4 Tamper activation - default = 137	Page 51
P745E	Zone 5 Tamper activation - default = 137	Page 51
P746E	Zone 6 Tamper activation - default = 137	Page 51
P747E	Zone 7 Tamper activation - default = 137	Page 51
P748E	Zone 8 Tamper activation - default = 137	Page 51
P749E	Zone 9 Tamper activation - default = 137	Page 51
P750E	Zone 10 Tamper activation - default = 137	Page 51
P751E	Zone 11 Tamper activation - default = 137	Page 51
P752E	Zone 12 Tamper activation - default = 137	Page 51
P753E	Zone 13 Tamper activation - default = 137	Page 51
P754E	Zone 14 Tamper activation - default = 137	Page 51
P755E	Zone 15 Tamper activation - default = 137	Page 51
P756E	Zone 16 Tamper activation - default = 137	Page 51

Keypad Panic Alarm Voice Message Mapping *

P757E	Voice message number mapped to panic alarm - default 0	Page 52
--------------	--	---------

****Keypad Fire Alarm Voice Message Mapping ****

P758E	Voice message number mapped to Fire (4&6) alarm - default 0	Page 52
--------------	---	---------

****Keypad Medical Alarm Voice Message Mapping ****

P759E	Voice message number mapped to Medical (7&9) alarm - default 0	Page 52
--------------	--	---------

****Zone Alarm Voice Message Mapping ****

P761E	Voice message number mapped to zone 1 activation - default 1	Page 52
P762E	Voice message number mapped to zone 2 activation - default 1	Page 52
P763E	Voice message number mapped to zone 3 activation - default 1	Page 52
P764E	Voice message number mapped to zone 4 activation - default 1	Page 52

P765E	Voice message number mapped to zone 5 activation - default 1	Page 52
P766E	Voice message number mapped to zone 6 activation - default 1	Page 52
P767E	Voice message number mapped to zone 7 activation - default 1	Page 52
P768E	Voice message number mapped to zone 8 activation - default 1	Page 52
P769E	Voice message number mapped to zone 9 activation - default 1	Page 52
P770E	Voice message number mapped to zone 10 activation - default 1	Page 52
P771E	Voice message number mapped to zone 11 activation - default 1	Page 52
P772E	Voice message number mapped to zone 12 activation - default 1	Page 52
P773E	Voice message number mapped to zone 13 activation - default 1	Page 52
P774E	Voice message number mapped to zone 14 activation - default 1	Page 52
P775E	Voice message number mapped to zone 15 activation - default 1	Page 52
P776E	Voice message number mapped to zone 16 activation - default 1	Page 52
**Arm/Disarm Command Control Status Message Addressing **		
P777E	Start of Status Message for Area "A" Command Control - Default 0	Page 43
P778E	Start of Status Message for Area "B" Command Control - Default 0	Page 43
P779E	Start of Status Message for Area "C" Command Control - Default 0	Page 43
**Output Command Control Status Message Addressing **		
P781E	Start of Status Message for Output #1 Command Control - Default 0	Page 43
P782E	Start of Status Message for Output #2 Command Control - Default 0	Page 43
P783E	Start of Status Message for Output #3 Command Control - Default 0	Page 43
P784E	Start of Status Message for Output #4 Command Control - Default 0	Page 43
P785E	Start of Status Message for Output #5 Command Control - Default 0	Page 43
P786E	Start of Status Message for Output #6 Command Control - Default 0	Page 43
P787E	Start of Status Message for Output #7 Command Control - Default 0	Page 43
P788E	Start of Status Message for Output #8 Command Control - Default 0	Page 43
**Mains & Battery Voice Message Mapping **		
P789E	Voice message number mapped to Mains Failure - default 0	Page 52
P790E	Voice message number mapped to Battery Low - default 0	Page 52

Defining Time Zones

P791E	Time Zone 1 day of the week Default 0	TIME ZONE PROGRAMMING	Page 40
P792E	Time Zone 1 start time - Default 0	DAYS 1 - 7	Page 40
P793E	Time Zone 1 finish time - Default 0	1 = Sunday	Page 40
P794E	Time Zone 2 day of the week - Default 0	2 = Monday	Page 40
P795E	Time Zone 2 start time - Default 0	3 = Tuesday	Page 40
P796E	Time Zone 2 finish time - Default 0	4 = Wednesday	Page 40
P797E	Time Zone 3 day of the week - Default 0	5 = Thursday	Page 40
P798E	Time Zone 3 start time - Default 0	6 = Friday	Page 40
P799E	Time Zone 3 finish time - Default 0	7 = Saturday	Page 40
P800E	Time Zone 4 day of the week - Default 0	8 = Invert time zone	Page 40
P801E	Time Zone 4 start time - Default 0	Times = 0000-2359	Page 40
P802E	Time Zone 4 finish time - Default 0		Page 40
P803E	Time Zone 5 day of the week - Default 0		Page 40
P804E	Time Zone 5 start time - Default 0		Page 40
P805E	Time Zone 5 finish time - Default 0		Page 40
P806E	Time Zone 6 day of the week - Default 0		Page 40
P807E	Time Zone 6 start time - Default 0		Page 40
P808E	Time Zone 6 finish time - Default 0		Page 40
P809E	Time Zone 7 day of the week - Default 0		Page 40
P810E	Time Zone 7 start time - Default 0		Page 40
P811E	Time Zone 7 finish time - Default 0		Page 40
P812E	Time Zone 8 day of the week - Default 0		Page 40
P813E	Time Zone 8 start time - Default 0		Page 40
P814E	Time Zone 8 finish time - Default 0		Page 40
** Test Calls **			
P815E	Test calls for days of the week 1-7 Default = days 1-7		Page 51
P816E	Test call time of the day Default = 2300		Page 51

Programming Daylight saving Adjustments

P817E	Daylight saving start Sunday - Default 1	Page 40
P818E	Daylight saving start month - Default 10	Page 40
P819E	Daylight saving start hour - Default 2	Page 40
P820E	Daylight saving end Sunday - Default 3	Page 40
P821E	Daylight saving end month - Default 3	Page 40
P822E	Daylight saving end hour - Default 2	Page 40

Setting the Real Time Clock

P823E	Set day of the week (1 -7 where 1 = Sunday)	Page 39
P824E	Set time (HHMM)	Page 39
P825E	Set day of the month (1 - 31)	Page 39
P826E	Set month (1 - 12)	Page 39
P827E	Set year	Page 39

** Upload/Download Security Code **

P828E	XXXXXXXX. Up to 8 digit security code	Page 54
--------------	---------------------------------------	---------

Dynamic Data

P830E	Misc system flags	1 = Spare 2 = Spare 3 = Spare 4 = Spare 5=Spare 6=Spare 7=Spare 8=Daylight saving active	Page 41
P831E	Display keyboard address		Page 41
P832E	Display partitions assigned to this keypad (1=A, 2=B, 3=C)		Page 41
P833E	Display software version		Page 41

Printing Events

P834E	Start event printing	Page 41
--------------	----------------------	---------

** Manually Answering an In-coming Call **

P835E	Answer incoming call (user initiated)	Page 54
--------------	---------------------------------------	---------

Walk Test Mode

P836E	Toggle walk-test mode ON/OFF	Page 42
--------------	------------------------------	---------

Temporary Output Disable Mode

P837E	Temporary Output Disable mode - Outputs 1-8	Page 41
--------------	---	---------

EE² Upload/Download

P838E	Write to EE ² board on serial port.	Page 41
P839E	Copy from EE ² board on serial port to panel.	Page 41

Reset to Defaults

P840E	Reset user codes	Page 42
P841E	Reset communicator parameters	Page 42
P842E	Reset radio parameters	Page 42
P843E	Reset PA & Voice Board Parameters	Page 42
P844E	Reset All other Parameters	Page 42
P845E	Reset Everything back to factory Default	Page 42

Clear Output Parameters

P846E	Clear all output parameters (outputs 1 - 8)	Page 41
--------------	---	---------

Clear Memory Events

P847E	Clear the 255 event Memory Buffer	Page 42
P848E	Clear unreported PA events	Page 42

Active Time Zones

P849E	Active Time-Zones	Page 41
--------------	-------------------	---------

PA Board Output ON Message

P851E	PA Board Output #1 On Message - Default 0	
--------------	---	--

P852E PA Board Output #2 On Message - Default 0
P853E PA Board Output #3 On Message - Default 0
P854E PA Board Output #4 On Message - Default 0
P855E PA Board Output #5 On Message - Default 0
P856E PA Board Output #6 On Message - Default 0
P857E PA Board Output #7 On Message - Default 0
P858E PA Board Output #8 On Message - Default 0

PA Board Output OFF Message

P861E PA Board Output #1 Off Message - Default 0
P862E PA Board Output #2 Off Message - Default 0
P863E PA Board Output #3 Off Message - Default 0
P864E PA Board Output #4 Off Message - Default 0
P865E PA Board Output #5 Off Message - Default 0
P866E PA Board Output #6 Off Message - Default 0
P867E PA Board Output #7 Off Message - Default 0
P868E PA Board Output #8 Off Message - Default 0

PA Board Entry Delay Message

P871E PA Board Area "A" Entry Delay Message - Default 0
P872E PA Board Area "B" Entry Delay Message - Default 0
P873E PA Board Area "C" Entry Delay Message - Default 0

PA Board Exit Delay Message

P874E PA Board Area "A" Exit Delay Message - Default 0
P875E PA Board Area "B" Exit Delay Message - Default 0
P876E PA Board Area "C" Exit Delay Message - Default 0

PA Board Armed Message

P877E PA Board Area "A" Armed Message - Default 0
P878E PA Board Area "B" Armed Message - Default 0
P879E PA Board Area "C" Armed Message - Default 0

PA Board Stay Mode Armed Message

P881E PA Board Area "A" Stay Mode Armed Message - Default 0
P882E PA Board Area "B" Stay Mode Armed Message - Default 0
P883E PA Board Area "C" Stay Mode Armed Message - Default 0

PA Board Disarmed Message

P884E PA Board Area "A" Disarmed Message - Default 0
P885E PA Board Area "B" Disarmed Message - Default 0
P886E PA Board Area "C" Disarmed Message - Default 0

PA Board Door Open Too Long (DOTL) Message

P887E PA Board Area "A" DOTL Message - Default 0
P888E PA Board Area "B" DOTL Message - Default 0
P889E PA Board Area "C" DOTL Message - Default 0

** PA Board Zone Alarm Message **

P891E Zone 1 Alarm PA Board Message default 0
P892E Zone 2 Alarm PA Board Message default 0
P893E Zone 3 Alarm PA Board Message default 0
P894E Zone 4 Alarm PA Board Message default 0
P895E Zone 5 Alarm PA Board Message default 0
P896E Zone 6 Alarm PA Board Message default 0
P897E Zone 7 Alarm PA Board Message default 0
P898E Zone 8 Alarm PA Board Message default 0
P899E Zone 9 Alarm PA Board Message default 0
P900E Zone 10 Alarm PA Board Message default 0
P901E Zone 11 Alarm PA Board Message default 0
P902E Zone 12 Alarm PA Board Message default 0
P903E Zone 13 Alarm PA Board Message default 0
P904E Zone 14 Alarm PA Board Message default 0
P905E Zone 15 Alarm PA Board Message default 0
P906E Zone 16 Alarm PA Board Message default 0

**** Miscellaneous PA Board Alarm Message ****

P907E Mains Failure PA Board Message default 0
P908E Battery Low PA Board Message default 0
P909E System Tamper Alarm PA Board Message default 0
P910E Zone Tamper Alarm PA Board Message default 0
P911E Radio Pendant Panic Alarm PA Board Message default 0
P912E Keypad Panic Alarm PA Board Message default 0
P913E Keypad Fire Alarm PA Board Message default 0
P914E Keypad Medical Alarm PA Board Message default 0

****System Tamper 4+2 Reporting Code****

P921E 4+2 Alarm Code for System Tamper (Default=86) Page 54

****System Tamper Restore 4+2 Reporting Code****

P922E 4+2 Alarm Code for System Tamper Restore (Default=87) Page 54

****Armed by "Arm" Button 4+2 Reporting Code****

P923E 4+2 Arm by "Arm" Button or Key-switch Code (Default=81) Page 54

****Single button or key-switch disarm 4+2 Reporting Code****

P924E 4+2 Disarm by Arm or Stay Button or Key-switch (Default=83) Page 54

****Stay Mode Arming 4+2 Reporting Code****

P925E 4+2 Stay Mode Arming Code (Default=82) Page 54

****Low Battery 4+2 Reporting Codes****

P926E Low Battery 4+2 Code (Default=94) Page 54

P927E Low Battery Restore 4+2 Code (Default=96) Page 54

****Mains Failure 4+2 Restore Codes****

P928E Mains Failure 4+2 Code (Default=95) Page 54

P929E Mains Failure restore 4+2 Code (Default=97) Page 54

****Panic Alarm 4+2 Reporting Codes****

P930E Manual Panic Alarm 4+2 Code (Default=88) Page 54

P931E Manual Panic Alarm Restore 4+2 Code (Default=91) Page 54

****Fire Alarm 4+2 Reporting Codes****

P932E Manual Fire Alarm 4+2 Code (Default=89) Page 54

P933E Manual Fire Alarm Restore 4+2 Code (Default=92) Page 54

****Medical Alarm 4+2 Reporting Codes****

P934E Manual Medical Alarm 4+2 Code (Default=90) Page 54

P935E Manual Medical Alarm Restore 4+2 Code (Default=93) Page 54

****Duress Alarm 4+2 Reporting Code****

P936E 4+2 Duress Alarm Code (Default=84) Page 54

****Automatic Test 4+2 Reporting Code****

P937E 4+2 Automatic Test Code (Default=85) Page 54

****Zone Alarm 4+2 Reporting Code****

P941E 4+2 Alarm Code for Zone 1 (Default=01) Page 54

P942E 4+2 Alarm Code for Zone 2 (Default=02) Page 54

P943E 4+2 Alarm Code for Zone 3 (Default=03) Page 54

P944E 4+2 Alarm Code for Zone 4 (Default=04) Page 54

P945E 4+2 Alarm Code for Zone 5 (Default=05) Page 54

P946E 4+2 Alarm Code for Zone 6 (Default=06) Page 54

P947E 4+2 Alarm Code for Zone 7 (Default=07) Page 54

P948E 4+2 Alarm Code for Zone 8 (Default=08) Page 54

P949E 4+2 Alarm Code for Zone 9 (Default=09) Page 54

P950E 4+2 Alarm Code for Zone 10 (Default=01) Page 54

P951E 4+2 Alarm Code for Zone 11 (Default=02) Page 54

P952E 4+2 Alarm Code for Zone 12 (Default=03) Page 54

P953E 4+2 Alarm Code for Zone 13 (Default=04) Page 54

P954E 4+2 Alarm Code for Zone 14 (Default=05) Page 54

P955E	4+2 Alarm Code for Zone 15 (Default=06)	Page 54
P956E	4+2 Alarm Code for Zone 16 (Default=07)	Page 54

****Zone Alarm Restore 4+2 Reporting Code****

P961E	4+2 Alarm Restore Code for Zone 1 (Default=11)	Page 54
P962E	4+2 Alarm Restore Code for Zone 2 (Default=12)	Page 54
P963E	4+2 Alarm Restore Code for Zone 3 (Default=13)	Page 54
P964E	4+2 Alarm Restore Code for Zone 4 (Default=14)	Page 54
P965E	4+2 Alarm Restore Code for Zone 5 (Default=15)	Page 54
P966E	4+2 Alarm Restore Code for Zone 6 (Default=16)	Page 54
P967E	4+2 Alarm Restore Code for Zone 7 (Default=17)	Page 54
P968E	4+2 Alarm Restore Code for Zone 8 (Default=18)	Page 54
P969E	4+2 Alarm Restore Code for Zone 9 (Default=19)	Page 54
P970E	4+2 Alarm Restore Code for Zone 10 (Default=11)	Page 54
P971E	4+2 Alarm Restore Code for Zone 11 (Default=12)	Page 54
P972E	4+2 Alarm Restore Code for Zone 12 (Default=13)	Page 54
P973E	4+2 Alarm Restore Code for Zone 13 (Default=14)	Page 54
P974E	4+2 Alarm Restore Code for Zone 14 (Default=15)	Page 54
P975E	4+2 Alarm Restore Code for Zone 15 (Default=16)	Page 54
P976E	4+2 Alarm Restore Code for Zone 16 (Default=17)	Page 54

****Zone Bypassed 4+2 Reporting Code****

P981E	4+2 Bypass Message for Zone 1 (Default=21)	Page 54
P982E	4+2 Bypass Message for Zone 2 (Default=22)	Page 54
P983E	4+2 Bypass Message for Zone 3 (Default=23)	Page 54
P984E	4+2 Bypass Message for Zone 4 (Default=24)	Page 54
P985E	4+2 Bypass Message for Zone 5 (Default=25)	Page 54
P986E	4+2 Bypass Message for Zone 6 (Default=26)	Page 54
P987E	4+2 Bypass Message for Zone 7 (Default=27)	Page 54
P988E	4+2 Bypass Message for Zone 8 (Default=28)	Page 54
P989E	4+2 Bypass Message for Zone 9 (Default=29)	Page 54
P990E	4+2 Bypass Message for Zone 10 (Default=30)	Page 54
P991E	4+2 Bypass Message for Zone 11 (Default=21)	Page 54
P992E	4+2 Bypass Message for Zone 12 (Default=22)	Page 54
P993E	4+2 Bypass Message for Zone 13 (Default=23)	Page 54
P994E	4+2 Bypass Message for Zone 14 (Default=24)	Page 54
P995E	4+2 Bypass Message for Zone 15 (Default=25)	Page 54
P996E	4+2 Bypass Message for Zone 16 (Default=26)	Page 54

****Zone Bypassed 4+2 Restore Code****

P1001E	4+2 Bypass Restore Message for Zone 1 (Default=31)	Page 54
P1002E	4+2 Bypass Restore Message for Zone 2 (Default=32)	Page 54
P1003E	4+2 Bypass Restore Message for Zone 3 (Default=33)	Page 54
P1004E	4+2 Bypass Restore Message for Zone 4 (Default=34)	Page 54
P1005E	4+2 Bypass Restore Message for Zone 5 (Default=35)	Page 54
P1006E	4+2 Bypass Restore Message for Zone 6 (Default=36)	Page 54
P1007E	4+2 Bypass Restore Message for Zone 7 (Default=37)	Page 54
P1008E	4+2 Bypass Restore Message for Zone 8 (Default=38)	Page 54
P1009E	4+2 Bypass Restore Message for Zone 9 (Default=39)	Page 54
P1010E	4+2 Bypass Restore Message for Zone 10 (Default=40)	Page 54
P1011E	4+2 Bypass Restore Message for Zone 11 (Default=31)	Page 54
P1012E	4+2 Bypass Restore Message for Zone 12 (Default=32)	Page 54
P1013E	4+2 Bypass Restore Message for Zone 13 (Default=33)	Page 54
P1014E	4+2 Bypass Restore Message for Zone 14 (Default=34)	Page 54
P1015E	4+2 Bypass Restore Message for Zone 15 (Default=35)	Page 54
P1016E	4+2 Bypass Restore Message for Zone 16 (Default=36)	Page 54

****Armed by User # 4+2 Reporting Code****

P1021E	4+2 Arm Code for User 1 (Default=41)	Page 54
P1022E	4+2 Arm Code for User 2 (Default=42)	Page 54
P1023E	4+2 Arm Code for User 3 (Default=43)	Page 54
P1024E	4+2 Arm Code for User 4 (Default=44)	Page 54
P1025E	4+2 Arm Code for User 5 (Default=45)	Page 54
P1026E	4+2 Arm Code for User 6 (Default=46)	Page 54
P1027E	4+2 Arm Code for User 7 (Default=47)	Page 54

P1028E 4+2 Arm Code for User 8 (Default=48)	Page 54
P1029E 4+2 Arm Code for User 9 (Default=49)	Page 54
P1030E 4+2 Arm Code for User 10 (Default=50)	Page 54
P1031E 4+2 Arm Code for User 11 (Default=41)	Page 54
P1032E 4+2 Arm Code for User 12 (Default=42)	Page 54
P1033E 4+2 Arm Code for User 13 (Default=43)	Page 54
P1034E 4+2 Arm Code for User 14 (Default=44)	Page 54
P1035E 4+2 Arm Code for User 15 (Default=45)	Page 54
P1036E 4+2 Arm Code for User 16 (Default=46)	Page 54
P1037E 4+2 Arm Code for User 17 (Default=47)	Page 54
P1038E 4+2 Arm Code for User 18 (Default=48)	Page 54
P1039E 4+2 Arm Code for User 19 (Default=49)	Page 54
P1040E 4+2 Arm Code for User 20 (Default=50)	Page 54
P1041E 4+2 Arm Code for User 21 (Default=41)	Page 54
P1042E 4+2 Arm Code for User 22 (Default=42)	Page 54
P1043E 4+2 Arm Code for User 23 (Default=43)	Page 54
P1044E 4+2 Arm Code for User 24 (Default=44)	Page 54
P1045E 4+2 Arm Code for User 25 (Default=45)	Page 54
P1046E 4+2 Arm Code for User 26 (Default=46)	Page 54
P1047E 4+2 Arm Code for User 27 (Default=47)	Page 54
P1048E 4+2 Arm Code for User 28 (Default=48)	Page 54
P1049E 4+2 Arm Code for User 29 (Default=49)	Page 54
P1050E 4+2 Arm Code for User 30 (Default=50)	Page 54
P1051E 4+2 Arm Code for User 31 (Default=41)	Page 54
P1052E 4+2 Arm Code for User 32 (Default=42)	Page 54
P1053E 4+2 Arm Code for User 33 (Default=43)	Page 54
P1054E 4+2 Arm Code for User 34 (Default=44)	Page 54
P1055E 4+2 Arm Code for User 35 (Default=45)	Page 54
P1056E 4+2 Arm Code for User 36 (Default=46)	Page 54
P1057E 4+2 Arm Code for User 37 (Default=47)	Page 54
P1058E 4+2 Arm Code for User 38 (Default=48)	Page 54
P1059E 4+2 Arm Code for User 39 (Default=49)	Page 54
P1060E 4+2 Arm Code for User 40 (Default=50)	Page 54
P1061E 4+2 Arm Code for User 41 (Default=41)	Page 54
P1062E 4+2 Arm Code for User 42 (Default=42)	Page 54
P1063E 4+2 Arm Code for User 43 (Default=43)	Page 54
P1064E 4+2 Arm Code for User 44 (Default=44)	Page 54
P1065E 4+2 Arm Code for User 45 (Default=45)	Page 54
P1066E 4+2 Arm Code for User 46 (Default=46)	Page 54
P1067E 4+2 Arm Code for User 47 (Default=47)	Page 54
P1068E 4+2 Arm Code for User 48 (Default=48)	Page 54
P1069E 4+2 Arm Code for User 49 (Default=49)	Page 54
P1070E 4+2 Arm Code for User 50 (Default=50)	Page 54

****Disarmed by User # 4+2 Reporting Code****

P1071E 4+2 Disarm Code for User 1 (Default=51)	Page 54
P1072E 4+2 Disarm Code for User 2 (Default=52)	Page 54
P1073E 4+2 Disarm Code for User 3 (Default=53)	Page 54
P1074E 4+2 Disarm Code for User 4 (Default=54)	Page 54
P1075E 4+2 Disarm Code for User 5 (Default=55)	Page 54
P1076E 4+2 Disarm Code for User 6 (Default=56)	Page 54
P1077E 4+2 Disarm Code for User 7 (Default=57)	Page 54
P1078E 4+2 Disarm Code for User 8 (Default=58)	Page 54
P1079E 4+2 Disarm Code for User 9 (Default=59)	Page 54
P1080E 4+2 Disarm Code for User 10 (Default=60)	Page 54
P1081E 4+2 Disarm Code for User 11 (Default=51)	Page 54
P1082E 4+2 Disarm Code for User 12 (Default=52)	Page 54
P1083E 4+2 Disarm Code for User 13 (Default=53)	Page 54
P1084E 4+2 Disarm Code for User 14 (Default=54)	Page 54
P1085E 4+2 Disarm Code for User 15 (Default=55)	Page 54
P1086E 4+2 Disarm Code for User 16 (Default=56)	Page 54
P1087E 4+2 Disarm Code for User 17 (Default=57)	Page 54
P1088E 4+2 Disarm Code for User 18 (Default=58)	Page 54
P1089E 4+2 Disarm Code for User 19 (Default=59)	Page 54
P1090E 4+2 Disarm Code for User 20 (Default=60)	Page 54

P1091E	4+2 Disarm Code for User 21 (Default=51)	Page 54
P1092E	4+2 Disarm Code for User 22 (Default=52)	Page 54
P1093E	4+2 Disarm Code for User 23 (Default=53)	Page 54
P1094E	4+2 Disarm Code for User 24 (Default=54)	Page 54
P1095E	4+2 Disarm Code for User 25 (Default=55)	Page 54
P1096E	4+2 Disarm Code for User 26 (Default=56)	Page 54
P1097E	4+2 Disarm Code for User 27 (Default=57)	Page 54
P1098E	4+2 Disarm Code for User 28 (Default=58)	Page 54
P1099E	4+2 Disarm Code for User 29 (Default=59)	Page 54
P1100E	4+2 Disarm Code for User 30 (Default=60)	Page 54
P1101E	4+2 Disarm Code for User 31 (Default=54)	Page 54
P1102E	4+2 Disarm Code for User 32 (Default=52)	Page 54
P1103E	4+2 Disarm Code for User 33 (Default=53)	Page 54
P1104E	4+2 Disarm Code for User 34 (Default=54)	Page 54
P1105E	4+2 Disarm Code for User 35 (Default=55)	Page 54
P1106E	4+2 Disarm Code for User 36 (Default=56)	Page 54
P1107E	4+2 Disarm Code for User 37 (Default=57)	Page 54
P1108E	4+2 Disarm Code for User 38 (Default=58)	Page 54
P1109E	4+2 Disarm Code for User 39 (Default=59)	Page 54
P1110E	4+2 Disarm Code for User 40 (Default=60)	Page 54
P1111E	4+2 Disarm Code for User 41 (Default=54)	Page 54
P1112E	4+2 Disarm Code for User 42 (Default=52)	Page 54
P1113E	4+2 Disarm Code for User 43 (Default=53)	Page 54
P1114E	4+2 Disarm Code for User 44 (Default=54)	Page 54
P1115E	4+2 Disarm Code for User 45 (Default=55)	Page 54
P1116E	4+2 Disarm Code for User 46 (Default=56)	Page 54
P1117E	4+2 Disarm Code for User 47 (Default=57)	Page 54
P1118E	4+2 Disarm Code for User 48 (Default=58)	Page 54
P1119E	4+2 Disarm Code for User 49 (Default=59)	Page 54
P1120E	4+2 Disarm Code for User 50 (Default=60)	Page 54

****Armed by Radio Pendant User # 4+2 Reporting Code****

P1121E	4+2 Arm Code for Radio User 1 (Default=61)	Page 54
P1122E	4+2 Arm Code for Radio User 2 (Default=62)	Page 54
P1123E	4+2 Arm Code for Radio User 3 (Default=63)	Page 54
P1124E	4+2 Arm Code for Radio User 4 (Default=64)	Page 54
P1125E	4+2 Arm Code for Radio User 5 (Default=65)	Page 54
P1126E	4+2 Arm Code for Radio User 6 (Default=66)	Page 54
P1127E	4+2 Arm Code for Radio User 7 (Default=67)	Page 54
P1128E	4+2 Arm Code for Radio User 8 (Default=68)	Page 54
P1129E	4+2 Arm Code for Radio User 9 (Default=69)	Page 54
P1130E	4+2 Arm Code for Radio User 10 (Default=70)	Page 54
P1131E	4+2 Arm Code for Radio User 11 (Default=61)	Page 54
P1132E	4+2 Arm Code for Radio User 12 (Default=62)	Page 54
P1133E	4+2 Arm Code for Radio User 13 (Default=63)	Page 54
P1134E	4+2 Arm Code for Radio User 14 (Default=64)	Page 54
P1135E	4+2 Arm Code for Radio User 15 (Default=65)	Page 54
P1136E	4+2 Arm Code for Radio User 16 (Default=66)	Page 54
P1137E	4+2 Arm Code for Radio User 17 (Default=67)	Page 54
P1138E	4+2 Arm Code for Radio User 18 (Default=68)	Page 54
P1139E	4+2 Arm Code for Radio User 19 (Default=69)	Page 54
P1140E	4+2 Arm Code for Radio User 20 (Default=70)	Page 54

****Disarmed by Radio Pendant User # 4+2 Reporting Code****

P1141E	4+2 Disarm Code for Radio User 1 (Default=71)	Page 54
P1142E	4+2 Disarm Code for Radio User 2 (Default=72)	Page 54
P1143E	4+2 Disarm Code for Radio User 3 (Default=73)	Page 54
P1144E	4+2 Disarm Code for Radio User 4 (Default=74)	Page 54
P1145E	4+2 Disarm Code for Radio User 5 (Default=75)	Page 54
P1146E	4+2 Disarm Code for Radio User 6 (Default=76)	Page 54
P1147E	4+2 Disarm Code for Radio User 7 (Default=77)	Page 54
P1148E	4+2 Disarm Code for Radio User 8 (Default=78)	Page 54
P1149E	4+2 Disarm Code for Radio User 9 (Default=79)	Page 54
P1150E	4+2 Disarm Code for Radio User 10 (Default=80)	Page 54
P1154E	4+2 Disarm Code for Radio User 11 (Default=71)	Page 54
P1152E	4+2 Disarm Code for Radio User 12 (Default=72)	Page 54

P1153E 4+2 Disarm Code for Radio User 13 (Default=73)	Page 54
P1154E 4+2 Disarm Code for Radio User 14 (Default=74)	Page 54
P1155E 4+2 Disarm Code for Radio User 15 (Default=75)	Page 54
P1156E 4+2 Disarm Code for Radio User 16 (Default=76)	Page 54
P1157E 4+2 Disarm Code for Radio User 17 (Default=77)	Page 54
P1158E 4+2 Disarm Code for Radio User 18 (Default=78)	Page 54
P1159E 4+2 Disarm Code for Radio User 19 (Default=79)	Page 54
P1160E 4+2 Disarm Code for Radio User 20 (Default=80)	Page 54

DIALLER INSTALLATION

The dialler facility of the Elite controller has been designed to provide optimum flexibility in the way in which alarm events are reported. This flexibility includes options for reporting to a central monitoring station using Contact ID format, a domestic reporting option using alternating siren tones, a format for reporting alarms to an alpha numeric pager and a powerful speech dialler.


In accordance with the statutory requirements of the Telepermit standards we must bring the following points to your attention;

A readily accessible disconnect device shall be incorporated into the 230V fixed wiring.

In the event of any problem with this device, the by-pass switch should be operated. The user is to then arrange with the installer of the device to make the necessary repairs. Should the matter be reported to Telecom as a wiring fault, and the fault be proven to be due to the alarm panel, a call out charge will be incurred.

Should the Elite control panel require relocation the Telecom connection must be disconnected before the power is disconnected. Similarly when reconnecting the dialler, it is necessary to power up the Elite before connecting the dialler to the Telecom Network.

Connection to the Telecom network should be made in accordance with Access Standards Newsletter #65 dated November 1993. This connection is to be readily accessible to allow disconnection in the event of a fault. An example of this connection method is shown below.



NOTE: *The telephone line must not enter the cabinet through the same cable entry hole as any 230 volt mains cables. A separate cable entry must be used for 230 volt cabling*

When using one of the knock-outs around the side of the cabinet for supply entry, a suitable bushing must be used where the supply cables pass through a knock-out.

The transmit level from this device is set at a fixed level and because of this there may be circumstances where this device does not give its optimum performance. Before reporting such occurrences as faults, please check the line with a standard Telepermitted telephone, and do not report a fault unless the telephone performance is impaired.

This automatic dialling equipment shall not be set up to make calls to the Telecom "111" Emergency Service

CONTACT ID CODE SUMMARY

In addition to the programmable Contact ID Event Code assignments defined at P721E - P756E there are a number of fixed event codes. The programmable and fixed event codes are all listed in the table below. Associated with the fixed and programmable event codes, there are a number of extension codes, that are also listed below. This extensions list is for your reference only and can not be changed in programming.

Event	Code	Extension	Comment
Cabinet Tamper	137	120	Panel & Sat Tamper etc
Zone Tamper - Low (short circuit)	137	001 to 008	Zones 1-8
Zone Tamper - High (open circuit)	137	009 to 016	Zones 1-8
**Keypad Tamper (Wrong Code)	137	101	At keypad #1
	through to	108	At keypad #8
**Keypad Panic	120	101	At keypad #1
	through to	108	At keypad #8
**Keypad Medical	100	101	At keypad #1
	through to	108	At keypad #8
**Keypad Fire	110	101	At keypad #1
	through to	108	At keypad #8
**Duress Alarm	121	001	At keypad #1
	through to	108	At keypad #8
Arm by "ARM key (shortcut)	408	000	User number zero
Arm by user code	401	001	User #1
		002	User #2
	through to	024	user #24
Arm by Radio-key	407	001	Radio User #1
		002	Radio User #2
	through to	020	Radio User #20
Arm by Time Zone	403	000	Time Zone arming
Arm by Key-switch	409	001	Key-switch Arm/Disarm KS#1
Arm by Key-switch	409	002	Key-switch Arm/Disarm KS#2
Arm by Up/Download	400	000	
Arm by DTMF remote control	400	000	
Radio-key Panic	120	001	Radio User #1
	through to	020	Radio User #20
Radio PIR / Reed Switch Activation	130	001	Zone 1
		002	Zone 2
	through to	016	Zone 16
System Battery Low	302	000	Control Panel Battery low
Mains Fail	301	000	230v mains to control panel lost
12V Supply fuse Fail	312	000	12V Fuse F1 or F2 blown
Radio PIR / Reed Switch Battery Low	384	001	Zone 1
		002	Zone 2
	through to	016	Zone 16
Radio-key Battery Low	384	021	Radio-key #1
		022	Radio-key #2
	through to	040	Radio-key #20
Radio Zone Supervised Failure	381	001	Radio Zone #1
	through to	016	Radio Zone #16
Zone Inactivity Alarm	391	001	Zone #1
	through to	016	Zone #16
TEST Calls	602	000	24 hour test
Zone Bypasses	570	001	Bypass Zone 1
	through to	016	Bypass Zone 16
Phone Line Failure	351	000	Reported when line is restored
Stay Mode (part set)	441	000	Arm by "Stay" Button
		001	User 1
	through to	024	User 24
Stay Mode by Key-switch (part set)	442	001	"Stay" mode Arm by K/S #1
		002	"Stay" mode Arm by K/S #2

** - Note: On some versions of the panel the keypad number is not sent (ie Extension ="000") to satisfy some monitoring companies

New Features Added in at software version V6.27

- 1) At address P370E, option 6 that was spare is now used to allow for longer duration dialling tones. If option 6 is off, the DTMF tone length during dialling the telephone numbers is 75ms. If option 6 is turned on, the DTMF tone duration will be 100ms during the dialling of the telephone numbers.
- 2) At addresses P343-P348E, option 7 that was spare is now used to allow for Domestic alarm reports via the dialler to be automatically kissed off. If option 7 is off, all events in domestic dial reporting must be kissed off with a non-repetitive tone as it has always been. The problem is that sometimes noise on the line can be seen as a kiss off tone. Where noise is a potential problem, by turning on option 7, the panel will not be looking for a kiss off tone, but will instead send the alarm report to the maximum number of re-tries set then automatically kiss off the event. This ensures all domestic alarms will get reported to the intended numbers and will not get accidentally kissed off by noise. For this function to work however, the alarm event has to be sent. If call progress is turned on and the number is either engaged or unanswered, the alarm event will not be sent. To allow the automatic kiss off to work properly, call progress should be turned off for domestic alarm reporting telephone numbers.
- 3) If option 7 above is turned off, meaning that domestic alarm reports can be kissed off by a non-repetitive tone, you can now fit a DTMF board to the panel, and if fitted, all domestic alarm reports will ONLY be kissed off by a valid DTMF tone. By adding the DTMF board to the panel, and leaving option 7 at addresses P343-348E off, the events can still be kissed off stopping any further reports, but they will not be kissed off by noise now.

New Features Added in at software version V6.29 (July 2003)

- 1) If a zone tamper alarm is generated (when Zone Doubling is selected) the panel will now also cause the associated zone to be in alarm as well e.g. if a short circuit tamper occurs on zone # 1, zone #1 tamper and zone # 1 alarms will be generated, if the tamper was an open circuit on the same input, a zone # 9 tamper and a zone # 9 alarm will be generated. This does two things, if the panel cannot be armed if a zone is unsealed, the panel will not be in the "Ready" state if a tamper alarm is present (because the associated zone is unsealed as well) so arming will be inhibited, plus, if a zone is tampered with in Domestic or Voice reporting modes, a zone alarm will be sent alerting the owner to the tamper alarm.
- 2) If the panel cannot be armed because a zone is unsealed ("Arm Only if Sealed/Ready" is selected P301E, P401E, P501E option 1 On) when doing a Command control arm the panel would return an arm status even though the panel did not arm. This has been fixed in this version. If the panel cannot be armed and an Arm is attempted, the panel will return the disarm message.
- 3) The same auto-kissoff option 7 at addresses P343-P348E was extended to include Voice reporting mode as well.
- 4) If a zone is bypassed and that input is zone doubled, the associated zone tamper is bypassed at the same time e.g. If zone 1 was bypassed, the short circuit zone 1 tamper will be bypassed as well. If zone 9 was bypassed, the open circuit zone 9 tamper will be bypassed.

New Features Added in at software version V6.34 (June 2005)

- 1) For Europe there is a requirement to restrict access to memory mode to authorised users only. This has been achieved by adding a new option at address P311E. If Option 6 is ON it will restrict access to memory mode. The user must press <MEMORY> <CODE> <ENTER> to access memory mode. If option 6 is OFF, memory mode can be accessed by simply pressing the <MEMORY> button.
- 2) To increase the life of smaller batteries during an AC fail when using an LCD keypad a new option has been added at address P311E. If Option 7 is ON the LCD module and the LCD keypad backlighting will turn off during an AC fail. If any button is pressed on the keypad during an AC fail all backlighting will turn on for a period of approximately 45 seconds then turn off again. When the AC returns all backlighting will return to normal automatically.
- 3) During an alarm on a zone the keypad buzzer can sound during the alarm state. This audible alarm indication normally continues until the alarm is disarmed. To allow the buzzer to reset after a programmed time period the keypad alarm buzzer has been linked to output 1. When the reset timer for output 1 expires, the alarm to the keypad buzzer will also reset.

INSTALLER NOTES