



videofied®

Made by RSI VIDEO TECHNOLOGIES

Complete Setup and Programming Guide for XT-IP and XTO-IP Control Panels



A Videofied CMA/XMA/WMB Alphabetic Keypad or Frontel TMT2 is required for programming and maintenance



CMA



XMA



WMB

Table of Contents

	Page
FCC	3
Installation Guidelines	4
Introduction	5
Initial Programming	6-17
Device Installation	18
Entering Badges and Access Codes	19-20
Choosing Siren Options	20
Disabling Monitoring	21
Ethernet Parameters and Testing	22
Testing 2G3G Level and Error Codes List	23
Enabling External RF Antenna	24
Testing Device RF Level	25
Connecting a 2G3G Antenna	26
XTIP Power Chart	26
Arming Input Wiring Diagram	27
Testing to Central Station	28
Mounting XT/XTX	29
Mounting XTO	29-31
Additional Application Notes	31
Troubleshooting	32-34
After Initial Programming Flow Chart	35-37
Addendum	38-40
Battery Specifications	38
Finding Manufacture Week/Year	39
Event Log Ethernet Codes	39
Additional System Quick Codes	39
Replacing Device and Control Panel batteries	40
Checking Control Panel Firmware	40

Regulatory Information for USA and Canada

FCC Part 15.21 *Changes or modifications made to this equipment not expressly approved by RSI Video Technologies may void the FCC authorization to operate this equipment.*

FCC Part 15.105 Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- *Reorient or relocate the receiving antenna.*
- *Increase the separation between the equipment and receiver.*
- *Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- *Consult the dealer or an experienced radio/TV technician for help.*

Radiofrequency radiation exposure information according 2.1091 / 2.1093 / OET bulletin 65

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and*
- (2) this device must accept any interference received, including interference that may cause undesired operation.*

Cet appareil est conforme à la Partie 15 des réglementations de la FCC et avec la norme RSS-210 de l'Industrie Canadienne.

Son fonctionnement est soumis aux deux conditions suivantes :

- (1) Cet appareil ne doit pas causer d'interférences nuisibles et*
- (2) Cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.*

Basic Setup Guidelines for Installation and Programming

Pre-Setup

- 1) Obtain the account number from the Central Station.
- 2) If using Cellular communication for primary or backup, activate the SIM card through your cellular provider.
 - a. **Do these steps at least 1 day before the install.*

System Programming and Setup

- 1) Setup and program the system in the office or in your vehicle. DO NOT MOUNT THE DEVICES. (Pages 6-17)
- 2) Add user codes and or badges after initial programming. (Pages 19-20)
- 3) Disable monitoring so that signals are not sent until you are ready to send them. (Page 21)

Deploying the System on Site

- 1) Place the panel where you want to mount it and run the Ethernet cable. In Maintenance run the ETH. STATUS test to make sure you are receiving an IP. If you are using cellular as backup or primary make sure you get 3/5 or better when running the 2G3G Level Test in maintenance. If not, you will need to move the panel and run the test again.* (Page 23)
- 2) Deploying Devices: Use your keypad to run the RF test for each device. If you get a 9/9 for your RF test on the first device, then mount it. If not, you will need to move the device to get optimal signal.* (Page 25)
 - a. If you are not getting an appropriate 2G3G or RF level, you can add an external antenna for either signal. (Not available for the XL600) Enabling External Antenna: (Page 24)
- 3) Re-enable monitoring before you send signals (Page 21)
 - a. If you are currently using TMT Installer to program the system you can now take still pictures from each MotionViewer using the software. See TMT Installer Users Manual available on <http://support.videofied.com>
- 4) Once you have everything mounted, arm the system and trip one MotionViewer at a time. Make sure you stand in front of each MotionViewer for 10 seconds so the central station has some video to look at. (Page 28)
- 5) After you have sent signals to central station, call to verify.

The following pages will go through each one of these steps and, if you have any issues please consult the troubleshooting section Pages 32-34. If you still cannot resolve the issue, please feel free to call technical support through live support chat and ticket submission at support.videofied.com.

Sleeping mode and Wake-up on the CMA:

They keypad backlight will go out after 30 seconds of inactivity. When you press a button the keypad wakes up. The first touch on the pad that wakes it up will not be a registered command and will only wake up the keypad.

Sleeping mode and wake-up on the XMA/WMB:

The keypad backlight will go out after 30 seconds of inactivity. The first touch on the keypad will wake up the keypad and will register as a command to the control panel.

Introduction:

Description:

The XT-IP series control panel is a Videofied wireless, battery operated hybrid alarm system. It is designed for residential, small business and commercial security applications. The XT-IP series provides integrated Video Verification and features dual communication paths: Ethernet and 2G3G.

The XT-IP series has programmable inputs and outputs. XT-IP series also features mapping where an external input can be used to generate a video clip from a MotionViewer.

Internal RF range and 2G3G range can be enhanced using external antennas.

Supervised Wireless Technology:

The XT-IP, along with all Videofied devices, uses the patented S2View® - Spread Spectrum, Videofied, Interactive, AES Encrypted Wireless technology, providing optimum signal integrity and security.

The bi-directional RF communication path between all devices and the system control panel guarantees high signal reliability. Integrated antennas eliminate protruding wires or rods, which are difficult to install, unsightly to consumers and potentially troublesome if damaged.

The panel supervises every device (excluding the remote key fob) to validate current open/close state, tamper condition, serial number, date of manufacture, firmware revision, and battery status.

In order for an installation to be UL compliant you must follow the specifications in the table below:

Type	Specifications	Location In Manual
Audio	When a MotionViewer is installed on the system you may not have the siren sound for less than 60 seconds	Page 43
Audio	If no MotionViewer is installed on the system you may not have the siren sound for less than 240 seconds	Page 43
Delays	When a MotionViewer is installed on the system the Entry delay must be 45 seconds	Page 9

SETUP MANUAL FOR XT-IP SERIES 2G3G PANEL

THIS SYSTEM REQUIRES A CMA/WMB/XMA or TMT2 INSTALLER SOFTWARE FOR PROGRAMMING



TO TRANSMIT ALARMS AND VIDEO VIA ETHERNET, THE SYSTEM REQUIRES AN EXTERNAL POWER SUPPLY WITH 4 ALKALINE BATTERIES FOR BACK-UP (PP4)

XT Initial Programming



Open the Control Panel

Using a #1 Phillips screwdriver, remove the 2 screws holding the cover on.




The cover will fold off the panel like a book with the curved side acting like the binding. The same technique is used when placing the cover back onto the unit.



When removing the XTTO cover, pull straight off, do not slide it.

*The SIM card must **NOT** be inserted or removed while the panel is powered*



Install the SIM card

Slide SIM card into the slot.
Make sure it is aligned correctly.
The SIM card is not required if you plan to use Ethernet only.


Connect the RJ45 (Ethernet cable) to the panel

Plug the RJ45 cable into the Ethernet jack on the control panel. The cable can be routed back through the wire channel to make sure it does not get pinched.



Important:

When the panel attempts a transmission via Ethernet a red LED will flash.



Obtaining WMB/XMA Keypad Special Characters

Keys	1 st Press	2 nd Press	3 rd Press	4 th Press	5 th Press	6 th Press	7 th Press	8 th Press	9 th Press	10 th Press	11 th Press	12 th Press	13 th Press	14 th Press
1	'Space'	1	.	-	@	\$	,	'	?	!	;	:	"	N/A
0	+	0	-	*	#	=	/	%	&	¥	<	>	(	)

Obtaining CMA Keypad Special Characters

Key	1 st press	2 nd press	3 rd press	4 th press	5 th press	6 th press	7 th press	8 th press	9 th press	10 th press	11 th press
1	"space"	.	,	'	?	!	:	:	#	1	
0	-	+	=	/	¥	-	<	>	(	)	0
@	@	\$	%	&	*	#					

Powering the Panel



****THE CONTROL PANEL MUST BE CONNECTED TO AN EXTERAL POWER SUPPLY WHEN ETHERNET FEATURE IS ACTIVE****

Option 1: PP1	Option 2
4 x LSH20 SAFT Lithium D-Cell	4 x E95VP Alkaline D-Cell + 12v 2amp DC Class 2 power supply (not supplied)
Used for Standalone or Xtender mode <u>without</u> Programmable Inputs, Programmable Outputs, Ethernet, or SMS	Used for Standalone or Xtender mode where Programmable Inputs/Mapping, Programmable Outputs, Ethernet connection, or SMS <u>will</u> be used
LSH20 Specifications: Operating Temp: -76°F to +230°F Storage Temp: Dry, Ventilated, 86°F Max	E95VP Specifications: Operating Temp: 0°F to 130°F

LSH20 Technical Specifications	
Nominal Voltage	3.6 V
Open Circuit Voltage	3.67 V
Nominal Capacity	9.3 Ah

E95VP Technical Specifications	
Nominal Capacity	8900 mA hours
Nominal Voltage	1.5 V

Power Supply Requirements	
Output Voltage (volts)	12
Output Current (mA)	2000
Certifications	Class 2 (For UL Compliance)



- WARNINGS:**
- 1. DO NOT USE ALKALINE BATTERIES IF INSTALLING AN XTXIP/XTOIP 2G3G BELOW 30° F, YOU MUST USE OPTION 1: PP1.
 - 2. DO NOT INSTALL A TRANSFORMER WHEN USING OPTION 1 (LITHIUM BATTERIES).

XT-IP Programming

Reset the XTIP Panel:


Press and hold programming button (1) for 10sec until the Indicator LED blinks twice



Press and instantly release the programming button (1). The indicator LED will blink once. The panel is now in 'Learn Mode' for the CMA/XMA/WMB keypad.




Insert all three batteries into the CMA/XMA/WMB and press both the ESC/NO and CLR keys at the same time and release. The indicator LED on the keypad will blink rapidly.




Other languages are available by scrolling with arrows. ENGLISH (UK), ENGLISH (US/AUS), FRENCH, ITALIANO, NEDERLANDS, DEUTSCH, CASTELLANO, SVENSKA, PORTUGUES, FRANCAIS. Press YES/OK for the selected one.


*NOTE: If you are having issues pairing the keypad to the panel, refer to the troubleshooting section.


Programming Device/Keypad



This Guide will display ENGLISH (US/AUS) Language only







Press right arrow → to select the transmission mode for alarms and videos and YES/OK to confirm.

1. Ethernet transmission with 2G3G back-up
2. Ethernet transmission only
3. 2G3G transmission only

Warning: the transmission mode "Ethernet only" is not recommended.


Your APN code (Access Point Name) is given to you by your Cellular Provider. Press ↵ YES/OK to enter into the parameter and use the Keypad to complete the code. Press ↵ YES/OK to confirm your entry and the → arrow to move to the next parameter.


Your USERNAME is given to you by your Cellular Provider. Press ↵ YES/OK to enter into the parameter and use the Keypad to complete the name. Press ↵ YES/OK to confirm your entry and the → arrow to move to the next parameter.


Your PASSWORD is given to you by your Cellular Provider. Press ↵ YES/OK to enter into the parameter and use the Keypad to complete the name. Press ↵ YES/OK to confirm your entry and ESC/NO followed by ESC/NO again to get back to programming.


During the 2G3G Level test, the Modem will boot and attempt to gain access to the cellular network. The system will display either a signal level out of 5 or an error code. Error codes are listed in the troubleshooting section. To keep the keypad awake, use any key on the keypad except the YES/OK, ESC/NO, and CLR keys. This test can take up to 5 minutes. Once the level or error has posted press YES/OK to continue in programming.

Videofied will require a 3/5 or better for reliable transmission of Video alarms









Device Installation


DCV#51 – Outdoor MotionViewer / BR#51 Outdoor Badge Reader

Place batteries in Device. Wait for LED to turn on. Press and release the programming button.




DCV#01 – Indoor MotionViewer / ITR#01 – Indoor Blind PIR/ IMD#01/IMV#01 – Indoor Motion and MotionViewer

Place batteries in device. Wait for LED to turn on behind PIR lens. Press and release the programming button.



CT#01 – Door/Window Contact / IDC#01 – Door Window Contact

Place battery into the door/window contact. Wait for LED to turn on. Press and release the programming button.



RC#01 – Remote Control Fob

Press and hold the ON and OFF keys at the same time for 5 counts of Mississippi and release.




SE#51/#01 – Indoor and Outdoor Sirens

Place all batteries into the siren. Wait for the LED to turn on right above the programming button. Press and release the programming button.



Entering a Badge or Access Code for Arming/Disarming

After Initial programming has been completed, you are not able to arm and disarm the system until you enter a user code or badge (the installer code cannot arm and disarm the system). Codes can be 4-6 digits and the 4th digit must be 2 values higher or lower than any other code on the system:
Example: User code 1234, next code cannot be 1235, 1236, 1233, or 1232 – These are reserved for



Silent Duress and Audible Duress. The XT system can accept up to 19 Badges or Access codes in any combination.

Reserved codes	Reserved codes	Reserved codes
000000	From 9998 to 9999	All codes +1
	From 99998 to 99999	All codes +2
	From 999898 to 999999	All codes -1
	From 314157 to 314159	All codes - 2

A total of 186 codes are forbidden	
Access level	Definition & rights
LVL1	Stand by level
LVL2	Restricted USER level where it is only possible to arm/disarm the system.
LVL3	USER level where it is possible to arm/disarm the system, check the event log, test the devices. Modifications of the setting are not possible at this level. User LVL3 can create LVL3 or LVL2 access codes.
LVL4	INSTALLER level where it is possible to modify the setup of the panel. The approval of a LVL3 or LVL2 is required to modify the level for LVL4. Installer LVL4 can create the first LVL3 access code only.

Configuration of Special Arming Modes:

To configure or modify a special arming mode, with the direction arrow go to the menu:

CONFIGURATION (LEVEL 4) + [YES/OK] → ALARM MODES PROGRAMMABLE + [YES/OK]
→ FULLY ARMED, SP1 and SP2 (use direction arrows to select the arming mode you want to modify + [YES/OK]).

For each arming mode, it is possible to specify how each of the 4 areas will be armed and how the system will behave during an alarm.

Areas: 1 2 3 4 press the corresponding number to change that areas arming option
States: A A A A state for the respective area.


Press the [YES/OK] key after this configuration step. The system will then display what siren mode will be in effect for this special profile. Select the siren mode using the direction arrows then press [YES/OK].

D	Disarmed
P	Perimeter Devices Only (devices must be programmed)
E	External Devices Only (devices must be programmed)

Siren	Immediate triggering of all sirens
Delay beeps	Entry/Exit delay beeps, then triggering of the sirens
Silent	No Sirens, No Beeps
Without Siren	Beeps on the keypad only

How to Disable/Enable Monitoring

Disabling monitoring can be a useful tool in many situations. Before mounting devices and moving the panel to find a good 2G3G level, disabling monitoring will ensure that you will have access to programming and that unnecessary signals are not sent to the monitoring station. When performing maintenance on the system disabling monitoring until the issue has been resolved will ensure that you will have access to programming throughout your troubleshooting.



ETHERNET Parameters:

To configure or modify Ethernet Parameters, go to:

CONFIGURATION (level 4) + [YES/OK] >> GENERAL PARAMETERS + [YES/OK] >> ETHERNET + [YES/OK]

- **IP Parameters:**

1. **DHCP Enable** – IP address is assigned by the DHCP service on the network.
2. **DHCP Disable** – IP address must be defined in Ethernet parameters. IP address will NOT be automatically obtained from DHCP service on the network.


- **Constant Ethernet:**

1. **“Auto” Mode** - We recommend this mode. If main powered, the panel will be connected constantly to the local Network. In case of an alarm, the alarm will be sent in few seconds to the monitoring station. When the main power is cut, the Ethernet module will switch off after a delay (DELAY BEFORE OFF – 30 by default) in order to save battery life. In case of an alarm, the panel will at first connect to the local Network. It adds few seconds to the total process of sending an alarm.
 2. **“ON” Mode** - The panel will be connected constantly to the local Network. This option will impact back-up battery life.
 3. **“OFF” Mode** - For each transmission of alarm and video, the panel will connect to the local Network.
- **PING REPLY:** Enables ping response
 - **Time Out Server:** In case of disconnection to the local Network, the panel will try after that time to re-connect.
 - **Max Seg. Size:** Size of packet sent

Codes	Action
999999	Maintenance request - 2G3G transmission
999996	Maintenance request - Ethernet transmission
999995	Displays local IP address assigned to the control panel: If the DHCP mode is deactivated : the static local IP of the panel will be displayed (defined in the ETHERNET menu – 7) If the DHCP is activated: • If the panel is not in transmission then 0.0.0.0 will be displayed • If the panel is in transmission (the RJ45 led will be flashing) then the dynamic IP of the panel will be displayed.
999991	Sends a test alarm to IP1 Address (Primary alarm receiver) This is a quick way to check for connectivity to the monitoring center. If there is a transmission problem the panel will terminate communication faster than in an actual alarm. The system will automatically attempt connection to IP2 Address (Backup alarm receiver) in the event that IP1 is unavailable.
999997	Displays external power supply status


Before the system is mounted you will need to check the 2G3G level to make sure it is adequate. If the level is 3/5 or better you can mount the control panel in that location.

2G3G Level	EVENT LOG	Error	Fix
010	11	SIM card not detected/not inserted	Power down control panel and check SIM card orientation and contacts
043	44	Provisioning problem	Contact the cellular provider to check provisioning and activation
132	133	SIM card not activated	Check with the cellular provider on SIM activation
255	256	Cannot connect to cell tower	Check coverage maps, bring panel outdoors to test,
003	3	SIM Card not detected/No Cellular Service	Check coverage maps, power down control panel and check SIM card orientation and contacts
030	31	No Cellular Service	Check coverage maps or with cellular provider for outages
101/57	*	Authentication Error	Check that the APN entered in the system is correct
102	*	No Cellular Service	Check coverage maps, move the panel outdoors to test, check with cellular provider for outages
149	*	Low Cellular Signal	Attempt a Yagi antenna installation to improve strength
*	47	Rejection by Host	IP, Domain Name, Port are incorrect or Receiver is rejecting the signal
013	*	Incorrect APN Code	Check with provider for proper APN information
*	13	SIM Card not detected	Power down control panel and check SIM orientation and contacts




How to enable the External RF Antenna

The XTO control panels have built in High Gain RF and 2G3G antennas. The 2G3G external comes pre-activated and hooked up, while the RF antenna is hooked up but needs to be activated in Configuration after you have completed initial programming. The following steps will walk you through how to enable the High Gain RF antenna after initial programming.



How to test RF for deployment of devices

Running the RF test during the mounting of devices is key to a successful Videofied installation. This test will ensure that all devices have adequate communication with the control panel. All Videofied devices are bi-directional which allows the system to ping the device and expect a response. The number of successful responses out of 9 will be displayed on the keypad for the device you are running the test for. This is also a relative range that will change in real time as you walk further away from the control panel and back closer.




NOTE: To insure proper operation of the system you must get 9/9 with each device before mounting.

2G3G Antenna Connection

! WARNING !

Use caution before removing antenna connection. Damaged antenna connector is NOT covered under warranty.




Using needle nose pliers, be sure to only grab the connector and pull directly up

XT-IP Power Chart


Parameters		Values		Units
		Min.	Max.	
Power	Voltage	9	15	VAC or VDC
	Current	2	/	A
Ref +	Voltage	3.5	16	VDC
	Current		50	mA
Arming Inputs 1&2 Prog. Inputs 1,2&3	Entry Inactive Voltage		~1.0	VDC
	Entry Active Voltage	~1.4	15	VDC
	Current	1.5	3	mA
Outputs 1&2	Switching Voltage		220VDC/250VAC	VAC or VDC
	Switching Current		4	A
	Switching Power		120	VA

Arming Input Wiring Diagram


HOST SYSTEM POWERED




Host System Powered: In this diagram the host system will power the control panel and latch 9-12v DC to the arming inputs when armed, removing that voltage when disarmed



POWERED BY POWER SUPPLY



Powered by Power Supply (PP4): In this diagram the panel is powered by the transformer included in the PP4 kit. The host system must control the relay, closing when armed and opening when disarmed. In this case the voltage is supplied by the REF+ on the panel when the relay is closed.




When in the 'Arm From Host' mode the Videofied system will only arm and disarm when 9-12v is supplied and sustained. When both arming inputs are supplied voltage at the same time the Videofied Keypad display will show 'SYSTEM ARMED. When only one arming input is supplied voltage the Videofied Keypad display will show 'PART LVL #'

Arming Input 1 will arm/disarm Areas 1 & 2

Arming Input 2 will arm/disarm Areas 3 & 4

How to test to the dispatch center

Testing to the dispatch is done twice during installation. Once while you are programming the system and then again once the installation has been completely finished. Although both will use the same steps the initial test will be just confirmation using one device to verify the programming.




Note: Send 1 MotionViewer in at a time and verify with Central Station that they are getting Alarm and Video before tripping another MotionViewer. This will save time with the Central Station.

How to mount the XT-IP

How to Mount the Control Panel?


Fix the back casing on the wall with 3 screws (1)



How to Mount the XTO-IP

Included Mounting Hardware:



Case and Mounting
Screws, locking
washers, bolts and
nuts.




L Bracket – x2

Mounting Brackets

1. Install the Weather Resistant Wire Port.



- Place the cover on the base.



- When closing the cover be sure to line up the two BOTTOM stickers face to face.
- Be Careful not to slide the cover on. Instead come straight down in order to have the cover tamper properly seat.

- Screw the cover to the base using the provided 8 screws.



NOTE: To ensure proper functioning and to keep the case water proof you must mount the panel with the wire channel facing down.


- Place the L shaped mounting bracket onto the base using the provided bolts.



For Pole Mounting: Complete step 4. Place the two U shaped brackets around the pole and attach the locking bracket. Use the locking washers and nuts to attach the U bracket to the L mount.



For Flat Wall Mounting: Complete step 4. Mount the additional L bracket to the structure. Place the longer edge of both brackets together so that the holes line up and use the longer/larger bolts and lock nuts to secure them together.



The following application notes are available on
<http://support.videofied.com>:


- Direct Bypass Configuration
- Programmable Input Configuration
- Programmable Output Configuration
- Partitioning Configuration
- Chime Configuration
- System Status Configuration
- Scheduling Configuration
- Ringtone Configuration
- Videofied Remote (Smartphone app) Configuration
- Ringtone Configuration

Troubleshooting

Monitoring Station is not getting ANY video but is getting signals:

Good communication between the MotionViewers and the Control Panel is key to getting successful video to the monitoring station. During mounting of any device on your Videofied system you must run the Radio Range/Device Locating test to ensure that the mounting location is with-in range of the Control Panel.

- Concrete, Metal and earth are some of the largest RF inhibitors and should be taken into account when choosing mounting locations.
- When running the Radio Range/Device Locating test you should have the site as close to the same as it would be when the site is closed/no one is there, i.e. close garage doors/service doors, etc. Device locating steps can be found on Page 17.




Important Note: Videofied will only automatically download the first MotionViewer video that is taken and only if this is the primary event or reason for the panel connecting with the monitoring station. If the account is on test you will only ever get the first video downloaded. If you are only getting the events at the station and all tests above pass more than likely you are sending a preceding event (like an arming signal or door contact) which will cause the video to not auto download because the video is not the primary event.

Monitoring Station is not getting any signals:

Communication between the Control Panel and the Monitoring Station is either over the Ethernet Connection or 2G3G side of the GSM cellular network.

- Go into Maintenance and run the ETH STATUS to see if you receive back an IP Address or error.
- If you receive an IP Address back you will want to contact and consult the network admin to make sure the outbound port is not being blocked (Port 1 programmed in the panel).
- If you are using 2G3G as the primary communication, you will want to check your 2G3G level to see if there is an error/level is too low. You must have a 3/5 or better for reliable transmission to the Monitoring Station. How to run the 2G3G level test and 2G3G error codes can be found on page 16.
- If you receive a successful 2G3G level test you will want to check the panel event log for more 2G3G errors that could be occurring during the attempted transmission but after cellular authentication.



Panel is staying CONNECTED WITH MONITOR STATION

While the Control Panel is attempting or is connected with the Monitoring Station you will see this message when you attempt to move around on the keypad. If the system is not successful in connecting with the station it will retry the connection multiple times, locking you out of programming until it is done trying. This normally can take anywhere between 15-20 minutes.

- If you want to force the panel to disconnect you must
 - o 1. Remove the batteries from the control panel
 - o 2. Secure the cover tamper of the panel
 - o 3. Re-insert the batteries into the control panel and sync the keypad back by pressing the CLR and ESC/NO buttons at the same time.
 - o 4. Access the Configuration menu by changing you access level to 4 and go to Configuration Monitor Station.
 - o 5. In Monitoring Parameters – Disable monitoring until the connection issue is resolved.

Unable to record device or getting 'Pairing Failure' error

This usually occurs when the device still has a pairing key from a previous system or setup. To perform a pairing key override:

- o 1. Remove all batteries from the device.
- o 2. Make sure your system is ready to record devices:
 - o A. If learning in the keypad, press the panel's programming button. DO NOT HOLD THE PANEL'S PROGRAMMING BUTTON
 - o B. If learning in additional devices, make sure the keypad reads 'Press Programming Button Of Device'
- o 3. Insert a single battery into the device.
- o 4. Wait 1 second for device to power up.
- o 5. Press programming button of device (for keypads press 'CLR' & 'ESC/NO' keys at the same time)



For the 4-button remote keyfobs the process is slightly different:

- o 1. Press and hold the 'ON' and 'OFF' keys at the same time for 12 seconds
- o 2. Wait 1 second
- o 3. Press and hold the 'ON' and 'OFF' keys at the same time for 5 seconds, you should hear 4 beeps from the keyfob.


Outdoor MotionViewer Trips All the Time:

It is important to follow these basic installation tips when mounting and aiming an outdoor MotionViewer

- o 1. Protect your assets, not the whole area.
 - Secure specific assets or clusters of assets rather than cover a large area where the range of the MotionViewer might extend beyond the assets and detect irrelevant objects.





- o 2. Terminate the view of the MotionViewer.
 - Make sure to tilt the MotionViewer down 5-7° so that its top line of sight terminates into the ground. Taking into account all three elements; PIR, digital video camera, and infrared illuminators – you will want to terminate the view of the MotionViewer at 40 ft. from the device.




XT-IP -SERIES 'AFTER INITIAL PROGRAMMING' FLOW CHART

Parameters are only available in Access Level 4







Addendum

1. LSH20 Control Panel Batteries:

Primary lithium battery LSH 20

3.6 V Primary lithium-thionyl chloride (Li-SOCl₂)
High power
D-size spiral cell



Cell size references		UM1 - R20 - D
Electrical characteristics		
<i>(typical values relative to cells stored for one year or less at +30°C max.)</i>		
Nominal capacity		13.0 Ah
<i>(at 15 mA +20°C 2.0 V cut off. The capacity restored by the cell varies according to current drain, temperature and cut off)</i>		
Open circuit voltage	(at +20°C)	3.67 V
Nominal voltage	(at 2 mA +20°C)	3.6 V
Pulse capability: Typically up to 4000 mA <i>(4000 mA/0.1 second pulses, drained every 2 mn at +20°C from undischarged cells with 10 µA base current, yield voltage readings above 3.0 V. The readings may vary according to the pulse characteristics, the temperature, and the cell's previous history. Fitting the cell with a capacitor may be recommended in severe conditions. Consult Saft)</i>		
Maximum recommended continuous current		1800 mA
<i>(to maintain cell heating within safe limits. Battery packs may imply lower level of maximum current and may request specific thermal protection. Consult Saft)</i>		
Storage	(recommended) (for more severe conditions, consult Saft)	+30°C (+86°F) max
Operating temperature range		-60°C/+85°C (-76°F/+185°F)
<i>(Operation above ambient T may lead to reduced capacity and lower voltage readings at the beginning of pulses. Operation with current continuously above 1 A may restrict upper T range. Consult Saft)</i>		

2. LS14500 Peripheral Batteries: Excludes SE601 and SE651

Primary lithium battery LS 14500

3.6 V Primary lithium-thionyl chloride (Li-SOCl₂)
High energy density
AA-size bobbin cell



Cell size references		R6 - AA
Electrical characteristics		
<i>(typical values relative to cells stored for one year or less at +30°C max.)</i>		
Nominal capacity		2.6 Ah
<i>(at 2 mA +20°C 2.0 V cut-off. The capacity restored by the cell varies according to current drain, temperature and cut-off)</i>		
Open circuit voltage	(at +20°C)	3.67 V
Nominal voltage	(at 0.2 mA +20°C)	3.6 V
Pulse capability: Typically up to 280 mA <i>(280 mA/0.1 second pulses, drained every 2 mn at +20°C from undischarged cells with 10 µA base current, yield voltage readings above 3.0 V. The readings may vary according to the pulse characteristics, the temperature, and the cell's previous history. Fitting the cell with a capacitor may be recommended in severe conditions. Consult Saft)</i>		
Maximum recommended continuous current		70 mA
<i>(Higher currents possible, consult Saft)</i>		
Storage	(recommended) (for more severe conditions, consult Saft)	+30°C (+86°F) max
Operating temperature range		-60°C/+85°C (-76°F/+185°F)
<i>(Operation above ambient T may lead to reduced capacity and lower voltage readings at the beginning of pulses. Consult Saft)</i>		

3. Lithium Battery Storage:

Storage

- The storage area should be clean, cool (*preferably not exceeding +30°C*), dry and ventilated.

Warning

- Fire, explosion and burn hazard.
- Do not recharge, short circuit, crush, disassemble, heat above 125°C (257°F), incinerate, or expose contents to water.
- Do not solder directly to the cell (*use tabbed cell versions instead*).

4. Finding Manufacture Week and Year:

The Manufacture week and year can be found in the serial number of the device/control panel. The second sets of 4 numbers in the serial number are WWYY.

####0411##### = Which shows that this device was manufactured in the 4th week of 2011.

5. Event Log Ethernet Codes

Log Code	Meaning
Ethernet Off	Ethernet interface is OFF
Ethernet On	Ethernet interface is ON
Ethernet (0)	Ethernet Error
Ethernet (1)	No DCHP reply (after MAX DHCP RETRY)
Ethernet (2)	No Frontel reply (after TIMEOUT SERVER)
Ethernet (255)	Ethernet communication success
Ethernet Lost	No Ethernet cable detected
Ethernet Returned	Ethernet cable restored

6. Additional System Codes

Codes	Action
999999	Maintenance request - 2G3G transmission
999996	Maintenance request - Ethernet transmission
999995	Displays local IP address assigned to the control panel: If the DHCP mode is deactivated : the static local IP of the panel will be displayed (defined in the ETHERNET menu – 7) If the DHCP is activated: • If the panel is not in transmission then 0.0.0.0 will be displayed • If the panel is in transmission (the RJ45 led will be flashing) then the dynamic IP of the panel will be displayed.
999991	Sends a test alarm to IP1 Address (Primary alarm receiver) This is a quick way to check for connectivity to the monitoring center. If there is a transmission problem the panel will terminate communication faster than in an actual alarm. The system will automatically attempt connection to IP2 Address (Backup alarm receiver) in the event that IP1 is unavailable.
999997	Displays external power supply status

7. Replacing Device and Control Panel batteries

When replacing batteries in the Videofied control panel or devices the battery replacement mode must be used. This will ensure that the low battery algorithm on the panel/device is properly reset and also helps keep the devices synced with the control panel.

Devices:

Access Level 4 -> Maintenance -> Replace Batteries -> Devices

The system will give you 1 minute to open any device on the system to replace the batteries. When a device is opened you will have 5 minutes to replace the batteries before the system will time out and all tampers will be active again on the system. We suggest that you start the device battery replacement for each individual device to ensure the 5 minutes does not expire and tamper signals are not sent to the monitoring station.

Control Panel:

Access Level 4 -> Maintenance -> Replace Batteries -> Panel

The system will give you 1 minute to open the panel. When the panel is opened it will give you 5 minutes to replace the batteries before the control panel tampers will be active again.

8. Checking control panel firmware version

1. All control panel labels on the box and inside of the cover will have the firmware version listed.



2. After completing initial programming hit the 0 key 6 times followed by YES/OK (000000 + YES) and the firmware version will be listed.
3. Connect the panel to TMT2 using the USB or Cellular connection. The firmware version of the control panel is listed on the main screen.

