



Contact ID Codes for Paradox 32 Zone Panels

PRODUCTS: MG5050, SP5500, SP6000, SP7000

TOPICS COVERED IN THIS KBA: Contact ID codes that are used on Paradox 32 Zone Panels

Standard CID Codes for Paradox 32 Zone Panels

In order to accommodate the ancillary equipment for Paradox's 32 zone panels, the CID Codes for zones 33 to 62 have been used as system alarms for this equipment. It is important that the Control Room is aware of these substitutes in order to adjust their template.

Zone No.	Event Description
Zone 01 to Zone 32	Burglary Alarms From Zone 1 to Zone 32
Zone 33 To Zone 48	Supervisory Alarms For Wireless PGM's Numbers 1 to 16
Zone 49 And Zone 50	Supervisory Alarms For Wireless Repeaters Numbers 1 and 2
Zone 51 To Zone 58	Supervisory Alarms For Wireless Keypads Numbers 1 to 8
Zone 59 To Zone 62	Supervisory Alarms For Wireless Sirens Numbers 1 to 4