

AEI SECURITY KEYPAD



DK-9510D

PROGRAM THE KEYPAD – SUMMARY CHART

A) Use the master code entry in programming – When starting

<u>Entry of code</u>	<u>Validation</u>	<u>Comments</u>
Master Code	*	Enter in programming mode by master code

B) Programming – Recording of user code – User programming

<u>Access Keys</u>	<u>Entry of codes</u>	<u>Validation</u>	<u>Comments</u>
0	From 1 to 8 digits	#	Personal Master Code
1	From 1 to 8 digits	#	User Code

C) Programming – Configuration of relay output – Installer programming

<u>Access Keys</u>	<u>Code Duration</u>	<u>Validation</u>	<u>Comments</u>
4 0	From 1 to 999	#	Output in MOMENTARY mode from 1 to 999 seconds

D) Leave programming mode

<u>Validation</u>	<u>Comments</u>
*	The keypad leaves programming mode, and is in OPERATION mode, ready for daily use