

APPENDIX 1

This document describes the DL-250 reporting event codes when using the SIA format (format 14). The following codes are programmable and are sent when the 100's digit is programmed as the event code. The 10's and 1's digit are then sent as a zone identifier.

<i>PROGRAMMED 100's DIGIT</i>	<i>SIA CODE</i>	<i>DEFINITION</i>
0	PA	PANIC ALARM
1	FA	FIRE ALARM
2	PA	PANIC ALARM
3	BA	BURGLARY ALARM
4	GA	GAS ALARM
5	KA	HEAT ALARM
6	WA	WATER ALARM
7	QA	EMERGENCY ALARM
8	SA	SPRINKLER ALARM
9	UA	UNTYPED ALARM
10	HA	HOLDUP ALARM
11	MA	MEDICAL ALARM
12	ZA	FREEZE ALARM
13	TA	TAMPER ALARM
14	RP	PERIODIC TEST
15		RESERVED

The following event codes are fixed but must be enabled by programming a 1 in the corresponding location.

<i>REPORTING EVENT</i>	<i>SIA CODE</i>	<i>PROGRAMMING LOCATION</i>
TAMPER	TA	304
AUTOTEST	RP	308
FAIL TO COMMUNICATE	RT	312
OPENING	OP	340
CLOSING	CL	341
CANCEL	OC	343
AC LOSS	AT	320
LOW BATTERY	YT	324
RESTORE CODE	*R	332
BYPASS CODE	*B	334
BYPASS RESTORE	*U	334/332
TROUBLE CODE	*T	336
TROUBLE RESTORE	*R	336/332
AC RESTORE	AR	328
BATTERY RESTORE	YR	329
FAIL TO CLOSE	CI	348
EARLY OPENING	OK	344
DOWNLOAD COMPLETE	RS	352

* The character transmitted in this location will be the first character in the SIA code from the top list for the event being transmitted. If a "1" is programmed in location 332, and a Burglary Alarm (B A) restores, a B R will be transmitted. If a "1" is programmed in location 336, and a Fire Alarm (E A) zone goes into Trouble, an (E T) will be transmitted.