


# Getting Integrity Panels to Auto Sync Time with the Software

❶ In this Guide we will go through the steps to setup an automated time synchronization of the controllers with the server


## Step 1.

Create a Scheduled task on the Integrity




## Step 2.

Name the Scheduled Task and add a trigger



## Step 3.


set a time trigger, and select the frequency you wish to sync the panels at  
in the example below it is set for every day at 9:55 AM



#### Step 4.


Create a Action

click on the action tab then add action



### Step 5.

Select Synchronize controller time then add the controller or controllers you wish to sync



### Step 6.

Now your ready to go

💡 if you wish to force the Time Synchronization right away you can select the Run task now option for force the scheduled action

