


Integriti


INTEGRATED SOLUTIONS




Integriti Client Software Installation

Download the desired Integriti Software version from the Inner Range website. This should match the Integriti server version.


Double Click on the Installer and allow the app to make changes.




Read and accept the End User License Agreement, then click next




Read the system requirements, ensure your hardware meets them, and click next.




Choose the installation directory and click next.




From the component selection drop down menu choose Client Only and click next. Both Integriti System Designer and Integriti GateKeeper will be installed with any Client selection.




Select the location for the Integrity shortcuts and click next.



Review the installation information and then click Install.



The installation wizard will display the installation progress.



Once completed select the next steps to perform and click Finish to exit.

