

Multipath V4 - Server Generated Messages V2

Description	Client Code	ContactID			IPServer Message			IRFAST Raw Data				
		Alarm Msg	Group	Point	Module	Zone	Area	Msg Type	Module Type	Module Number	Area	Zone
Loss of Polling	STU	356	??	801	V01	S01	??	IRFAL	1E	00	??	00
Message Quarantined	STU	354	??	802	V01	S02	??	IRFAL	1E	00	??	01
Alarm out of Sequence	STU	350	??	803	V01	S03	??	IRFAL	1E	00	??	02
Panel Unenrolled	STU	352	??	804	V01	S04	??	IRFAL	1E	00	??	03
Panel serial number has changed	STU	137	??	805	V01	S05	??	IRFAL	1E	00	??	04
Invalid message format - ContactID	STU	300	??	806	V01	S06	??	IRFAL	1E	00	??	05
Invalid message format - IRFast	STU	300	??	807	V01	S07	??	IRFAL	1E	00	??	06
Installer access timer has started	STU	412	??	808	V01	S08	??	IRFAL	1E	00	??	07
Installer access timer has stopped	STU	412	??	809	V01	S09	??	IRFAL	1E	00	??	08
Ethernet path warning	STU	366	??	810	V01	S10	??	IRFAL	1E	00	??	09
GPRS 1 path warning	STU	366	??	811	V01	S11	??	IRFAL	1E	00	??	A
GPRS 2 path warning	STU	366	??	812	V01	S12	??	IRFAL	1E	00	??	B
PSTN path warning	STU	366	??	813	V01	S13	??	IRFAL	1E	00	??	C
Repeated loss of polling	STU	356	??	814	V01	S14	??	IRFAL	1E	00	??	D
Alternate path warning	STU	366	??	815	V01	S15	??	IRFAL	1E	00	??	E
Repeated Ethernet Path Warning	STU	366	??	816	V01	S16	??	IRFAL	1E	00	??	F
Repeated GPRS 1 Path Warning	STU	366	??	817	V01	S17	??	IRFAL	1E	00	??	10
Repeated GPRS 2 Path Warning	STU	366	??	818	V01	S18	??	IRFAL	1E	00	??	11
Repeated Dialup ISP Path Warning	STU	366	??	819	V01	S19	??	IRFAL	1E	00	??	12
STU changed path to Ethernet	STU	366	??	821	V01	S21	??	IRFAL	1E	00	??	14
STU changed path to GPRS 1	STU	366	??	822	V01	S22	??	IRFAL	1E	00	??	15
STU changed path to GPRS 2	STU	366	??	823	V01	S23	??	IRFAL	1E	00	??	16
STU changed path to Dial-up ISP	STU	366	??	824	V01	S24	??	IRFAL	1E	00	??	17
STU Service Required	STU	380	??	825	V01	S25	??	IRFAL	1E	00	??	18
Dial-up ISP path warning	STU	366	??	827	V01	S27	??	IRFAL	1E	00	??	1A
					NOTE: Area field is selectable on installation. Changed since last Version							
IPServer internal error	SERVER	300	??	850								
IPServer resource error	SERVER	300	??	851								
Message from unknown Multipath STU	SERVER	300	??	852								
IPServer communications error	SERVER	350	??	853								
IPServer automation system test message	SERVER	602	??	854								
IPServer remote access enabled	SERVER	632	??	855								
IPServer remote access disabled	SERVER	632	??	856								
Redundancy is not correctly configured	SERVER	300	??	857								
Redundancy IPServer database error	SERVER	300	??	858								
Redundancy IPServerEvent database error	SERVER	300	??	859								
Critical network alarm for all paths	SERVER	350	??	860								
Critical network alarm for Ethernet network	SERVER	350	??	861								
Critical network alarm for Optus GPRS network	SERVER	350	??	862								
Critical network alarm for Telstra GPRS network	SERVER	350	??	863								
Critical network alarm for Vodafone GPRS network	SERVER	350	??	864								
The HASP dongle is missing	SERVER	300	??	865								
Software licence will expire in 10 days.	SERVER	300	??	866								
Software licence will expire in 9 days.	SERVER	300	??	867								
Software licence will expire in 8 days.	SERVER	300	??	868								
Software licence will expire in 7 days.	SERVER	300	??	869								
Software licence will expire in 6 days.	SERVER	300	??	870								
IMPORTANT - Software licence will expire in 5 days.	SERVER	300	??	871								
IMPORTANT - Software licence will expire in 4 days.	SERVER	300	??	872								
IMPORTANT - Software licence will expire in 3 days.	SERVER	300	??	873								
IMPORTANT - Software licence will expire in 2 days.	SERVER	300	??	874								
IMPORTANT - Software licence will expire TOMORROW.	SERVER	300	??	875								
IMPORTANT - Software licence has EXPIRED!	SERVER	300	??	876								