

Menu Group Programming

Menu Group contains a series of options which are used to decide what actions a particular User Type is allowed to perform at an LCD Terminal. Menu Groups may be allocated to User Types and/or LCD Terminals to restrict access to menu functions allowable for a particular User Type and/or Terminal. It also controls remote access via a PC.

Note: There are 4 default Menu Groups already programmed and available for use in the system. These Menu Groups will cover some common User Type and Terminal programming requirements. **The procedure to reset Menu Group Programming to the factory default is explained in more detail at the end of this chapter.**

Menu Group Defaults

	MG001	MG002	MG003	MG004
Name	All Menus	Restricted Menus	Extra Menus	Admin. Menus
TimeZone				
Alternate Group				
BASIC OPTIONS				
Remote Access				
Isolate on Exit	Yes		Yes	Yes
Defer On				
Cancel Holdup				
Disable Sirens			Yes	Yes
Ack. All Alarms	Yes			Yes
Multiple Area ON/OFF	Yes	Yes	Yes	Yes
Tamper OFF	Yes			Yes
MENU ACCESS				
Info. (review)	Yes			Yes
Access	Yes			Yes
Isolate	Yes			
Test	Yes		Yes	Yes
Time	Yes			Yes
Service	Yes		Yes	Yes
Control	Yes			Yes
OPTION ACCESS				
User Codes	Yes			Yes
User Types*	Yes			
Lists*	Yes			
Groups*	Yes			
TimeZones*	Yes			
Review*	Yes			
Adjust Counters*	Yes			
OTHER OPTIONS				
Reset Alarms				
Isolate HomeZones				
Only Own List				

* If access to the Menu containing this option is already allowed.

Menu Group to alter: MG001

This screen allows the Installer to select the Menu Group to alter. Pressing the ON key displays the “Find Menu Grp” screen. By pressing one of the alphabetical keys the Installer is able to search the Menu Groups and go to the group with the name beginning with the letter of the key pressed.

Find Menu Grp ^ ALL MENUS

NOTE: MG001 should not be altered.

M. Grp. 001 Name ALL MENUS

This screen allows an optional Menu Group name to be entered up to 16 characters in length. It is recommended that Menu Group names be programmed to simplify programming of the other options where Menu Groups are allocated.

MG001 T. Zone -> WEEKDAY

This screen allows an optional TimeZone to be “attached” to this Menu Group. When a TimeZone is “attached”, the Menu Group is only valid when the TimeZone is valid. When the TimeZone is invalid, ALL Menu Group options are considered to be invalid OR the Menu Group specified below will be used instead, if programmed. To select a TimeZone press the right arrow key to scroll through all the available TimeZones alphabetically. Press the OFF key if you wish no TimeZone control of this Menu Group. (The ON key may be used to change modes to allow a TimeZone to be selected by number if desired.)

MG001 TimeZone TZ001

MG001 Alt.Grp.-> SOME MENUS

This screen specifies what Menu Group will be used instead of this Menu Group when an “attached” TimeZone is invalid. If no alternative Menu Group is specified and the TimeZone is invalid, all options for the Menu Group are considered invalid.

MG001 Alt. Group MG008

MG001 RIDCSAMT Opt1-> nnnnnnnn

The screen sets the basic options concerning this Menu Group.

R Remote Access

Allows this User remote access via an upload/download package.

The system allows remote access to the system via the upload/download package or via direct line or dialer formats that support remote access. In all cases access is only granted via knowledge of a User code within the system. The table below lists the permission's granted to each User:

User 00001	All programming and all on/off control allowed via upload/download package. Installer must not be locked out by Master User (U00002)
User 00002	Some programming and all on/off control allowed via upload/download package. Remote access is enabled regardless of the setting of the Remote option in Menu Group
User 00003	No programming and some or no on/off control allowed via upload/download package. Remote access is enabled regardless of the setting of the Remote option in Menu Group. Intended as a secondary Master or Central Station User.

		User > 00003	No programming and some or no on/off control allowed via upload/download package. Menu Group must have Remote option set to yes to enable Remote access.
I	Isolate on Exit		Allows this User to Isolate Zones on Exit if they are unsealed.
D	Defer On		If set to "Y" this User will cause the Deferred Area processing timer to start when they turn off an Area which has its Defer Area flag set to yes and is on the User's Area Off list. Go to the section of this manual on " Deferred Area Programming " for detailed Instructions.
C	Cancel Holdup		Allows this User to cancel Holdup Alarms by stopping the Holdup timer.
S	Siren Off		User Types with this Menu Group will automatically turn off any sirens sounding at the time of code entry, regardless of whether they are allowed control over the Areas in which the sirens are sounding. The relevant Areas are NOT automatically turned off.
A	Acknowledge		User Types with this Menu Group will be allowed to acknowledge alarm messages from any Area, regardless of whether they are allowed control over Areas in which the alarm messages came from.
M	Multiple Areas		User Types with this Menu Group are allowed to turn on or off more than one Area at a time via an Area List. Although the User can pick any Area List to use, only Areas belonging to the User Type "ON" and "OFF" lists will be actioned.
T	Tamper On/Off		User Types with this Menu Group will be allowed to turn OFF the 24 Hour or Tamper part of any Area belonging to their Area OFF list.
MG001 RAITt . SC MMenu ->nnnnnnnn		This screen allows the Installer to set permissions for access to specified menus on a Terminal. NOTE: The Installer (U00001) and Master (U00002) codes are allowed access to all these menus regardless of the settings below.	
R	Read Info		User Types with this Menu Group are allowed access to the Information Menu. (See qualifying options below)
A	Access		User Types with this Menu Group are allowed access to the Access Programming Menu. (See qualifying options below)
I	Isolate		User Types with this Menu Group are allowed access to the Isolate Menu.
T	Test		User Types with this Menu Group are allowed access to the Test Menu.
t	Time		User Types with this Menu Group are allowed access to the Time Programming Menu. (Set Time/Date and Holidays Only - See qualifying options below)
.	Spare		Spare for future development. Set to "n".

S	Service	User Types with this Menu Group are allowed access to the Service Menu. Only the Installer (U00001) and Master (U00002) codes are permitted access to the "Security" sub-menu which is found within the Service Menu.
C	Control	User Types with this Menu Group are allowed access to the Control Menu. (See qualifying options below)

MG001 UTLGZRA.
Amenu-> nnnnnnnn

This screen sets permissions for access to specified sub-menus on a Terminal.

U	User Codes	If "Y" then User Types with this Menu Group are allowed access to User Code programming. Note that a simple priority scheme means that only User Codes higher than the programmer's User Code may be programmed. For example, U00567 cannot programme U00001 to U00566. (See "User Ranks" in "User Code Programming" for details of a more complex priority scheme).
T	User Types	If "Y" then User Types with this Menu Group are allowed access to User Type programming if they are allowed access to the Access Menu. (See last screen)
L	Lists	If "Y" then User Types with this Menu Group are allowed access to List Programming (Areas, Doors, Sirens) if they are allowed access to the Access Menu (See last screen).
G	Groups	If "Y" then User Types with this Menu Group are allowed access to Group Programming (Menu Groups and Access Groups only) if they are allowed access to the Access Menu (See last screen).
Z	TimeZones	If "Y" then User Types with this Menu Group are allowed access to TimeZone Programming in addition to Set Time/Date and Holiday Programming if they are allowed access to the Time Menu (See last screen).
R	Review	If "Y" then User Types with this Menu Group are allowed to access Review provided they are allowed access to the Information Menu (See last screen).
A	Adjust Counters	If "Y" then User Types with this Menu Group are allowed to adjust counters under MENU 9,6 provided they are allowed access to the Control Menu (See last screen).

MG001 RHO.....
Other-> nnnnnnnn

This screen allows the Installer to set other special options.

R	Reset latched alarms	If "Y" then User Types with this Menu Group are allowed to reset latched alarms. <i>See Input Types in Process Group Programming [MENU 2,4,3].</i>
H	Isolate HomeZones	If "Y" then User Types with this Menu Group will be presented with alpha search HomeZones only when they access the Isolate Menu [MENU 3] if allowed. If set to "n", the normal Zone ID screens will be presented. <i>See "Isolate" [MENU 3] for further details.</i>
O	Only Own List	V4 or later. If "Y" then User Types with this Menu Group, when selecting an Area List to Control, will only be presented with their User Type's Area On List. This simplifies Area List selection.

Menu Group Defaulting

Two options are available by which to default Menu Group Programming to factory settings. These are explained below

Menu Group to
alter: MG001

At the first Menu Group Programming screen press HELP, “9”.

M.Grp. Default->
Don't Default

This screen is then displayed. Available defaulting options are viewed by pressing the right Arrow Key. To make a selection, press the OK Key.

Don't Default

Selecting this option will abort the procedure.

Clear All

Selecting this option will reset the first four Menu Groups as follows:

MG001	ALL MENUS
MG002	RESTRICTED MENUS
MG003	EXTRA MENUS
MG004	ADMIN MENUS

In addition, this option will delete all other Menu Groups, if present.

Standard

Selecting this option will reset the first four Menu Groups as follows:

MG001	ALL MENUS
MG002	RESTRICTED MENUS
MG003	EXTRA MENUS
MG004	ADMIN MENUS

This option will make no alterations to any other Menu Groups, if present.

Push '9' key to
Confirm Default

The confirmation screen is displayed. Press the “9” Key to confirm your selection.

Default
Done

The default procedure is confirmed.

