


Control Menu

HOME AUXILIARIES



Home Auxiliaries are outputs in the system that can be turned On and Off by a User. Access to control of some Home Auxiliaries may be gained by simply pressing the <RIGHT> arrow key on the LCD Terminal. Other Home Auxiliaries need to be more secure and can only be controlled via access to this Control Menu option.



The display shows the current status of the first Home Auxiliary. (The example shown opposite is a default Home Auxiliary name. This type of name should only appear for Home Auxiliaries that are not used.)



To select a Home Auxiliary, use the <UP> and <DOWN> Arrow keys to search through the list.


OR




Search for a Home Auxiliary by name by pressing the DIGIT key that represents the first letter of the name. (You may have to press the key 2 or 3 times, depending on the letter required and the Home Auxiliary names in the system.)



If the Home Auxiliary you want is not displayed because of other names beginning with the same letter, use the <DOWN> Arrow key to locate it.



Controlling the Home Auxiliary.



When the desired Home Auxiliary is displayed;




Press the ON key or OFF key to turn the Auxiliary On or Off as required.

OR



Press the <LEFT> arrow key to enter a Home Auxiliary "On time" in Minutes or the <RIGHT> arrow key to enter an "On time" in Seconds. (V2 or later only)



Use the <DIGIT> keys to enter the time period required, then <OK> to execute the action.



Select another Home Auxiliary to control using the <UP> and <DOWN> arrow keys or <DIGIT> keys.

OR



Press the <END> key to exit to the normal display.

DOOR CONTROL



The “Door Control” option allows a User with the appropriate authority to Unlock and Lock individual Doors (V3 or later only) or all Doors in the Door List assigned to their User Type.

e.g. If Doors are programmed for “free access” during the day, it may be necessary to re-lock the doors if all the staff leave early to attend a company function at another location.

OR

It may be necessary to un-lock doors if free access is required outside normal working hours to allow staff to fulfil an urgent order.

NOTE: Only Doors included in the User’s “Door List” (defined in their “User Type”) can be controlled.

Door to
Control? 000

The display will allow you to enter the number of the Door to control.



Use the <DIGIT> keys to enter the three digit Door number then <OK>. (Press <END> to abort)

A Door number of “000” will include all Doors in the User’s Door List.

(L)ock or
(U)nlock ?

The display will now allow you to select the “Lock” or “Unlock” operation.



Press the <4> (L) key to Lock the Door.

Press the <7> (U) key to Unlock the Door.

Operation
Done

The display will briefly show the “Operation Done” message to indicate that the operation was successful and then return to the main menu.



Press the <END> key to exit to the normal display or select another Menu option.

LIFT CONTROL

“Lift Control” allows a User with the appropriate authority to Access or Secure Floor/s in a specific Lift Car. If accessed, all Users may access the floors. If secured, only valid Users may access the floors.

e.g. If Floors are normally programmed for “free access” during the day, it may be necessary to Secure the floors to restrict access during a VIP visit.

OR

If access is required outside normal working hours for staff to complete an urgent project, it may be necessary to Access the Floors.

Lift
Car ? 01



The display will allow you to enter the number of the Lift Car to control.

Use the <DIGIT> keys to enter the two digit Lift Car number then <OK>. (Press <END> to abort)

A Lift Car number of “00” will include all Lifts.

Floor
to do ? 00



The display will allow you to enter the number of the Floor to control. (V3 or later only)

Use the <DIGIT> keys to enter the two digit Floor number then <OK>. (Press <END> to abort)

A Floor number of “00” will include all Floors.

(A)ccess or
(S)ecure ?



The display will allow you to select the “Access (Free) Floor” or “Secure Floor” operation.

Press the <1> (A) key to Access (Free) the Floor.

Press the <7> (S) key to Secure the Floor.

Operation
Done

The display will briefly show the “Operation Done” message to indicate that the operation was successful and then return to the main menu.



Press the <END> key to exit to the normal display or select another Menu option.

ADJUST COUNT



Adjust Count allows a User with the appropriate authority to reset a Counter (to 0) or to set the count value to the required number.
(V3 or later only)

.Counter 001
SetCnt: 00000000

The display will show the first Counter and the current count value.



Use the <UP> and <DOWN> arrow keys to select the Counter to reset or adjust.

Camera 2 Film
SetCnt: 00000000



Use the <DIGIT> keys and <RIGHT> Arrow key (if necessary) to enter in the count value then press <OK>.

The <OFF> key can be used to clear the field. (Reset to 0)



Press the <END> key to exit to the normal display or select another Menu option.