

PROGRAMMING

ACCESS TO PROGRAMMING ON POWER UP

When power is applied to the controller for the first time, with the panel tamper input open, the panel will enter Install Program Mode. (Program light flashing). From this point you can start to enter the required program information. If the panel has previously been programmed, and the Installer Lock-out option has been enabled, the "Power up with Tamper open" access (Back-Door) **WILL NOT WORK**.

ACCESS TO PROGRAM MODES FROM RUN MODE

Before you can enter program mode, the panel must be unset with no monitor mode.

Press <PROGRAM> - <Code 1(Master Code)> - <ENTER>

Program light steady

Note: Default Master Code is 123

You are now in Client Program Mode. To enter Install Program Mode

Press <PROGRAM> - <Code 16(Install Code)> - <ENTER>

Program light flashing

Note: Default Install Code is 000000

HOW TO PROGRAM

The programming sequence always follows this pattern:

<PROGRAM> - <2 or 3 digit address> - <ENTER>

3 short beeps if OK - 1 long beep if error

The leds will display current value or status

Enter the new value or option

∴ <New Value> - <ENTER>

3 short beeps if OK - 1 long beep if error

Throughout this manual you will see program instructions expressed as
P 23 E 5 E for an example.

In this example the <P> represents the PROGRAM key and <E>
represents the ENTER key.