

TAMPER TO OUTPUTS 1-5 (P42E)

Outputs 1-5 may be programmed to operate under TAMPER Alarm conditions as required.

DAY MODE ALARMS TO OUTPUTS 1-5 (P43E)

Day Zone activations may be programmed to operate outputs 1-5 as required. The momentary timer function is normally used in conjunction with this option.

MONITOR MODE ALARMS TO OUTPUTS 1-5 (P44E)

Monitor Zone activations may be programmed to operate outputs 1-5 as required. The momentary timer function is normally used in conjunction with this option also.

PANIC TO OUTPUTS 1-5 (P45E)

Outputs 1-5 may be programmed to operate under PANIC Alarm conditions as required.

CONTROL FUNCTION TO OUTPUTS 1-5 (P46E)

Outputs 1-5 may be programmed to operate as the Control Output. Care should be taken to ensure that an output assigned as Control is not assigned to any other function.

2 SECOND AUTOEXCLUDE WARNING TO OUTPUTS 1-5 (P47E)

Outputs 1-5 may be programmed to operate for 2 seconds, at the end of the Exit Delay, when the panel Autoexcludes a zone if required.

SMOKE RESET PULSE TO OUTPUTS 1-5 (P48E)

Outputs 1-5 may be programmed to operate as the common side of the 12v supply used to power latching Smoke Detectors. When this option is selected the assigned output should have the invert output option enabled so as to provide a constant supply for the detectors. Every time the panel is set, the outputs defined as Smoke reset will change state for a period of 2 seconds. This feature is used to reset latched devices.

NOTE: 100mA available from outputs 4 to 9