

NOTE: *A separate cable entry hole into the cabinet must be used for the telephone line and any 230 volt cables.*

The transmit level from this device is set at a fixed level and because of this there may be circumstances where this device does not give its optimum performance. Before reporting such occurrences as faults, please check the line with a standard Telepermitted telephone, and do not report a fault unless the telephone performance is impaired.

PROGRAM OPTIONS

TELEPHONE NUMBERS 1-4 (P101E to P104E)

The telephone numbers you wish the communicator to dial to are set at these addresses.

eg. P 101 E 5797506 E
3 beeps - program light flashing

The stored numbers will then be flashed back on the display

In this example we have set the telephone number 579 7506 to be the first number the communicator will dial to.

If special functions or characters are required in the phone number, select them from the following list

1.5 second pause	Control Button
* character	Ann Button
# character	Monitor Button

<i>Keypad Display</i>
Armed LED
Memory LED
Exclude LED

eg. P 102 E 00 "CONTROL" 5797506 E
3 beeps - program light flashing

The stored numbers will then be flashed back on the display

In this example we have programmed the second telephone number with a pause between the 00 area code and the 579 7506 STD number.

The special function characters will be flashed back via the keypad display leds as listed above.