

P28E	Arming & Control Options (Default none)	Page 19
	1 = Keyswitch Enable/Disable	Page 20
	2 = Control Requires Code	Page 20
	3 = Control Function Toggles	Page 20
	4 = Control Function Pulses	Page 20
	5 = Control Output follows Set / Unset State	Page 20
	6 = Single button "ARM" Enable/Disable	Page 20
	7 = "Monitor" mode Enable/Disable	Page 20
	8 = User codes 11-15 Control function only	Page 20
P29E	Invert Outputs 1-8	Page 20
P30E	Invert Outputs 9	Page 20
P31E	Zones to Alarm Output 1 (Default all)	Page 21
P32E	Zones to Alarm Output 2 (Default all)	Page 21
P33E	Zones to Alarm Output 3 (Default all)	Page 21
P34E	Zones to Alarm Output 4 (Default all)	Page 21
P35E	Zones to Alarm Output 5 (Default all)	Page 21
P36E	Signals to Output 6 Options (Default 1)	Page 21
	1 = Set / Unset	Page 21
	2 = Monitor	Page 21
	3 = Mains Fail	Page 21
	4 = Battery Low	Page 21
	5 = Tamper	Page 21
	6 = Zone Excluded	Page 21
	7 = Zones Sealed (ready)	Page 21
	8 = 24hr Alarm	Page 21
P37E	Signals to Output 7 Options (Default 3)	Page 21
	As per P36E	Page 21
P38E	Signals to Output 8 Options (Default 4)	Page 21
	As per P36E	Page 21
P39E	Signals to Output 9 Options (Default 5)	Page 21
	As per P36E	Page 21
P40E	Zones to Keypad Piezo (Default all)	Page 21
P41E	Signals 5&7 to Keypad Piezo (Default 5&7)	Page 21
P42E	Tamper to Alarm Output 1-5 (Default all)	Page 22
P43E	Day Alarm to Alarm Output 1-5 (Default none)	Page 22
P44E	Monitor Alarm to Alarm Output 1-5 (Default 2)	Page 22
P45E	Panic to Alarm Output 1-5 (Default all)	Page 22
P46E	Control Function to output 1-5 (Default none)	Page 22
P47E	2 Sec Alarm on Autoexclude to Output 1-5 (None)	Page 22
P48E	Smoke Reset Pulse to Outputs 1-5 (Default none)	Page 22
P49E	Alarm Reset Time to Outputs 1-5 (Default 1-4)	Page 23
P50E	Alarm Output Delay Time to Outputs 1-5 (none)	Page 23
P51E	Momentary Output Time to Outputs 1-5 (none)	Page 23
P52E	Chirps on keyswitch ARM/DISARM to OPT 1-5	Page 23