

|      |                                                |         |
|------|------------------------------------------------|---------|
| P53E | Exit Beeps to Output 1-5 (Default none)        | Page 23 |
| P54E | Exit Delay Time (Default 60 Sec)               | Page 23 |
| P55E | Entry Delay 1 Time (Default 20 Sec)            | Page 23 |
| P56E | Entry Delay 2 Time (Default 60 Sec)            | Page 23 |
| P57E | Alarm Reset Time (Default 10 Min)              | Page 24 |
| P58E | Alarm Delay On Time (Default 5 Min)            | Page 24 |
| P59E | Momentary Output Time (Default 10 Sec)         | Page 24 |
| P60E | Two Trigger Zones Time Window (Default 60 Sec) | Page 24 |
| P61E | Duress Digit                                   | Page 24 |
| P62E | 1/2 second flash to outputs 1-5                | Page 24 |
| P70E | Radio transmitter type                         | Page 25 |
|      | 1 = DCA Elite Series                           |         |
|      | 2 = Ness 24 bit PIR's and Transmitters         |         |
|      | 3 = Ness 12 bit transmitters (Single channel)  |         |
|      | 4 = Label Micro Tx series                      |         |
|      | 5 = Spare                                      |         |
|      | 6 = Spare                                      |         |
|      | 7 = Spare                                      |         |
|      | 8 = Spare                                      |         |
| P71E | Radio User 1 options                           | Page 26 |
|      | 1 = Set / Unset 26                             |         |
|      | 2 = Monitor On / Off                           |         |
|      | 3 = Panic (after 3 seconds)                    |         |
|      | 4 = Operate output 1                           |         |
|      | 5 = Operate output 2                           |         |
|      | 6 = Operate output 3                           |         |
|      | 7 = Operate output 4                           |         |
|      | 8 = Operate output 5                           |         |
| P72E | Radio User 2 options                           |         |
| P73E | Radio User 3 options                           |         |
| P74E | Radio User 4 options                           |         |
| P75E | Radio User 5 options                           |         |
| P76E | Radio User 6 options                           |         |
| P77E | Radio User 7 options                           |         |
| P78E | Radio User 8 options                           |         |
| P79E | Radio User 9 options                           |         |
| P80E | Radio User 10 options                          |         |
| P81E | Radio PIR Zone 1                               | Page 27 |
| P82E | Radio PIR Zone 2                               |         |
| P83E | Radio PIR Zone 3                               |         |
| P84E | Radio PIR Zone 4                               |         |
| P85E | Radio PIR Zone 5                               |         |
| P86E | Radio PIR Zone 6                               |         |
| P87E | Radio PIR Zone 7                               |         |