

P151E	Misc send options 1		Page 32
	1 = Send Zone Restores	Default on	
	2 = Send Zone Excludes	Default on	
	3 = Send Test calls	Default on	
	4 = Send tampers	Default on	
	5 = Send battery low	Default on	
	6 = Send mains failure	Default on	
	7 = Send keypad panic	Default off	
	8 = Send Keypad Tamper	Default on	
P152E	Misc send options 2		Page 32
	1 = Send duress	Default off	
	2 = Send Set / Unset	Default on	
	3 = Send unset only after activation		
	4 = Keypad Listen in inhibit	Default off	
	5 = Enable Voice Dialler	Default off	
	6 = Enable communicator	Default off	
	7 = Installer Lockout	Default off	
	8 = Spare		
P153E	Delay Mains fail Report by 1 - 99 min (Default 60)		Page 33
P154E	Time between test calls	Default 24	Page 33
P155E	Time before first test call	Default 0	Page 33

COMMON CONTACT ID CODES

Medical Alarm	100 Plus extn 000
Medical Pendant	101 Plus zone number
Fire Alarm	110 Plus zone number
Smoke Detector Alarm	111 Plus zone number
Heat Detector Alarm	114 Plus zone number
Manual Call Point	115 Plus zone number
Duct Detector Alarm	116 Plus zone number
Silent Panic	122 Plus zone number
Audible Panic	123 Plus zone number
Perimeter Activation	131 Plus zone number
24 Hour Activation	133 Plus zone number
Entry / Exit Activation	134 Plus zone number
Gas Detected	151 Plus zone number
Refrigeration Alarm	152 Plus zone number
Water Leakage	154 Plus zone number
High Temperature	158 Plus zone number
Low Temperature	159 Plus zone number