

MA2600 KEYPAD PROGRAMMING SHEET

CUSTOMER: _____
 ADDRESS: _____
 ACCOUNT NO. _____
 DATE: _____
 TEL: _____

EXIT DELAY TIME (SEC) ENTRY DELAY 1 TIME (SEC) ENTRY DELAY 2 TIME (SEC)

DEFAULT PROGRAM IN PARENTHESES----> (3)

000
x16 x1

 (C) (1)

001
x16 x1

 (E) (1)

002
x16 x1

 (E)

USER ARM/DISARM CODES

USER 1						USER 2						USER 3						USER 4					
003	004	005	006	007	008	009	010	011	012	013	014	015	016	017	018	019	020	021	022	023	024	025	026
(7)	(8)	(9)																					
USER 5						USER 6						USER 7						USER 8					
027	028	029	030	031	032	033	034	035	036	037	038	039	040	041	042	043	044	045	046	047	048	049	050
USER 9						USER 10						USER 11						USER 12					
051	052	053	054	055	056	057	058	059	060	061	062	063	064	065	066	067	068	069	070	071	072	073	074
USER 13						USER 14						USER 15						USER 16					
075	076	077	078	079	080	081	082	083	084	085	086	087	088	089	090	091	092	093	094	095	096	097	098
SERVICE CODE						USER PROGRAM CODE						ACCESS CODE						AMBUSH CODE					
099	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118				

TRANSMISSION INFORMATION

DEALER SECURITY CODE*

CALLBACK TELEPHONE NUMBER

119	120	121	122	123	124	188	189	190	191	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

TEL NO. RCVR | DATA

1	208	209
2	210	211
3	212	213

DIALER TELEPHONE NUMBER

(DIAL-TONE DETECTION "E" OR PRE-DIAL DELAY "D" REQUIRED AS FIRST ENTRY)

128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147
(E)																			
148	149	150	151	152	153	154	155	156	157	158	159	160	161	162	163	164	165	166	167
(E)																			
168	169	170	171	172	173	174	175	176	177	178	179	180	181	182	183	184	185	186	187
(E)																			

ENTRY	RECEIVER FORMAT
BLANK	ADEMCO SLOW, SILENT KNIGHT SLOW
1	SESCOA, VERTEX, DCI, FRANKLIN FAST
2	RADIONICS FAST
3	SILENT KNIGHT FAST
4	RADIONICS, DCI, FRANKLIN SLOW
5	UNIVERSAL HI-SPEED
8	RADIONICS BPSK

ENTRY	DATA FORMAT
1	SUM CHECK
2	(NOT USED)
4	(NOT USED)
8	(NOT USED)
1	2300Hz HANDSHAKE
2	2300Hz KISSOFF
4	2-DIGIT OR 4/2
8	SINGLE DIGIT ONLY

*SEE LABEL ON MICRO CAN FOR MASTER SECURITY CODE. ALSO SEE "DEALER SECURITY CODE" IN GLOSSARY

MA2600 KEYPAD PROGRAMMING SHEET

SUBSCRIBER I.D. NUMBERS, TELEPHONE #1	248 249 250 251	252 253 254 255	256 257 258 259	260 261 262 263	264 265 266 267
	OPEN/CLOSE	BANK ZERO	BANK ONE	BANK TWO	BANK THREE
SUBSCRIBER I.D. NUMBERS, TELEPHONE #2	268 269 270 271	272 273 274 275	276 277 278 279	280 281 282 283	284 285 286 287
	BANK FOUR	BANK FIVE	BANK SIX	BANK SEVEN	BANK EIGHT
SUBSCRIBER I.D. NUMBERS, TELEPHONE #3	288 289 290 291	292 293 294 295	296 297 298 299	300 301 302 303	304 305 306 307
	BANK FOUR	BANK FIVE	BANK SIX	BANK SEVEN	BANK EIGHT
SUBSCRIBER I.D. NUMBERS, TELEPHONE #3	308 309 310 311	312 313 314 315	316 317 318 319	320 321 322 323	324 325 326 327
	BANK FOUR	BANK FIVE	BANK SIX	BANK SEVEN	BANK EIGHT
SUBSCRIBER I.D. NUMBERS, TELEPHONE #3	328 329 330 331	332 333 334 335	336 337 338 339	340 341 342 343	344 345 346 347
	BANK FOUR	BANK FIVE	BANK SIX	BANK SEVEN	BANK EIGHT
SUBSCRIBER I.D. NUMBERS, TELEPHONE #3	348 349 350 351	352 353 354 355	356 357 358 359	360 361 362 363	364 365 366 367
	BANK FOUR	BANK FIVE	BANK SIX	BANK SEVEN	BANK EIGHT

BANK ZERO ALARM CODES								BANK ONE ALARM CODES								BANK TWO ALARM CODES							
FIRE #1	FIRE #2	FIRE TBL	AMB	PAN	LOW	AC	BATT FAIL	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
368	370	372	374	376	378	380		385	387	389	391	393	395	397	399	401	403	405	407	409	411	413	415
(1)	(1)	(1)	(2)	(2)	(1)	(1)		(3)	(3)	(3)	(3)	(3)	(3)	(3)	(3)	(4)	(4)	(4)	(4)	(4)	(4)	(4)	(4)
369	371	373	375	377	379	381		386	388	390	392	394	396	398	400	402	404	406	408	410	412	414	416
(1)	(2)	(1)	(1)	(2)	(8)	(9)		(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)

EVENT CODES (NOT USED IN BFSK FORMAT)										
EVENT	BANK 0	BANK 1	BANK 2	BANK 3	BANK 4	BANK 5	BANK 6	BANK 7	BANK 8	
ALARM----->	(USE ABOVE ALARM CODES)			426	429	432	435	438	441	PULSE- uses above alarm codes (1st and/or 2nd code)
				(5)	(6)	(7)	(8)	(9)	(0)	BFSK - "ALARM" then 2nd code (1st if 2nd blank)
RESTORE----->	418	421	424	427	430	433	436	439	442	PULSE- Event Code then position of zone (1-8)
	(E)	(E)	(E)	(E)	(E)	(E)	(E)	(E)	(E)	BFSK - "TROUBLE" then 2nd code (1st if 2nd blank)
TROUBLE/STATUS-->	422	425	428	431	434	437	440	443		PULSE- Event Code then position of zone (1-8)
	(F)	(F)	(F)	(F)	(F)	(F)	(F)	(F)		BFSK - "TROUBLE" then 2nd code (1st if 2nd blank)

382	383	384	
(B)	(C)	(F)	
OPENING CODE	CLOSING CODE	*FORCE ARM CODE	*LEAVE BLANK IF NOT REPORTING FORCE ARM; NOT USED FOR STATUS, BFSK, 4/2.

ALARMS, BANKS 0, 1, 2	
PULSE-	uses above alarm codes (1st and/or 2nd code)
BFSK -	"ALARM" then 2nd code (1st if 2nd blank)
ALARMS, BANKS 3 THROUGH 8	
PULSE-	Event Code then position of zone (1-8)
BFSK -	"ALARM" then position of zone (1-8)
TROUBLES, BANKS 1, 2	
PULSE-	Event Code then 2nd code (1st if 2nd blank)
BFSK -	"TROUBLE" then 2nd code (1st if 2nd blank)
TROUBLES, BANKS 3 THROUGH 8	
PULSE-	Event Code then position of zone (1-8)
BFSK -	"TROUBLE" then position of zone (1-8)
RESTORES, BANKS 0, 1, 2	
PULSE-	Event Code then 2nd code (1st if 2nd blank)
BFSK -	"RESTORE" then 2nd code (1st if 2nd blank)
RESTORES, BANKS 3 THROUGH 8	
PULSE-	restore Event Code then position of zone (1-8)
BFSK -	"RESTORE" then by position of zone (1-8)
TROUBLE RESTORES, BANKS 1, 2	
PULSE-	restore Event Code then trouble Event Code
BFSK -	"RESTORE" then 2nd code (1st if 2nd blank)
TROUBLE RESTORES, BANKS 3 THROUGH 8	
PULSE-	restore Event Code then trouble Event Code
BFSK -	"RESTORE" then position of zone (1-8)

MA2600 KEYPAD PROGRAMMING SHEET

ZONE FEATURES

FEATURE	BANK TWO					BANK ONE					BANK ZERO				
	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	AC LB PA	ADDR	AM	FT	F2 F1
LOOP RESPONSE 50ms	16 15 14 13	ADDR	12 11 10 9	8 7 6 5	ADDR	4 3 2 1	AC LB PA	ADDR	AM	FT	F2 F1				
LOOP RESPONSE 10ms	8 4 2 1	624	8 4 2 1	8 4 2 1	576	8 4 2 1	*	*	*	528	*	*	*	*	*
PRIORITY ZONE	(8)(4)(2)(1)	626	(8)(4)(2)(1)	(8)(4)(2)(1)	578	(8)(4)(2)(1)	4	2	1	530	*	4	2	1	
PRIORITY WITH BYPASS	8 4 2 1	627	8 4 2 1	8 4 2 1	579	8 4 2 1	4	2	1	531	*	4	2	1	
AUTO BYPASS	8 4 2 1	628	8 4 2 1	8 4 2 1	580	8 4 2 1	*	*	*	532	*	*	*	*	*
SELECTIVE BYPASS	(8)(4)(2)(1)	629	(8)(4)(2)(1)	(8)(4)(2)(1)	581	(8)(4)(2)(1)	*	*	*	533	*	*	*	*	*
GROUP (INTERIOR) BYPASS	8 4 2 1	630	8 4 2 1	8 4 2 1	582	8 4 2 1	*	*	*	534	*	*	*	*	*
24-HOUR PROTECTION	8 4 2 1	631	8 4 2 1	8 4 2 1	583	8 4 2 1	*	*	*	535	*	*	*	*	*
SWEEP SIREN	(8)(4)(2)(1)	632	(8)(4)(2)(1)	(8)(4)(2)(1)	584	(8)(4)(2)(1)	4	2	1	536	*	4	2	1	
PULSE-SWEEP SIREN	8 4 2 1	633	8 4 2 1	8 4 2 1	585	8 4 2 1	4	2	(1)	537	*	4	2	1	
STEADY SIREN	8 4 2 1	634	8 4 2 1	8 4 2 1	586	8 4 2 1	4	2	1	538	*	4	(2)	(1)	
RELAY OUTPUT 1	8 4 2 1	635	8 4 2 1	8 4 2 1	587	8 4 2 1	4	2	1	539	*	4	2	1	
RELAY OUTPUT 2	8 4 2 1	636	8 4 2 1	8 4 2 1	588	8 4 2 1	4	2	1	540	*	4	2	1	
EXIT/ENTRY 1	8 4 2 1	637	8 4 2 1	8 4 2 1	589	8 4 2 (1)	*	*	*	541	*	*	*	*	*
EXIT/ENTRY 2	8 4 2 1	638	8 4 2 1	8 4 2 1	590	8 4 2 1	*	*	*	542	*	*	*	*	*
E/E FOLLOWER	8 4 2 1	639	8 4 2 1	8 4 2 1	591	8 4 2 1	*	*	*	543	*	*	*	*	*
AUTO RESET	(8)(4)(2)(1)	640	(8)(4)(2)(1)	(8)(4)(2)(1)	592	(8)(4)(2)(1)	*	*	*	544	*	*	*	*	*
SWINGER SHUTDOWN	(8)(4)(2)(1)	641	(8)(4)(2)(1)	(8)(4)(2)(1)	593	(8)(4)(2)(1)	*	*	*	545	*	*	*	*	*
CHIME	8 4 2 1	642	8 4 2 1	8 4 2 1	594	8 4 2 (1)	*	*	*	546	*	*	*	*	*
ABORT DELAY	8 4 2 1	643	8 4 2 1	8 4 2 1	595	8 4 2 1	*	*	*	547	*	4	2	1	
POWER-UP DELAY	8 4 2 1	644	8 4 2 1	8 4 2 1	596	8 4 2 1	*	*	*	548	*	*	*	*	*
DAY ZONE OPEN	8 4 2 1	645	8 4 2 1	8 4 2 1	597	8 4 2 1	*	*	*	549	*	*	*	*	*
DAY ZONE SHORT	8 4 2 1	646	8 4 2 1	8 4 2 1	598	8 4 2 1	*	*	*	550	*	*	*	*	*
ALARM ON DAY ZONE	8 4 2 1	647	8 4 2 1	8 4 2 1	599	8 4 2 1	*	*	*	551	*	*	*	*	*
REPORT TELCO 1															
ALARM	8 4 2 1	648	8 4 2 1	8 4 2 1	600	8 4 2 1	4	2	1	552	8	4	2	1	
ALARM RESTORE	8 4 2 1	649	8 4 2 1	8 4 2 1	601	8 4 2 1	4	2	1	553	*	4	2	1	
TROUBLE	8 4 2 1	650	8 4 2 1	8 4 2 1	602	8 4 2 1	*	*	*	554	*	*	*	*	*
TROUBLE RESTORE	8 4 2 1	651	8 4 2 1	8 4 2 1	603	8 4 2 1	*	*	*	555	*	*	*	*	*
REPORT TELCO 3 (DOUBLE OR SPLIT REPORTING)															
ALARM	8 4 2 1	656	8 4 2 1	8 4 2 1	608	8 4 2 1	4	2	1	560	8	4	2	1	
ALARM RESTORE	8 4 2 1	657	8 4 2 1	8 4 2 1	609	8 4 2 1	4	2	1	561	*	4	2	1	
TROUBLE	8 4 2 1	658	8 4 2 1	8 4 2 1	610	8 4 2 1	*	*	*	562	*	*	*	*	*
TROUBLE RESTORE	8 4 2 1	659	8 4 2 1	8 4 2 1	611	8 4 2 1	*	*	*	563	*	*	*	*	*
NO EOL RESISTOR	8 4 2 1	660	8 4 2 1	8 4 2 1	612	8 4 2 1									
PIR SUPERVISION	8 4 2 1	661	8 4 2 1	8 4 2 1	613	8 4 2 1									
TROUBLE ON OPEN	8 4 2 1	662	8 4 2 1	8 4 2 1	614	8 4 2 1									
TROUBLE ON SHORT	8 4 2 1	663	8 4 2 1	8 4 2 1	615	8 4 2 1									
TROUBLE ON NIGHT OPEN	8 4 2 1	664	8 4 2 1	8 4 2 1	616	8 4 2 1									

USERS OPENING/CLOSING

	USER				USER				USER				USER			
	* 15 14 13	ADDR	12 11 10 9	8 7 6 5	ADDR	4 3 2 1										
CLOSING REPT TELCO 1	* 4 2 1	565	8 4 2 1	8 4 2 1	564	8 4 2 1										
OPENING REPT TELCO 1	* 4 2 1	567	8 4 2 1	8 4 2 1	566	8 4 2 1										
CLOSING REPT TELCO 3	* 4 2 1	573	8 4 2 1	8 4 2 1	572	8 4 2 1										
OPENING REPT TELCO 3	* 4 2 1	575	8 4 2 1	8 4 2 1	574	8 4 2 1										

MA2600 KEYPAD PROGRAMMING SHEET

FEATURE	BANK FIVE								BANK FOUR								BANK THREE												
	POSITION				ADDR	POSITION				ADDR	POSITION				ADDR	POSITION				ADDR	POSITION								
	8	7	6	5		4	3	2	1		8	7	6	5		4	3	2	1		8	7	6	5	4	3	2	1	
	ZONE				ZONE				ZONE				ZONE				ZONE				ZONE								
	40	39	38	37		36	35	34	33		32	31	30	29		28	27	26	25		24	23	22	21		20	19	18	17
PRIORITY ZONE	8	4	2	1	770	8	4	2	1	8	4	2	1	722	8	4	2	1	8	4	2	1	674	8	4	2	1		
PRIORITY WITH BYPASS	8	4	2	1	771	8	4	2	1	8	4	2	1	723	8	4	2	1	8	4	2	1	675	8	4	2	1		
AUTO BYPASS	8	4	2	1	772	8	4	2	1	8	4	2	1	724	8	4	2	1	8	4	2	1	676	8	4	2	1		
SELECTIVE BYPASS	8	4	2	1	773	8	4	2	1	8	4	2	1	725	8	4	2	1	8	4	2	1	677	8	4	2	1		
GROUP (INTERIOR) BYPASS	8	4	2	1	774	8	4	2	1	8	4	2	1	726	8	4	2	1	8	4	2	1	678	8	4	2	1		
24-HOUR PROTECTION	8	4	2	1	775	8	4	2	1	8	4	2	1	727	8	4	2	1	8	4	2	1	679	8	4	2	1		
SWEEP SIREN	8	4	2	1	776	8	4	2	1	8	4	2	1	728	8	4	2	1	8	4	2	1	680	8	4	2	1		
PULSE-SWEEP SIREN	8	4	2	1	777	8	4	2	1	8	4	2	1	729	8	4	2	1	8	4	2	1	681	8	4	2	1		
STEADY SIREN	8	4	2	1	778	8	4	2	1	8	4	2	1	730	8	4	2	1	8	4	2	1	682	8	4	2	1		
RELAY OUTPUT 1	8	4	2	1	779	8	4	2	1	8	4	2	1	731	8	4	2	1	8	4	2	1	683	8	4	2	1		
RELAY OUTPUT 2	8	4	2	1	780	8	4	2	1	8	4	2	1	732	8	4	2	1	8	4	2	1	684	8	4	2	1		
EXIT/ENTRY 1	8	4	2	1	781	8	4	2	1	8	4	2	1	733	8	4	2	1	8	4	2	1	685	8	4	2	1		
EXIT/ENTRY 2	8	4	2	1	782	8	4	2	1	8	4	2	1	734	8	4	2	1	8	4	2	1	686	8	4	2	1		
E/E FOLLOWER	8	4	2	1	783	8	4	2	1	8	4	2	1	735	8	4	2	1	8	4	2	1	687	8	4	2	1		
AUTO RESET	8	4	2	1	784	8	4	2	1	8	4	2	1	736	8	4	2	1	8	4	2	1	688	8	4	2	1		
SWINGER SHUTDOWN	8	4	2	1	785	8	4	2	1	8	4	2	1	737	8	4	2	1	8	4	2	1	689	8	4	2	1		
CHIME	8	4	2	1	786	8	4	2	1	8	4	2	1	738	8	4	2	1	8	4	2	1	690	8	4	2	1		
ABORT DELAY	8	4	2	1	787	8	4	2	1	8	4	2	1	739	8	4	2	1	8	4	2	1	691	8	4	2	1		
POWER-UP DELAY	8	4	2	1	788	8	4	2	1	8	4	2	1	740	8	4	2	1	8	4	2	1	692	8	4	2	1		
DAY ZONE OPEN	8	4	2	1	789	8	4	2	1	8	4	2	1	741	8	4	2	1	8	4	2	1	693	8	4	2	1		
DAY ZONE SHORT	8	4	2	1	790	8	4	2	1	8	4	2	1	742	8	4	2	1	8	4	2	1	694	8	4	2	1		
ALARM ON DAY ZONE	8	4	2	1	791	8	4	2	1	8	4	2	1	743	8	4	2	1	8	4	2	1	695	8	4	2	1		
REPORT TELCO 1																													
ALARM	8	4	2	1	792	8	4	2	1	8	4	2	1	744	8	4	2	1	8	4	2	1	696	8	4	2	1		
ALARM RESTORE	8	4	2	1	793	8	4	2	1	8	4	2	1	745	8	4	2	1	8	4	2	1	697	8	4	2	1		
TROUBLE	8	4	2	1	794	8	4	2	1	8	4	2	1	746	8	4	2	1	8	4	2	1	698	8	4	2	1		
TROUBLE RESTORE	8	4	2	1	795	8	4	2	1	8	4	2	1	747	8	4	2	1	8	4	2	1	699	8	4	2	1		
REPORT TELCO 3 (DOUBLE OR SPLIT REPORTING)																													
ALARM	8	4	2	1	800	8	4	2	1	8	4	2	1	752	8	4	2	1	8	4	2	1	704	8	4	2	1		
ALARM RESTORE	8	4	2	1	801	8	4	2	1	8	4	2	1	753	8	4	2	1	8	4	2	1	705	8	4	2	1		
TROUBLE	8	4	2	1	802	8	4	2	1	8	4	2	1	754	8	4	2	1	8	4	2	1	706	8	4	2	1		
TROUBLE RESTORE	8	4	2	1	803	8	4	2	1	8	4	2	1	755	8	4	2	1	8	4	2	1	707	8	4	2	1		
NO EOL RESISTOR	8	4	2	1	804	8	4	2	1	8	4	2	1	756	8	4	2	1	8	4	2	1	708	8	4	2	1		
PIR SUPERVISION	8	4	2	1	805	8	4	2	1	8	4	2	1	757	8	4	2	1	8	4	2	1	709	8	4	2	1		
TROUBLE ON OPEN	8	4	2	1	806	8	4	2	1	8	4	2	1	758	8	4	2	1	8	4	2	1	710	8	4	2	1		
TROUBLE ON SHORT	8	4	2	1	807	8	4	2	1	8	4	2	1	759	8	4	2	1	8	4	2	1	711	8	4	2	1		
TROUBLE ON NIGHT OPEN	8	4	2	1	808	8	4	2	1	8	4	2	1	760	8	4	2	1	8	4	2	1	712	8	4	2	1		

MA2600 KEYPAD PROGRAMMING SHEET

FEATURE	BANK EIGHT								BANK SEVEN								BANK SIX														
	POSITION				ADDR	POSITION				ADDR	POSITION				ADDR	POSITION				ADDR	POSITION										
	8	7	6	5		4	3	2	1		8	7	6	5		4	3	2	1		8	7	6	5	4	3	2	1			
	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE						
	64	63	62	61		60	59	58	57		56	55	54	53		52	51	50	49		48	47	46	45		44	43	42	41		
PRIORITY ZONE	8	4	2	1	914	8	4	2	1	8	4	2	1	866	8	4	2	1	8	4	2	1	818	8	4	2	1	8	4	2	1
PRIORITY WITH BYPASS	8	4	2	1	915	8	4	2	1	8	4	2	1	867	8	4	2	1	8	4	2	1	819	8	4	2	1	8	4	2	1
AUTO BYPASS	8	4	2	1	916	8	4	2	1	8	4	2	1	868	8	4	2	1	8	4	2	1	820	8	4	2	1	8	4	2	1
SELECTIVE BYPASS	8	4	2	1	917	8	4	2	1	8	4	2	1	869	8	4	2	1	8	4	2	1	821	8	4	2	1	8	4	2	1
GROUP (INTERIOR) BYPASS	8	4	2	1	918	8	4	2	1	8	4	2	1	870	8	4	2	1	8	4	2	1	822	8	4	2	1	8	4	2	1
24-HOUR PROTECTION	8	4	2	1	919	8	4	2	1	8	4	2	1	871	8	4	2	1	8	4	2	1	823	8	4	2	1	8	4	2	1
SWEEP SIREN	8	4	2	1	920	8	4	2	1	8	4	2	1	872	8	4	2	1	8	4	2	1	824	8	4	2	1	8	4	2	1
PULSE-SWEEP SIREN	8	4	2	1	921	8	4	2	1	8	4	2	1	873	8	4	2	1	8	4	2	1	825	8	4	2	1	8	4	2	1
STEADY SIREN	8	4	2	1	922	8	4	2	1	8	4	2	1	874	8	4	2	1	8	4	2	1	826	8	4	2	1	8	4	2	1
RELAY OUTPUT 1	8	4	2	1	923	8	4	2	1	8	4	2	1	875	8	4	2	1	8	4	2	1	827	8	4	2	1	8	4	2	1
RELAY OUTPUT 2	8	4	2	1	924	8	4	2	1	8	4	2	1	876	8	4	2	1	8	4	2	1	828	8	4	2	1	8	4	2	1
EXIT/ENTRY 1	8	4	2	1	925	8	4	2	1	8	4	2	1	877	8	4	2	1	8	4	2	1	829	8	4	2	1	8	4	2	1
EXIT/ENTRY 2	8	4	2	1	926	8	4	2	1	8	4	2	1	878	8	4	2	1	8	4	2	1	830	8	4	2	1	8	4	2	1
E/E FOLLOWER	8	4	2	1	927	8	4	2	1	8	4	2	1	879	8	4	2	1	8	4	2	1	831	8	4	2	1	8	4	2	1
AUTO RESET	8	4	2	1	928	8	4	2	1	8	4	2	1	880	8	4	2	1	8	4	2	1	832	8	4	2	1	8	4	2	1
SWINGER SHUTDOWN	8	4	2	1	929	8	4	2	1	8	4	2	1	881	8	4	2	1	8	4	2	1	833	8	4	2	1	8	4	2	1
CHIME	8	4	2	1	930	8	4	2	1	8	4	2	1	882	8	4	2	1	8	4	2	1	834	8	4	2	1	8	4	2	1
ABORT DELAY	8	4	2	1	931	8	4	2	1	8	4	2	1	883	8	4	2	1	8	4	2	1	835	8	4	2	1	8	4	2	1
POWER-UP DELAY	8	4	2	1	932	8	4	2	1	8	4	2	1	884	8	4	2	1	8	4	2	1	836	8	4	2	1	8	4	2	1
DAY ZONE OPEN	8	4	2	1	933	8	4	2	1	8	4	2	1	885	8	4	2	1	8	4	2	1	837	8	4	2	1	8	4	2	1
DAY ZONE SHORT	8	4	2	1	934	8	4	2	1	8	4	2	1	886	8	4	2	1	8	4	2	1	838	8	4	2	1	8	4	2	1
ALARM ON DAY ZONE	8	4	2	1	935	8	4	2	1	8	4	2	1	887	8	4	2	1	8	4	2	1	839	8	4	2	1	8	4	2	1
REPORT TELCO 1																															
ALARM	8	4	2	1	936	8	4	2	1	8	4	2	1	888	8	4	2	1	8	4	2	1	840	8	4	2	1	8	4	2	1
ALARM RESTORE	8	4	2	1	937	8	4	2	1	8	4	2	1	889	8	4	2	1	8	4	2	1	841	8	4	2	1	8	4	2	1
TROUBLE	8	4	2	1	938	8	4	2	1	8	4	2	1	890	8	4	2	1	8	4	2	1	842	8	4	2	1	8	4	2	1
TROUBLE RESTORE	8	4	2	1	939	8	4	2	1	8	4	2	1	891	8	4	2	1	8	4	2	1	843	8	4	2	1	8	4	2	1
REPORT TELCO 3 (DOUBLE OR SPLIT REPORTING)																															
ALARM	8	4	2	1	944	8	4	2	1	8	4	2	1	896	8	4	2	1	8	4	2	1	848	8	4	2	1	8	4	2	1
ALARM RESTORE	8	4	2	1	945	8	4	2	1	8	4	2	1	897	8	4	2	1	8	4	2	1	849	8	4	2	1	8	4	2	1
TROUBLE	8	4	2	1	946	8	4	2	1	8	4	2	1	898	8	4	2	1	8	4	2	1	850	8	4	2	1	8	4	2	1
TROUBLE RESTORE	8	4	2	1	947	8	4	2	1	8	4	2	1	899	8	4	2	1	8	4	2	1	851	8	4	2	1	8	4	2	1
NO EOL RESISTOR	8	4	2	1	948	8	4	2	1	8	4	2	1	900	8	4	2	1	8	4	2	1	852	8	4	2	1	8	4	2	1
PIR SUPERVISION	8	4	2	1	949	8	4	2	1	8	4	2	1	901	8	4	2	1	8	4	2	1	853	8	4	2	1	8	4	2	1
TROUBLE ON OPEN	8	4	2	1	950	8	4	2	1	8	4	2	1	902	8	4	2	1	8	4	2	1	854	8	4	2	1	8	4	2	1
TROUBLE ON SHORT	8	4	2	1	951	8	4	2	1	8	4	2	1	903	8	4	2	1	8	4	2	1	855	8	4	2	1	8	4	2	1
TROUBLE ON NIGHT OPEN	8	4	2	1	952	8	4	2	1	8	4	2	1	904	8	4	2	1	8	4	2	1	856	8	4	2	1	8	4	2	1

MA2600 KEYPAD PROGRAMMING SHEET

			455		
					(4)
RESET TEST TIMER ON ANY REPORT	1	1			BACKUP REPORTING TELCO 1, 2
ACTIVATE ZONE 14 ON EZM TAMPER	2	2			TOUCHTONE DIALING ONLY
(RESERVED)	4	(4)			TOUCHTONE WITH ROTARY BACKUP
(RESERVED)	8	8			REPORT TEST TIMER ON ZONE 16

TEST TIMER POWER-UP OFFSET	456		457	TEST TIMER REPORT INTERVAL
(HOURS)				(DAYS)
	x16	x1	x16	x1

			969		
DISABLE FUNCTION-8 DOWNLOAD	1	1			INTERIOR NORMALLY BYPASSED
DISABLE CALLBACK DOWNLOAD	2	2			(RESERVED)
DISABLE CARRIER DOWNLOAD	4	4			RESET DAY ZONE WITH ARM/DISARM ONLY
DISABLE AUTO-RESET ON DAY ZONE	8	8			WATCH ON WITH FUNCTION 2

			970		
					(2)
ACCESS CONTROL ON RELAY OUTPUT 2	1	1			AUTO BELL TEST UPON ARMING
EASY ARM WITH ON/OFF BUTTON	2	(2)			AUTO RESET AFTER SWEEP SIREN TIME-OUT
REPORT SERVICE CODE AS USER 15	4	4			POWER UP IN LAST STATE
START EXIT DELAY AFTER RINGBACK	8	8			DISABLE SMOKE RESET ON RELAY 1

			971		
					(D)
ENABLE RED BUTTONS AS FIRE ZONE	(1)	1			OPENING REPORT ONLY AFTER ALARM REPORT
ENABLE GREEN BUTTONS AS ZONE 15	2	2			CLOSING ONLY ON FORCE ARM (AUTO BYPASS)
ENABLE BLUE BUTTONS AS PANIC	(4)	4			INCL SEL/GRP BYPASS IN FORCE ARM/STATUS
ENABLE TELCO TEST ON KEYPAD TEST	(8)	8			STATUS RPT (AUTO-BYPASS ZONES ON CLOS.)

TIME-OUTS	x16	x1
RELAY OUTPUT 1 TIME	960	
(MINUTES)		
RELAY OUTPUT 2 TIME	961	
(MINUTES)		
RELAY OUTPUT 2 ACCESS CONTROL TIME	962	
(SECONDS)		
SWEEP SIREN TIME	963	
(MINUTES)		(.,F)
PULSE-SWEEP SIREN TIME	964	
(MINUTES)		(.,F)
STEADY SIREN TIME	965	
(MINUTES)		(.,F)
ABORT DELAY TIME	966	
(SECONDS)		
CHIME TIME	967	
(SECONDS)		(.,2)
AC FAIL REPORT DELAY	968	
(MINUTES)		(4.,)
PIR SUPERVISION	992	
(24 DISARMED HOURS)		

CLEAR SHUTDOWN MESSAGE	990
NUMBER OF RINGS BEFORE	993
CALLBACK (3 TO 15)	
NUMBER OF KEYPADS	995
NUMBER OF EZM GROUPS	996
(4 ZONES = 1 GROUP)	
CLEAR DEALER PROGRAM	997
LOAD DEFAULT PROGRAM	998
*LOAD PROM	999

*NOTE: LOADING DATA FROM A PROM
WILL ERASE PREVIOUS PROGRAMMING
EXCEPT FOR THOSE FEATURES/CODES
NOT PROGRAMMABLE BY PROM.