

PARKEP-03



318/433MHz V1.2

# PROGRAMMING CARD

Press "PROG" button + [ENTER] + [INSTALLER CODE] + [SECTION]  
+ *required data* + [ENTER]

\* = DEFAULT SETTING


| Section | Data                    | Description              |
|---------|-------------------------|--------------------------|
| [00]    | ___/___/___/___/___/___ | Installer Code* (757575) |
| [01]    | ___/___/___/___/___/___ | User Access Code 1       |
| [02]    | ___/___/___/___/___/___ | User Access Code 2       |
| [03]    | ___/___/___/___/___/___ | User Access Code 3       |
| [04]    | ___/___/___/___/___/___ | User Access Code 4       |
| [05]    | ___/___/___/___/___/___ | User Access Code 5       |
| [06]    | ___/___/___/___/___/___ | User Access Code 6       |
| [07]    | ___/___/___/___/___/___ | User Access Code 7       |
| [08]    | ___/___/___/___/___/___ | User Access Code 8       |

- [09] Press [ENTER] & button 1 twice to assign RC to User 1 ☐  
 [10] Press [ENTER] & button 1 twice to assign RC to User 2 ☐  
 [11] Press [ENTER] & button 1 twice to assign RC to User 3 ☐  
 [12] Press [ENTER] & button 1 twice to assign RC to User 4 ☐  
 [13] Press [ENTER] & button 1 twice to assign RC to User 5 ☐  
 [14] Press [ENTER] & button 1 twice to assign RC to User 6 ☐  
 [15] Press [ENTER] & button 1 twice to assign RC to User 7 ☐  
 [16] Press [ENTER] & button 1 twice to assign RC to User 8 ☐


## Remote Control Options

|               |        | Keys (on/off) |     |     |     |     |     |     |     |
|---------------|--------|---------------|-----|-----|-----|-----|-----|-----|-----|
|               |        | [1]           | [2] | [3] | [4] | [5] | [6] | [7] | [8] |
| Section [17]: | User 1 | ___           | ___ | ___ | ___ | ___ | ___ | ___ | ___ |
| Section [18]: | User 2 | ___           | ___ | ___ | ___ | ___ | ___ | ___ | ___ |
| Section [19]: | User 3 | ___           | ___ | ___ | ___ | ___ | ___ | ___ | ___ |
| Section [20]: | User 4 | ___           | ___ | ___ | ___ | ___ | ___ | ___ | ___ |
| Section [21]: | User 5 | ___           | ___ | ___ | ___ | ___ | ___ | ___ | ___ |
| Section [22]: | User 6 | ___           | ___ | ___ | ___ | ___ | ___ | ___ | ___ |
| Section [23]: | User 7 | ___           | ___ | ___ | ___ | ___ | ___ | ___ | ___ |
| Section [24]: | User 8 | ___           | ___ | ___ | ___ | ___ | ___ | ___ | ___ |


| OFF      | Key | On                                                                                                |
|----------|-----|---------------------------------------------------------------------------------------------------|
|          | [1] | } Set arming methods<br>see table on<br>next page                                                 |
|          | [2] |                                                                                                   |
|          | [3] |                                                                                                   |
| Disabled | [4] | * Button 1 PGM Enabled                                                                            |
| Disabled | [5] | * Button 2 PGM Enabled                                                                            |
| Disabled | [6] | * Button 3 PGM Enabled                                                                            |
| Disabled | [7] | * Button 4 PGM Enabled                                                                            |
| Disabled | [8] | * Panic Enabled (simultaneously<br>press buttons 1 and 2 or 3 and<br>4 to activate a panic alarm) |




= Button 1



= Button 3



= Button 2



= Button 4

| Key<br>[1] | Key<br>[2] | Key<br>[3] | Description                                            |
|------------|------------|------------|--------------------------------------------------------|
| Off        | Off        | Off        | No Arming & Disarming                                  |
| On         | Off        | Off        | * Button 1 = Regular Arming                            |
| Off        | On         | Off        | Button 2 = Regular Arming                              |
| On         | On         | Off        | Button 1 = Regular Arming<br>Button 2 = Regular Arming |
| Off        | Off        | On         | Button 1 = Away Arming                                 |
| On         | Off        | On         | Button 1 = Away Arming<br>Button 2 = Stay Arming       |
| Off        | On         | On         | Button 1 = Regular Arming<br>Button 2 = Stay Arming    |
| On         | On         | On         | Button 1 = Stay Arming                                 |

### Panic Output Programming

Section [25]:  (select one digit only)

- [0] = Disabled
- [1] = Activate output 1 on panic alarm
- [2] = Activate output 2 on panic alarm
- \* [3] = Activate output 3 on panic alarm
- [4] = Activate output 4 on panic alarm

### Panic Lockout Timer

Section [26]:  (select one digit only)

- \* [0] = Disabled
- [1] = 30-second signal lockout on panic alarm
- [2] = 60-second signal lockout on panic alarm
- [3] = 90-second signal lockout on panic alarm
- [4] = 120-second signal lockout on panic alarm

### PGM Options Timing

Section [27]:  PGM 1 (select one digit only)

Section [28]:  PGM 2 (select one digit only)

Section [29]:  PGM 3 (select one digit only)

Section [30]:  PGM 4 (select one digit only)

[0] = Latched [3] = 10 seconds [6] = 60 seconds

[1] = 1 second [4] = 20 seconds [7] = 2 minutes

\* [2] = 5 seconds [5] = 40 seconds [8] = 4 minutes

### PGM Options

Keys (on/off)

[1] [2] [3] [4]

PGM1 PGM2 PGM3 PGM4

Section [31]: Button 1 (default: [1] on)    

Section [32]: Button 2 (default: [2] on)    

Section [33]: Button 3 (default: [3] on)    

Section [34]: Button 4 (default: [4] on)    

Key ON activates corresponding PGM

Key OFF disables corresponding PGM

### Section [35]: General Options

|          |                                                                                   |     |                                                                                     |                                                                      |
|----------|-----------------------------------------------------------------------------------|-----|-------------------------------------------------------------------------------------|----------------------------------------------------------------------|
|          | OFF                                                                               | Key | ON                                                                                  |                                                                      |
| 4-Digit  |  | [1] |  | * 6-Digit Access Codes                                               |
| PGM only |  | [2] |  | * Panic activates enabled PGM & sends panic command to control panel |

**P A R A D O X**  
SECURITY SYSTEMS  
730 Industrial Blvd., St-Eustache, Montreal  
Quebec, Canada J7E 5V3  
Fax: (514) 844-2215 <http://www.paradox.ca>

Paradox Security Systems  
Graphic Dept.  
MONTREAL CANADA Q7E 5V3